




PLEASE READ THIS USER MANUAL CAREFULLY BEFORE SYSTEM CONNECT

210mm

Before using this machine, please read all the safety and operating instructions, meanwhile, please observe all the indications about safe operating. These safety and operating instructions should be kept in condition of consultation.



Attention: This set applies to AC 110V / 50Hz~60Hz power supply. Use standard power supply
Please be sure for te correct power supply before use it.

- Wireless
- Plays songs stored in external audio device.
- Guitar input • Microphone inputs
- Wireless microphone included • With remote control
- Built-in rechargeable battery • Super dynamic sound speaker
- X-Bass is powerful

- Standby
- LINE (Audio input)
- Prev/FM CH-
- Play/pause/FM tun
- Next/FM CH+
- Repeat
- Stop
- Volume up
- Volume down
- Mute
- Equalizer
- Number

1. This set applies to AC 110V, 50/60Hz
2. AC power: battery can be charged when connected to AC power.
Red light on battery is charging, it will change to green once battery complete charge.
3. Internal battery will be charged even device switch off when plugged in to AC power
4. Speaker battery can be charged using 12V external car battery as well(connect cable not included) by "DC 12V input". Please make sure "+" and "-" in right connection.
5. Adjust function keys to your personal audio preference.

1. The unit takes approximately 8 hours to fully charge. It will automatically begin charging once the power cord is connected.
2. If the battery power is low may caused sound distortion or stop play, please charging the battery on time.
3. To maximize the battery's lifespan, please charging the battery immediately. When the unit is not used for prolonged periods of time, the battery will gradually lose its power. It is recommended to fully charge the battery at least every 30days.
4. To saving battery, please power off once stop using.

When you turn on the speaker, the display will read OPEN that means your speaker is ready to connect. Go to your smart device and search for your BT device. You will see the device name MPD18XB(INFERNO-18) and please select that. Please select MPD18XB(INFERNO-18) and you will be connected.

Secondary Speaker


Primary Speaker

Wireless device

First bring two speakers next to each other, turn on both the speakers. Both the speakers display should read open. The first speaker/primary speaker, please press and hold the TWS button for 3 seconds. The primary speaker will sound an alarm and the display will show "BTST" and the second speaker automatically connect to the primary speaker. The display of secondary speaker will say BT.

Now you may connect to BT from your smart device and listen to music from both your speaker.

MODE: MODE SELECT
REC: RECORDING/INSERT CARD PRESS THIS BUTTON FOR
 RECORDING/PRESS AGAIN TO STOP AND PLAY RECORDING SOUND
⏮: PREVIOUS SOUND
⏭: NEXT SOUND
LED MODE ADJUSTMENT
DISC WIRELESS DISCONNECTED
1 **TWIS/SCAN:** PLAY/PAUSE/TWIS/FM STATION AUTOMATIC SEARCH
REPEAT
2 **VOLUME:** MASTER VOLUME ADJUST
3 **DC 12V INPUT:** DC 12V CHARGING INPUT
4 **AUDIO INPUT**
5 **EQUALIZER**
6 **DISPLAY SCREEN**
7 **POWER:** ON/OFF SWITCH
8 **M.HI:** INCREASE/DECREASE MICROPHONE TREBLE
9 **M.LO:** INCREASE/DECREASE MICROPHONE BASS
ECHO: ECHO ADJUST
GT.VOL: GUITAR VOLUME ADJUST
X-BASS: X-BASS ADJUST
9 **MIC:** MICROPHONE INPUT JACK
GTIN: GUITAR INPUT JACK
MIC PRI: MICROPHONE PRIORITY ON/OFF SWITCH
10 **CARD SLOT**
11 **MIC.VOL:** MICROPHONE VOLUME ADJUST



The back panel features several ports and labels:

- WARNING:** A label with a lightning bolt icon and the text: "DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE."
- CAUTION:** A label with a lightning bolt icon and the text: "DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE."
- POWER INPUT (AC110V-240V):** A label above a rectangular power input port.
- FM ANTENNA:** A label next to a circular antenna port.

- ① POWER INPUT(AC 110V-240V)
② FM ANTENNA

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

-148.5mm

-148.5mm

-148.5mm

-148.5mm

-148.5mm