

EB5232 User's manual

Please follow the below steps to operate your EB5232 earphones
Ensure the full power for EB5232

Please prepare well for EB5232 and smartphone for pairing

Charging for Bluetooth headphones

Please use charging cable to connect power sources and EB5232 for charging. If charging well, the power indicator light will be red.

Turn on Bluetooth headphones

Please press Multi-function button (central button in the controller) for 5 seconds, and hear the sound, it means that EB5232 is turned on, and now the twinkling light (Red & Blue) is lighting, it means EB5232 is ready for pairing.

Turn-off EB5232

If EB5232 is turned on, you can press Multi-function button for 5 seconds till light turns off!

Bluetooth pairing

Please turn of EB5232 for pairing status, (Twinkling light for Red & Blue when you press Multi-function button for 5 seconds).

Then turn on the BT function from Smartphone and search EB5232 code, then press connection code for connecting.

If you want to change to another new Bluetooth smartphone or smart devices when EB5232 pairs with 1st Bluetooth smartphone, you can press Multi-function button for 2 seconds for change new pairing status.

If pairing well, you can use EB5232 for phone call and music playing

Get the phone call

When pairing well with smartphone, you can press the Multi-function phone call simply.
If you want to reject phone call, you can press Multi-function for 2 seconds or more.

End for phone call

If EB5232 in the phone call, you can press Multi-function once to take off phone call !

Dial the latest phone no.

Under the stand-by status for EB5232, you can press multi-function button 2 times continuously, you can dial the latest phone call.

Play / Pause

Under the working status, you can press Multi-function button in short time, it means Pause function for music playing. Press again, music playing again !

Back music

Press Button “ ____ “, play the backward music

Music forward

Press Button “ + “, play the forward music

Increase volume

During playing music or phone call, press button “ + “ for longer time for increasing volume to Maximum (Du sound for Max volume).

Decrease volume

During playing music or phone call, press button “ ____ “ to decrease volume to the Min. (Du means Min).

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.