


FRONT

———— Die lines (DO NOT PRINT)
- - - - Crease lines (DO NOT PRINT)


4C double sided print

the accordion fold



SPLASH

WIRELESS SHOWER SPEAKER



SPEAKER FEATURES

1. Previous Track/Volume Down
2. Play/Pause/ Answer Phone
3. Next Track/Volume Up
4. LED indicator
5. 3.5mm audio input port
6. Micro USB charging port
7. On/Off power switch

INDICATORS

INDICATOR (Control Buttons)	STATUS
Bluetooth	Blinking Blue and Red
	Light in Blue
Battery	Light in Red
	Charging

BLUETOOTH PAIRING

1. Turn the speaker on (turn switch to on).
 2. Make sure your device has Bluetooth capability.
 3. Follow the instructions of your device to pair the unit.
 5. Select "SPLASH" from the Bluetooth list on your device.
- *The speaker is defaulted to Bluetooth mode.

HANDS FREE INSTRUCTIONS

When there is a call coming in answer on your phone or press the phone button on the speaker to answer, playing music will pause; then press again to end call. Hold phone button for 3 seconds to refuse call.

AUDIO CONTROLS

1. Adjust the volume by holding Volume Up or Volume Down buttons on the speaker; or native controls on your audio device.
2. Press pause button on the speaker to play/pause the song or press play/pause on your Bluetooth device.
4. When not playing music, turn the power button to OFF.

AUX-IN MODE

1. Plug one end of a 3.5mm Audio cable into the unit.
2. Plug the other end of the 3.5mm Audio cable into your audio device.
3. Turn the speaker on, it will play music from the audio device.
4. Adjust the volume by pressing Volume Up or Volume Down buttons on the speaker; or native controls on your audio device.
5. If you want to play/pause the tune, press the play/pause button or control the native buttons on your audio device.

CHARGING THE UNIT

Connect the device to computer or adapter with micro USB cable, LED indicator will turn red. When fully charged LED indicator will turn off.

SPECIFICATIONS

- Speaker size: 3.07in x 5.51in
- Power by USB cable: DC 5V
- Rechargeable Li-Ion battery included
- Battery capacity: 5V 450mAh
- Battery life: 3-4Hrs (Volume at 70%)
- Working distance: < 50ft (10 m) (Distance may vary between different cellphone Bluetooth devices and the environment)

This product is not a toy.



Made in China exclusively for
iWave Secure Media, Inc.
New York NY 10018
support@iwaveaudio.com
www.iwaveaudio.com



iWave and the iWave logo are registered trademarks of iWave Secure Media, Inc.
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by iWave is under license. All other trademarks and trade names are those of their respective owners.

SAFETY INFORMATION

⚠ WARNING:
Please read these safety warnings and cautions carefully to ensure your personal safety and prevent property damage.

Fire and Electric Shock Hazard

- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects in to the speaker. Such actions could result in electric shock.
- Clean the speaker only with a dry cloth.
- Do not expose your speaker to extremely high or low temperatures.
- Do not leave your speaker in direct sunlight for extended periods of time.
- Do not leave your speaker near open flames such as cooking burners, candles, or fireplaces.
- Do not block any ventilation openings.

Battery/Charger Hazard

1. It's dangerous if you replace the battery improperly.
2. You can only use the same type or equivalent type of battery to replace the damage one.
3. Battery shall not be exposed to an overheating environment such as sunshine and fire.

Warning:
To reduce the risk of electric shock, do not remove cover (or back). Refer servicing to qualified service personnel.

Automobile Accident Hazard

- Do not leave or store the speaker or any of its accessories near or over your automobile's air bag as serious injury may result when an air bag deploys.

Fall Hazard

- Do not place the speaker on high surfaces such as shelves. During music playback the speaker may move which could cause the speaker to shift and fall off of the edge.

⚠ CAUTION:

- Do not use abrasive cleaners to clean your speaker. It could cause scratches and damage.
- Do not bring your speaker in to contact with any sharp objects. It could cause scratches and damage.
- Do not insert anything into your speaker unless otherwise specified in the user instructions. This may damage the internal components.
- Do not attempt to repair, modify, or disassemble your speaker yourself, it does not contain any user-serviceable components.
- Do not attempt to replace your speaker battery, it is built-in and is not changeable.
- Use only the manufacturer supplied charger to charge your speaker. Other chargers may look similar, but using them could result in electric shock and could damage.
- Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.
- Turn off your speaker prior to boarding an aircraft. Do not use the speaker inside an aircraft unless allowed by your airline.
- Dispose of the speaker and its battery in accordance with local regulations. Do not dispose of the battery with regular household waste.

FCC Disclaimer:

This device Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions;

- (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.
- Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.
- Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.



www.iwaveaudio.com

