


100mm

140mm

VT NEXUS 34/36 Series Headset




Headset Components

- | | |
|--|--|
| 1 Primary microphone | 9 Clothing clip |
| 2 Secondary microphone 2
(Only for VT NEXUS 36) | 10 Cable |
| 3 Flex boom | 11 USB 06 Controller
(VT NEXUS 34/36) |
| 4 Ear cushion | 12 USB 04 Controller
(VT NEXUS 34 Lite) |
| 5 Wideband Speaker | 13 Type A and Type C |
| 6 Headband | 14 T-bar |
| 7 Busylight | |
| 8 Secondary microphone 1 | |

2


Headset Components

1. Mute-microphone
2. Volume control button
3. Hook On/Off Key
4. Ringtone speaker
(with on/off switch:
press and hold the
mute button 2s)



Connection

1. Connect your Headset to an available USB A or USB C port on your PC.
2. Make sure the headset is set as the default audio device in your system's sound settings.
3. Refer to your softphone application's user guide to check if additional audio settings are required for headset use.



Compatibility & Feature

The headset is compatible with leading UC Platforms, including Microsoft Teams, Cisco Jabber, Avaya Workplace, Linkus, MicroSIP, etc.
Dual-microphone or Three microphones ENC technology filters out background noise for crystal-clear calls.

3


How to Wear the Headset



Expand or contract the headband until it feels comfortable and secure. The ideal fit should exert little to no pressure on your ears.



For clear, crisp audio and to prevent low or distorted sound, position the microphone 20-30 mm from the corner of your mouth. The flexible boom arm can be adjusted in multiple directions to achieve the perfect position.




Use the included clothing clip to secure the cable. Fasten it at a comfortable height, ensuring there is enough slack in the cable to allow natural head movement without pulling on or displacing the headset.

4

Wearing Your Headset


To switch sides, rotate the microphone boom over the headband to wear the headset on your left or right ear.

Auto Mute: The microphone is automatically muted when you flip the boom arm up to the stowed position against the headband.




Ear Cushion Removal

To remove the earmuff, rotate it counterclockwise and pull it off. After cleaning or replacement, align it with the designated position on the earcup and rotate it clockwise until you hear a "click," which confirms it is properly seated



Maintenance

The ear cushions can be removed for cleaning or replacement.



5

Safety

For your own safety, this product should only be used with CE and RoHS approved equipment. Using this headset with non approved equipment can void this product warranty.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Xiamen VBeT Electronics Co.,Ltd

Add: Unit 701-702, Building #1, No.4 Xingqi Road , Tongxiang
High-tech City, Xiamen Torch Hi-tech Industrial Development Zone.
Xiamen, Fujian, China P.C 36110
Tel : +86-592-5778728
Fax: +86-592-5778708
E-mail: sales@vbetglobal.com
Web: www.vbetglobal.com
N34-02003-A1



6



VT N34/36 Series User Manual