






1-N41-PC2-30-60-M-16-CP-QPSK-Edge_1R
B_Left-1@0-30-1000-Ant1--61.88--35-PASS




1-N41-PC2-30-60-M-16-CP-QPSK-Edge_1R
B_Left-1@0-1000-3000-Ant1--41.92--25-PASS



1-N41-PC2-30-60-M-16-CP-QPSK-Edge_1R
B_Left-1@0-3000-18000-Ant1--36.22--25-PASS




1-N41-PC2-30-60-M-16-CP-QPSK-Edge_1R
B_Left-1@0-18000-26500-Ant1--42.40--25-PASS




1-N41-PC2-30-60-M-17-CP-QPSK-Edge_1R
B_Right-1@161-30-1000-Ant1--62.03--35-PA
SS









1-N41-PC2-30-60-M-17-CP-QPSK-Edge_1R
B_Right-1@161-1000-3000-Ant1--42.09--25-
PASS








1-N41-PC2-30-60-M-17-CP-QPSK-Edge_1R
B_Right-1@161-3000-18000-Ant1--36.96--25
-PASS





1-N41-PC2-30-60-M-17-CP-QPSK-Edge_1R
B_Right-1@161-18000-26500-Ant1--42.59--2
5-PASS













1-N41-PC2-30-60-M-23-CP-64QAM-Edge_1
RB_Right-1@161-30-1000-Ant1--62.09--35-P
ASS



1-N41-PC2-30-60-M-23-CP-64QAM-Edge_1
RB_Right-1@161-1000-3000-Ant1--42.11--2
5-PASS



1-N41-PC2-30-60-M-23-CP-64QAM-Edge_1
RB_Right-1@161-3000-18000-Ant1--36.37--
25-PASS



1-N41-PC2-30-60-M-23-CP-64QAM-Edge_1
RB_Right-1@161-18000-26500-Ant1--42.48-
-25-PASS