


Multi-Function Keyboard with Touchpad
for Surface Pro 4 & Surface Pro 3
User Manual
Model:HB187

Package Contents

1. Bluetooth Keyboard with touchpad
2. MicroUSB charging cable
3. User Manual

Product Overview



- ① Power on/off: Press 1.5 seconds, the keyboard turns on; Re-press 3 seconds to close.
② Bluetooth pairing: Press "FN + " keys together for connecting.
③ Backlit on/off: Only for keyboard with backlit.

Backlit of keyboard guide (Only for Keyboard with backlit)

1. Lighting ON/OFF Key.
Press first time is turning on the light.
Press second time is increasing brightness.
Press third time is lighting off.
2. + ^ / v to change the backlit colors. (7-color backlit)
3. When the battery is less than 20%, the backlit will be turnt off.
4. The backlit won't work until the keyboard paired with your tablet.

Specifications

Bluetooth Specification	Bluetooth 3.0
Touchpad	Elan chip, with left and right click control keyboard
Operating Range	Up to 33 feet or 10 meters
Lithium Battery Capacity	750 mAh
Standby Time	90 days
Charge Time	< 4 hours
Uninterrupted Work Time without backlit	187 hours
Uninterrupted Work Time with backlit	5 hours
Lithium Battery Life	3 years
OS Supported	Windows

Keys and Functions

ON/OFF	Mouse right button	Backlit on/off
Touchpad on/off	Reduce brightness	Increase brightness
Play/pause	Mute	Volume down
Volume up	Prt Sc	Screenshot
Home	Cursor to the Front	
End	Line End	Page front
Page End	Battery Power Display	

Pairing Instruction

1. Press 1.5 seconds, the keyboard turns on, green light will be on for 10 seconds.
2. Press the "FN + " keys together to enter pairing mode. The blue Bluetooth indicator will start to rapidly flash.
3. Go to your "SETTINGS" screen on your tablet with Bluetooth -enabled device, activate its Bluetooth function and search for the keyboard device.
4. "Bluetooth 3.0 Keyboard" should appear.
5. Select "Bluetooth 3.0 Keyboard" on your tablet and the keyboard will now be paired. The Bluetooth indicator will be off.

SPECIAL NOTE:

1. Please get it charged before first usage.
2. Only one device can be actively paired at one time.
3. After pairing for the first time, your tablet will connect to the keyboard automatically when opening the keyboard.
4. In case of connect failure, delete the pairing record from your tablet, and try the above procedures again.

Gestures supported Win 10

Single-finger tap	Mouse left button	Single-finger slide	Move the mouse cursor
Single finger quick click, not loose, to drag	Left button select the target, to drag	Double finger tap	Mouse right button
Two-finger vertical movement	Middle key vertically scroll, sliding the mouse wheel	Two-finger along a straight line outward move	Zoom in
Two-finger along a straight line inward move	Zoom out	Three-fingers click	Open cortana
Three-fingers slide up	Open the window of Task browser	Three-fingers slide up	Show Desktop
Three-fingers slide to the left or right	Switch Active window	Four-fingers click	Open Action Center

Slide from the left edge to right	Open the window of Task browser	Slide from the right edge to left	Open Action Center
Slide from the up edge to bottom	Show Desktop	Slide from the bottom edge to up	Show hidden icons

Power Saving Mode

The keyboard will enter sleep mode when idle for 30 minutes. To re-activate it, press any key and wait for 3 seconds.

Charge it

1. Use the included USB cable for charging. Connect one end to a USB charger, and the other to the keyboard. (charger is not included)
2. In charging, the power indicator will turn red. Generally, it takes approximately 4 hours for a full charge.

Caution

It is recommended that you turn off the keyboard to conserve the battery life.

Troubleshooting

If you are unable to connect the keyboard to your tablet, please try the following:
1. Starting with a full charge on both devices ensures that process won't be interrupted by a low battery.
2. Make sure your tablet's Bluetooth is on.
3. Make sure that the keyboard is within the effective operation distance of 33 feet (10 M).
4. To clean the keyboard, gently wipe it by using a moist cotton cloth.
5. Make sure the keyboard is turned off before cleaning. Do not use liquid cleaner.
6. Please do not spill coffee, tea or other liquids on the keyboard.

Safety Instructions

1. Keep the keyboard away from sharp objects that could damage it.
2. Do not put heavy objects on the keyboard.
3. Do not stretch, twist or apply force to the keyboard.
4. To clean the keyboard, gently wipe it by using a moist cotton cloth.
5. Make sure the keyboard is turned off before cleaning. Do not use liquid cleaner.
6. Please do not spill coffee, tea or other liquids on the keyboard.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.