

XO HEADSET MANUAL

사이즈: 145 x 520 mm
(접지시 최종사이즈: 145 x 65 mm)
미색모조지 80g
영/한 양면 인쇄 , panton coolgray 7u(별색1도)

/groove,
made to meet — your
colorful taste


bluetooth
headset manual

XODJ

Groove is compatible with any Bluetooth devices
(Mobile phones, PC, PMP, TV, etc.)

Contents : Groove, Earbuds, USB charging cable, Manual (includes Warranty)

01 / Overview



02 / Charging the groove

- Before you use the Groove, it is important to bring the power up to full charge for maximum talk time. The RED LED turns off when the battery is fully charged.
- Audible Battery Status Alert

High	Medium	Low
Battery High	Battery Medium	Battery Low
- Always keep the battery between -10 °C and 50 °C for optimal performance. Extreme temperatures reduce the capacity and lifetime of the battery.
- Audible Battery Status Alert: Press PLAY button for more than 2,5 seconds.

03 / Connect to your mobile phone

- The Groove must be paired with a Bluetooth compatible device for the first time use.
You only need to pair the Groove with your mobile phone for one time. After the Groove is connected to your device, it is ready for use.
- a. Turn on your mobile phone and the Groove.
(The WHITE/RED LED will flash with voice announcement of 'paring' to indicate pairing mode.)
- b. Activate the Bluetooth function on your mobile phone.(See the user guide of your mobile phone for instruction.)
- c. Search and select the 'XODJ Groove' from the list of founded devices.
(Enter the passcode (PIN number) '0000' to pair and connect to your mobile phone, if required.)
- d. If the pairing is successful, you will hear the voice announcement of 'paired' or 'connected' and the WHITE LED will be flashed every 6 seconds.

04 / Connect to other mobile phones

- 'Connect to other mobile phones' is required if you want to connect with a different mobile phone while the Groove is already pairing with the mobile phone initially connected.
- a. Turn on the Groove and press 'PLAY / CALL' buttons at the same time for 2 seconds.
(The WHITE/RED LED will flash with voice announcement of 'paring' to indicate pairing mode.)
- b. Activate the Bluetooth function on your mobile phone.
(See the user guide of your mobile phone for instruction.)
- c. Search and select the 'XODJ Groove' from the list of founded devices.
(Enter the passcode (PIN number) '0000' to pair and connect to your mobile phone, if required.)
- d. If the Groove cannot be connected, delete 'XODJ Groove' from the list of founded devices on your mobile phone. Then try again.

05 / Multi-connection

- Multi-connection enables your Groove to maintain an active connection with two mobile phones at once.
(Your mobile phones must be Bluetooth compatible.)
- a. Pair the Groove with one of your mobile phones.(See 'Connect to your mobile phone' in this page.)
- b. Be ready to pair the Groove with your second mobile phone.
(Press 'VOL+' and 'CALL' buttons at the same time for over 3 seconds while Groove is connecting with one of your mobile phones. You will hear voice announcement of 'paring' to indicate pairing mode.)
- c. Connect the Groove with your second mobile phone. (See 'Connect to your mobile phone' in this page.)
- d. Connect the Groove again with your first mobile phone after the second mobile phone is connected.
- e. Make sure that the Groove is connected with 2 mobile phones at once.

06 / Basic Use: Make and answer calls

- Answer a Call: Press 'CALL' button for incoming calls.(Groove will vibrate for incoming calls.)
- Reject a Call: Press 'CALL' button for over 1 second for incoming calls.
- Hang up a Call: Press 'CALL' button.
- Make a Call: Make a call normally using your mobile phone while Groove is connecting with your phone.
- Redial the Last Call: Press 'CALL' button 2 times.
- Voice Dialing: Press 'CALL' button for over 1 second to activate voice dialing.(This operation may vary depends on the mobile phones)
- Switching Calls between Groove and mobile phone:
Press 'CALL' button for over 1 second during a call to switch mobile phone » Groove or Groove » mobile phone
- Call Waiting: Press 'CALL' button 2 times to answer a second call. To go back to the first call, press 'CALL' button 2 times again.
- Mute/Unmute the Microphone: Press and hold 'VOL+' and 'VOL-' buttons for 2 seconds to mute microphone during a call. Press the same buttons to unmute.

07 / Basic Use: Play music

- Play Music: Press 'Play / Pause' button.
- Pause: Press 'Play / Pause' button while playing music.
- Stop: Press 'Play / Pause' button for 2 seconds.
- Play the Previous or Next Music: Press '<' or '>' button.
- Fast Forward/Rewind: Press and hold '<' or '>' button while playing music.

08 / Auto reconnect

If the Groove and Mobile phone are separated by a range of 10 meters or more, they will be disconnected and RED LED will be flashed. When the Groove is turned back on the range, they will be automatically reconnected. If Groove and mobile phone do not automatically reconnect, press 'CALL' button for over 1second or delete 'XODJ Groove' from the list of founded devices on your mobile phone. Then try again.

09 / Disconnecting

Turn off the Groove or disconnect/unpair from your Bluetooth device.

10 / Troubleshooting Tips

Unable to Turn On	Check the battery status and charge in full.
Unable to Pair with Bluetooth Phone/Device	Confirm that your phone/device is Bluetooth compatible. Follow 'Connect to your mobile phone' instruction in this guide.
Not Loud Enough	Turn up the volume on your phone/device or your Groove. Make sure Groove is fully charged.

11 / Notice

- Do not attempt to open, repair or disassemble.
- Do not place this device near flammables.
- Keep the device dry. Humidity and all types of liquids or moisture can corrode electronic circuits.
- Bluetooth wireless connections may be subject to interference from obstructions, such as walls, or other electronic devices.
- This device works by using Bluetooth wireless technology to connect with your mobile phone and cannot guarantee connection under all conditions like medical emergencies.

12 / Limited warranty information

Warranty Period: 1 Year from the purchasing date		
Description	1 Year	Over 1 Year
The functional defect / faults under normal usage circumstance	Replaceable	Replaceable
Careless / Faults by users	Paid Repair	Paid Repair

13 / FCCID: 2ACABGROOVE

- Fcc statement
This device complies with part 15 of the fcc rules. Operation is subject to the following two conditions:
a. This device may not cause harmful interference, and
b. This device must accept any interference received, including interference that may cause undesired operation.
"changes or modifications not expressly approved by the party responsible

Quick Start Guide, Connect to your mobile phone

Phones have different menus to select from.

01
Turn on the Groove

Flashing WHITE / RED indicates the pairing mode

....

02
Activate the bluetooth function on your mobile phone

....

03
Seach/Select XODJ Groove

If required, enter the passcode '0000'

....

04
Connected

Voice announcement with WHITE LED flashing indicates connect mode

Specification / Bluetooth 3.0 (HFP, HSP, A2DP, AVRCP) / Battery 3.7V / 250mAh (Lithium Ion Polymer) / Standby Time Upto 625 hours / Talk Time Upto 18 hours / Music Play Time Upto 12.5 hours / Charging Time Less than 2.5 hours / Wireless Bluetooth Range 10m / Working Temperature -10 °C ~ 50 °C / Frequency Range 2.402GHz ~ 2.480GHz ISB Band
Website www.byzero-DJ.com / Contact mail@by-zero.com / Manufacture byzero inc. (Made in Korea)

영문 / 앞면