

BL10 Manual goldhorse  FCC ID:2ACATBL10 Bluetooth    HiFi	IMPORTANT Safety Important Safety Instructions • Heed all warnings. • Do not use this apparatus near water. • Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. • Do not install near any heat sources such as radiators, heat registers, stoves, or other devices (including amplifiers) that produce heat. • Only use attachments/ accessories specified by the manufacturer. • Refer all servicing to qualified service personnel. • Servicing is required when the device has been, damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the device, the device has been	exposed to rain or moisture, does not operate normally, or has been dropped. • Devices shall not be exposed to dripping or splashing. • Do not place any sources of danger on the device (e.g. liquid filled objects, lighted candles). Warning Never remove the casing of this apparatus. Never place this apparatus on other electrical equipment. Your Bluetooth Speaker Power supply The speaker can operate on built-in rechargeable battery. 1.To recharge the built-in battery 2.Connect this appavatus"DC 5V" port with PC through supplied USB cable.(turn on the computer)	3.The power indicator (red) turns on,the power indicator (red) tures off when it's fully charged. 4.Whe low battery there will be indicated to charge. Play Play from a Bluetooth device Note: The effective operation range between the speaker and your Bluetooth device is approximately 10 meters (30 feet) Bluetooth Mode: 1.Turn on speaker, the indicator light is flashing (when power on, the blue light is on, when waiting pairing, the blue light is flashing fast, after paired, the blue light is flashing slowly. 2.Turn on bluetooth function of device (i.e. Phone, Computer or Tablet PC...)	3.Search and select bluetooth speaker , i.e. “BL10” to pair. You will hear “Connected” from bluetooth speaker. For some devices, you need to input password “0000” to pair. 4.Playing music and it is outputted from bluetooth speaker 5.Turn off the speaker if you don't use it. When the phone rings 1.Press the bluetoothd speaker”  to answer the calling. 2.Re-press”  "to hang up the calling. 3.If you do not want to answer this calling,long-press”  "three secouds can hang up the calling. 4.Double click”  "can make the final call of your phone. Tip Speaker with the mic closely to get the best effect.
User Manual GOLDHORSE ELECTRONIC (SHEN ZHEN) CO., LTD	Camping light Press " "can open and close the camping light. 1.Press"  "once,the brightness is one-tenth,press twice,the brightness is full, press again to close the light. 2.Long press"  "can control the light.	Q&A: Please don't try to repair the product by yourself. No Power: Please recharge the bluetooth speaker. No Sound: Please adjust the sound volume of your bluetooth device. Please make sure you bluetooth device is in the effective range. Please check the selected audio source is correct. Speaker No sound: Please reboot the bluetooth speaker.	Long-press vol+/Short-press prev Long-press vol-/Short-press next Lighting LED Pause/Play Mic USB charging fort ON/OFF	Specification: Note: product specification can be changed without notify. DC power input USB 5V500MAH Built-in Li-ion battery 3.7V 1800MAH Battery working time >8Hours Bluetooth solution Broadcom V3.0 Advanced features Echo and noise elimination Range 10 meters (No obstacle) This user manual is applied to all bluetooth speaker products of BL10.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.