

LUVIN

GLAXY 8 (G8) MANUAL



Waterproof



Rider & Passenger



Make & Receive Phone Calls

Welcome :

The GLAXY8 (G8) Motorcycle Bluetooth Communication system is a product specially developed for rider and passenger communication needs while riding. The Bluetooth function will keep you connected to your mobile phone, Bluetooth audio device or Bluetooth GPS system. The intercom means you can communicate with your passenger while riding. The GLAXY8 (G8) Motorcycle Bluetooth Communication system is simple to set up and provides clear sound quality, abundant functions convenience for your riding.

Getting to know Your Glaxy 8 (G8)



Instruction Of Functions & Operations

Functions	Buttons		Actions
Power On/Off; Connect to Mobile phone		Long press (3")	Long press(3") the "power on" button to turn On/Off the device → entering mobile pairing mode automatically
Music Sharing		Double click	Double click the "power on" button to share music
Manually Or Automatically Answer A Calling		Double click	Without connecting with any other device,double click the "Volume Up" button to switch between answer the phone manually or automatically
Voice Command		Long press	Long press the "multi-function" button to activate voice command on your mobile phone
Reject Calls		Long press	Long press the "multi-function" button to reject calling
Answer/Hang Up Calling		Short press	Short press the "multi-function" button to answer or hang up calling
Redial Last Calling		Double click	Double click the "multi-function" button to redial last calling
Play/Pause Music		Short press	Short press the "multi-function" button to play or pause Music

Status_1 , how to ajust the music volume under the intercom disconnecting state?

Music Volume up		Long press	Long press the "volume up" button to increase the volume
Music Volume Down		Long press	Long press the "volume down" button to decrease the volume
Next Song		Short press	Short press the "volume up" button to switch to the next song
Previous Song		Short press	Short press the "volume down" button to switch to the previous song

Status_2 , how to adjust intercom and music volume and switch the previous/next song under the mixing audio state or music sharing state?

Music Volume up		Short press	Short press the "volume up" button to increase the music volume
Intercom Volume Up		Long press	Long press the "volume up" button to increase the intercom talking volume
Next Song		Double click	Double click the "volume up" button to switch to the next song
Music Volume Down		Short press	Short press the "volume down" button to decrease the music volume
Intercom Volume Down		Long press	Long press the "volume down" button to decrease the intercom talking volume
Previous Song		Double click	Double click the "volume down" button to switch to the previous song

Intercom Pairing/Intercom Connection/Intercom Disconnection/Intercom Reconnection

Switch Between Paring Receiving Signal & Transmit Signal Mode		Double click	Under the intercom pairing state,double click the "volume down" button to switch between pairing receiving signal or transmit signal mode. (Note: if you want to pair between two devices, need to make one in receiving mode and another one in transmitting mode)
Intercom Pairing & Connecting		Short press	Turn on or turn off intercom pairing, Voice prompt: "intercom receiving mode" or "intercom transmit mode"
Intercom Disconnection & Intercom Reconnection		Short press	In the state that the two devices have completed the intercom pairing,clicks the "Power on/Off" button on one of them to disconnect or reconnect the intercom, and the other device's voice prompt will be "intercom connected" or "intercom disconnected".

Restore factory Settings: under the power on state, (without connecting with mobile phone and other BT intercome device),long press the "volume up" and "volume down" keys at the same time to restore factory Settings, mean while the multi-function indicator light flashing fast for a while.

How To Install?

▪ Steps for Installing Micro-speakers



① Attach the speaker velcro to the cochlea on both sides of the helmet.



② Stick the two speakers on the Velcro respectively. (The short line is pasted on the left side and the longer line is for the right side) line on the Velcro respectively

③ Hard-microphone: Stick the square Velcro at a position, that could ensure the microphone can be 1mm nearby the mouth.
Soft-microphone: Stick the microphone(the square Velcro) to a position 1mm nearby the mouth.



④ Insert the headset plug into the Type-C port on the product to complete the installation.



▪ Steel Clamp Installation Steps



① Stick the hook&loop pad onto the steel clip's corresponding position.



② Stick the Non slip Velcro mat onto the helmet's corresponding position.

③ Attach the back clip onto the helmet (position it so that it is glued to the hairy surface Velcro)



④ Attach the main unit to the steel clip, insert the microphone plug into the Type-C port on the product.



Parts List:



Hard Microphone&Speakers x 1

Note: hard tube mark wind or hose mark wind two choose one according to the front end of the sale to choose matching

FCC Warning

This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Product Parameter:

Model: GLAXY 8
BT Version:5.3
BT Unit Size: 91mm*42mm*24mm
Weight: 62g
Standby Time: 40hours
Intercom Talking Time:15hours
Phone Talking Time:18hours
Frequency: 2.402GHz-2.480GHz
Voltage:3.7v
Travel Adaptor: 5v/1A
Battery Type: Polymer lithium battery
Battery Model:802060
Battery Capacity: 1000mAh

LUVIN

GLAXY 8 (G8)
说明书



防水



前后座对讲



拨打和接听电话

欢迎：

GLAXY8 (G8) 摩托车蓝牙通信系统是一款专为骑摩托车者开发的产品乘客在乘车时需要沟通。蓝牙功能将使您与手机保持连接，蓝牙音频设备或蓝牙GPS系统。对讲机意味着您可以在乘车时与乘客交流。
GLAXY8 (G8)摩托车蓝牙通信系统设置简单，音质清晰，功能丰富方便您的骑行。

了解您的 Glaxy 8 (G8)



功能按键和操作说明

功能	按键		操作说明
开/关机； 连接手机		长按3秒	长按(3")开机/关机键→自动进入移动配对模式(注：如果连接失败，可尝试关闭蓝牙列表再重新开启)
音乐分享		双击	双击开机键打开/关闭音乐分享
手动或自动 接听来电		双击	在不连接任何设备的情况下，双击音量“加”键，切换为手动接听或自动接听。 注意：对讲连接状态下此操作无效。
语音控制		长按	长按多功能键启动语音控制
拒接电话		长按	长按多功能键拒接电话
接听/挂断电话		短按	短按多功能键接听/挂断电话
末码重播		双击	双击多功能键重播上次呼出号码
音乐播放/暂停		短按	短按多功能键 播放或暂停音乐
状态-1，在“对讲未连接”情况下，调节音乐声音大小和切换上/下一曲			
增大音量		长按	长按音量“加”键，增大音量
减小音量		长按	长按音量“减”键，减小音量
下一曲		短按	短按音量“加”键，切换到下一首
上一曲		短按	短按音量“减”键，切换到上一首
状态-2，在“混音状态”或“分享音乐状态”下，调节音乐声音大小和切换音乐上/下一曲和调节对讲音量			
音乐声音增大		短按	短按音量“加”键，增大音量
对讲声音增大		长按	长按音量“加”键，增大音量
下一曲		双击	双击音量“加”键，切换到下一首
音乐声音减小		短按	短按音量“减”键，减小音量
对讲声音减小		长按	长按音量“减”键，减小音量
上一曲		双击	双击音量“减”键，切换到上一首
对讲配对/对讲连接/对讲断开/对讲回连			
切换配对信号 “接收”和 “发射”模式		双击	在对讲机配对状态下，双击音量“减”键，可切换“配对信号”的发射或接收模式。(注意：两个设备之间配对，需要一个处于接收模式，另一个处于发射模式)
对讲配对		短按	单击“开机/关机”键，打开或关闭对讲配对。提示音：“对讲接收模式”或“对讲发射模式”和“对讲关闭”
对讲连接/断开		短按	在两台设备已经完成对讲配对的状态下，其中一方单击“开机/关机”键断开或重连对讲，未操作的一方听到提示音“对讲连接”或“对讲断开”
恢复出厂设置：开机状态下，不连接手机，不连对讲的情况下，同时长按音量“加”“减”键实现恢复出厂设置，多功能指示灯快速闪烁。			

如何安装？

• 耳唛安装步骤



①将喇叭魔术贴贴在头盔两侧的耳蜗位置



②把两个喇叭分别贴在魔术贴上；(线短的那一侧贴左边，线长的贴右边)

③硬管：将方形魔术贴贴在确保麦克风能够“紧贴”嘴巴的位置；软管：将方形魔术贴贴在头盔内侧“紧贴”嘴巴的位置，然后把麦克风风对应贴好。



④将耳机插头插入产品的Type-C接口即可完成安装。



• 钢夹安装步骤



①把防滑魔术贴背面粘在背夹对应位置



②将防滑魔术贴背面贴在头盔对应位置上(毛面位置需要与背夹相对应)

③把背夹安装在头盔上(位置要粘贴在毛面魔术贴上)



④将产品安装在钢夹对应位置；把耳唛Type-C口插入产品对应耳唛接口，即安装完成(要完全插入耳唛接口)



产品清单



注意：硬管麦克风或者软管麦克风二选一根据销售前端选择匹配

产品参数

型号：GLAXY 8
蓝牙版本：5.3
主机尺寸：91*42 *24mm
重量：62g
待机时长：40H
对讲时长：15H
通话时长：18H

频率：2.402GHz-2.480GHz
电压：3.7V
旅行适配器：5V/1A
电池类型：聚合物锂电池
电池型号：802060
容量：1000mAh