



Bluetooth speaker USER MANUAL EBT001 	Table of contents 1. Introduction 2. Packaging Includes / Connection Diagram 3. How to use 4. Pairing 5. Charging 6. Technical Specifications	Introduction Congratulations, and thank you for choosing the Bluetooth Wireless Speaker. This manual will help you operate the Bluetooth Wireless Speaker, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Bluetooth Wireless Speaker. Safety Rules 1) Please follow the rules depicted in this manual closely to ensure your safety. Before using this Bluetooth speaker, we would strongly encourage you to read through this user manual. 2) Be more wary of any edges, uneven surfaces, metal parts, accessories and its packaging so as to prevent any possible injuries or damages. 3) Do not modify, repair or dismantle this Bluetooth speaker. Doing so may result in fires, electric shocks, complete breakdown of this Bluetooth speaker, etc. All of which, are not covered under warranty. 4) Do not use any diluents or volatile liquid to clean the Bluetooth speaker. 5) Do not use the Bluetooth speaker in a hazardous location. 1	Package includes  1 X Bluetooth Wireless Speaker  1 X Micro USB Charging Cable,1 X 3.5mm Aux-in Cable  1 X User Manual 3.Connection Diagram  2	How to use General Functions <table><thead><tr><th>Desired Result</th><th>Required Action</th></tr></thead><tbody><tr><td>Turn on & Enter the pairing mode</td><td>Switch the On/Off button at the back.</td></tr><tr><td>Pairing</td><td>You should use a Bluetooth function mobile phone or other Bluetooth Master Device and to perform pairing action (detail refer to the chapter about pairing)</td></tr><tr><td>Next</td><td>Press  is for next music.</td></tr><tr><td>Previous</td><td>Press  is for previous music.</td></tr><tr><td>Volume up</td><td>Long press the VOL  for volume up .</td></tr><tr><td>Volume down</td><td>Long press the VOL  for volume down .</td></tr><tr><td>Charging</td><td>Plug the charger to micro-USB port at the back of the device. (Red LED is on)</td></tr></tbody></table> 3	Desired Result	Required Action	Turn on & Enter the pairing mode	Switch the On/Off button at the back.	Pairing	You should use a Bluetooth function mobile phone or other Bluetooth Master Device and to perform pairing action (detail refer to the chapter about pairing)	Next	Press  is for next music.	Previous	Press  is for previous music.	Volume up	Long press the VOL  for volume up .	Volume down	Long press the VOL  for volume down .	Charging	Plug the charger to micro-USB port at the back of the device. (Red LED is on)
Desired Result	Required Action																			
Turn on & Enter the pairing mode	Switch the On/Off button at the back.																			
Pairing	You should use a Bluetooth function mobile phone or other Bluetooth Master Device and to perform pairing action (detail refer to the chapter about pairing)																			
Next	Press  is for next music.																			
Previous	Press  is for previous music.																			
Volume up	Long press the VOL  for volume up .																			
Volume down	Long press the VOL  for volume down .																			
Charging	Plug the charger to micro-USB port at the back of the device. (Red LED is on)																			
Pairing to Mobile phone To use your wireless speaker, you must first pair your speaker with a phone. Once your Bluetooth speaker is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range. Pairing to a phone: • Turn on your phone and ensure its Bluetooth function is activated. • Turn the speaker on and it will go into pairing mode. • Search your Bluetooth devices on your phone by following the phone's instructions. • After a few seconds the phone will list "OR1016BT" as a discovered device. Select it and follow your phone's instruction to pair. • Your phone will confirm the pairing, and then press Yes/Ok. • Finally, select to connect with "OR1016BT" from your phone. 4	Charging your speaker The speaker is convenient to connect to a USB charger via its Micro-USB port. Make sure that your speaker is fully charged for at least 6 hours before initial use. Insert one terminal of your charger to the USB port of your PC and the other terminal to the Micro-USB port. While charging, the red LED light is constantly on. When charging is completed, the LED turns off.  Warning: • You must select a qualified charger from a reliable source. You must charge the Bluetooth speaker if it has not been used for more than 12 months. 5	This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment to an outlet on a circuit Different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. 6	Technical specification Bluetooth speaker Model:EBT001 Bluetooth Version:5.0 Charging:DC 5V Material:ABS and fabric Size:117.5*77.5*39.5mm Speaker Driver:45mm plus 4Q/3W Working distance:Max 10 meter Frequency Response:120 Hz-18 KHz Battery:400mah lithium-ion Battery Support USB and Micro SD Card Normal Volume Playing Time:1.5-2.5H With FM function can search radio station broadcast Shenzhen EPT Electronic Technology Co.,Ltd. Room 305-306,QianXi Building B, Changken, Bantian Town, Longgang District, Shenzhen,China. 7	 Bluetooth® wireless technology streamsaudio from all your devices. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc and any use of suchmarks by Orbit Innovations is under license. Other trademarks and trade names are those of their respective owners.  8																