

EUT INTERNAL PHOTOS


EUT UNCOVER VIEW 1




EUT UNCOVER VIEW 2



EUT UNCOVER VIEW 3




EUT UNCOVER VIEW 4




EUT UNCOVER VIEW 5




EUT UNCOVER VIEW 6




EUT UNCOVER VIEW 7




MAIN BOARD TOP VIEW (WITH SHIELDING)




MAIN BOARD TOP VIEW (WITHOUT SHIELDING)




MAIN BOARD REAR VIEW (WITH SHIELDING)




MAIN BOARD REAR VIEW (WITHOUT SHIELDING)




SECONDARY BOARD 1 TOP VIEW




SECONDARY BOARD 1 REAR VIEW



SECONDARY BOARD 2 TOP VIEW



SECONDARY BOARD 2 REAR VIEW



BATTERY TOP VIEW



BATTERY REAR VIEW



ANTENNA

ANT_1:
LTE: Bands
1/2/3/4/5/7/12/13/20/28/66(TX/RX)
NR: n2/4/5/12/13/66(TX/RX)

ANT_7:
NR: n77/78(TX)
LTE: Bands B48/46(RX)
NR: n48/77/78/46 (RX)

ANT_2:
LTE: Bands 2/66(RX)
NR: n2/66(RX)

ANT_8:
LTE: Bands B48(TX/RX)
NR: n48/77/78(TX/RX)

ANT_10: 2.4G/5G/6G

ANT_6:
LTE: Bands B48(TX/RX)
NR: n48/77/78/46 (TX/RX)

ANT_9: 2.4G/5G/6G

ANT_4:
LTE: Bands 2/66(RX)
NR: n2/66(RX)

ANT_5:
LTE: Bands B48(TX/RX)
NR: n48/77/78(TX/RX)

ANT_3:
LTE: Bands 2/66(TX)
NR: n2/66(TX)
LTE: Bands
1/2/3/4/5/7/12/13/20/28/66(RX)
NR: n2/4/5/12/13/66(RX)

--BLANK BELOW--