

alcatel

POP 4S


QUICK START GUIDE

LED
indicator





Power Key

Volume
up/down



① Removing or installing the back cover.

② Charging the battery.



③ Inserting or removing the SIM card.

④ Installing or removing the microSD card.

5095B

5095I

User guide and FAQ are available online
www.alcatelonetouch.com



PLEASE CONSIDER THE
ENVIRONMENT BEFORE PRINTING