

TCL NXTPAPER 70Pro

QUICK START GUIDE

English - CJB2PL0LCAAA
Printed in China

Welcome to TCL

Check out the TCL website at www.tcl.com for tutorials and answers to frequently asked questions, and to download the User Manual.

CUSTOMER SUPPORT

United States & Canada

Phone: 1-855-224-4228

Web: <https://support.tcl.com>

Update your phone's software

Go to **Settings > System > System Update** to check software updates.

Back up your personal data


Go to **Settings > System > Backup > Turn on** to turn it on.

Reset your phone


Go to **Settings > System > Reset options > Erase all data (factory reset) > Erase all data**.

Your TCL phone


Keys and connectors



USB Type-C connector/headset connector



SIM and microSD™ tray




Set up your TCL phone

- ① Insert the provided SIM pin into the hole.
- ② Pull out the SIM tray.
- ③ Place the Nano SIM card and/or microSD™ card into the tray, then carefully slide the SIM tray into the slot.
- ④ Charge the battery for 10~30 minutes before turn on the phone with the included USB-C cable.

Note: Charger not included with your device. Refer to the Safety guide for information on compatible chargers.

Note: microSD™ cards are sold separately. Only use Nano SIM cards with your phone.




Caution: Do not insert the SIM pin into the small holes on top or bottom of the phone.

Home screen


You can bring all of the items that you use most frequently (applications, folders, widgets) to your Home screen for quick access.




To return to the Home screen, swipe up from the bar at the bottom edge of the screen.



Expand your Home screen with widgets and more personalization.



Swipe down from the left side of the status bar to view the Notification panel and access all pending notifications. Tap on the Notification to open the message.




Swipe down from the right side of the status bar to view Quick Access settings options. Tap  to access the complete Settings menu.

Messages

Create, edit, send, and receive text (SMS) and media (MMS) messages.


A SMS will be converted to MMS automatically when media files (such as image, video, or audio) are attached, when a subject is added to the message, or an email address is used for a recipient.



- ① Touch and hold  to record audio.
- ② Attach a picture from the gallery or shoot one directly.
- ③ Touch and hold to switch language (if additional language keyboards are activated).
- ④ Insert a GIF, location, contact or other media file.
- ⑤ Tap to input a comma. Touch and hold to access keyboard settings or enter left or right hand input mode.
- ⑥ Tap to access the symbols and numbers keyboards.

Gmail

Use Gmail to create, send, and receive emails directly on your phone. The Gmail app will allow you to add several email accounts.



- ① Tap to view the email accounts on your device.
- ② Tap to access email folders, settings, and more.
- ③ Tap to create an email.