

TCL K70

NXTPAPER

QUICK START GUIDE



English - CJB2R40LCAAA
Printed in China
T624J



www.tcl.com/ca/en/

Your Mobile

Keys and connectors




Getting started

- ① It is recommended that you charge the battery for about 10-30 minutes with the included USB-C cable before turning on the phone.

Note: Charger not included with your device. Refer to the Safety guide for information on compatible chargers.

- ② Use the provided SIM pin to open the SIM tray.
- ③ Place the Nano SIM card and/or microSD™ card into the tray, then slide the SIM tray into the slot.

Note: microSD™ cards are sold separately. Only use Nano SIM cards with your phone.




Caution: Do not insert the SIM pin into the small hole on top or bottom of the phone.

Home screen

You can bring all of the items that you use most frequently (applications, shortcuts, folders) to your Home screen for quick access.

To return to the Home screen, swipe up from the bar at the bottom edge of the screen.



- ① Swipe down from the left edge of the status bar to view the notification panel and access all pending notifications. Swipe down from the right edge of the status bar to view Quick Access settings options.
- ② Tap  to access the complete Settings menu.

Note: Software updates happen frequently, so your phone may not have all listed apps or features.

Calls


Making a call

From the **Phone** app, use the keypad to enter the phone number and then tap  to place the call, or use keyboard to enter the contact name and then tap  to place the call.

Answering a call


When you receive a call:

- Tap **Answer**, or swipe up the icon  to answer;
- Tap **Decline**, or swipe down the icon  to reject;
- Tap **Message** to reject the call by sending a preset message.



Contacts

Use **Contacts** to view your saved contacts or create a new contact. Synchronize your contacts from your email account(s) and other applications to your phone.




- ① Tap to search for a contact.
- ② Tap  and then tap  Contacts settings to access contacts settings
- ③ Tap on the contact name or icon to open the contact card, where you can edit their information, call them, and more.
Touch and hold to share or delete the selected contact(s).
- ④ Tap to create a new contact.

Messages

You can create, edit, send, and receive SMS and MMS.


A SMS will be converted to MMS automatically when media files (image, video, audio, etc.) are attached, when a subject is added to the message, or an email address is used for a recipient.



- ① Touch and hold to record audio.
- ② Insert a picture from the gallery or shoot one directly.
- ③ Touch and hold to switch language.
- ④ Insert a GIF, sticker, location, contact, or other media file.
- ⑤ Tap to input a comma. Touch and hold to access keyboard or enter left or right hand input mode.
- ⑥ Tap to access the symbols and numbers keyboards.

Gmail

Use Gmail to create, send, and receive emails directly on your phone. The Gmail app will allow you to add several email accounts.



- ① Tap to view the email accounts on your device.
- ② Tap to access email folders, settings, and more.
- ③ Tap to create an email.

General Information

- Visit the TCL website at **www.tcl.com/ca/en/** for tutorials and answers to frequently asked questions, and to download the User Manual.
- To get support for your phone, visit the TCL website (www.tcl.com/ca/en/), or dial the number listed below:

Canada- 1-855-224-4228

United States- 1-855-224-4228

- **Update your phone's software**

Go to **Settings > System > System update** to check software updates.

- **Back up your personal data**

Go to **Settings > System > Backup > Turn on** and turn it on.

- **Reset your phone**

Go to **Settings > System > Reset options > Erase all data (factory reset) > Erase all data**.

- **Removing your Google Account**

Go to **Settings > Accounts > tap on the account > Remove account**.