

Preface


Dear Users :

Welcome to purchase "our" product, please read this user manual carefully before using it. Thanks, Let's enjoy music together!

Warnings

- Please use and store this product at room temperature
- Do not expose this product to rain or wet conditions
- Do not throw and drop this product to avoid product damage
- Do not self-dismantling, repair and transform the product
- Do not use chemical solvent cleaning the product
- Please don't arbitrarily discarded or placed the lithium battery in the fire in order to avoid the risk of explosion

Packing Content :




Features

- With wireless Bluetooth technology
- Support one button Bluetooth reconnection
- With built-in Mic, support handfree function
- Play APE/FLAC format high quality audio files stored in TF card
- Play main MP3/WMA/WAV format audio files stored in TF card



- Automatic shutdown after suspension without operation for 10 minutes
- Built in efficient li-on battery, USB charging is available
- With voice broadcast, support the phone ring

Technique Parameters

Interfaces	Micro USB port
	TF card slot
Product size	W77.5xD85xH46mm
Product weight	200g(Including battery)
Speaker type	Bluetooth Speaker
Speaker structure	Single track+ Low frequency radiator
Functions	Bluetooth wireless connection, Handfree function, Voice prompt, TF card music play,
Supported cards	Max. 32GB TF card
Power supply	Built-in 650 mAh li-on battery
	DC 5V—500mA USB charging
Loudspeaker	1.5inch
Frequency Response	100Hz~20KHz
Wireless connection	Bluetooth 2.1+EDR
USB	USB2.0 Compatible with USB1.1
File formats	APE/FLAC/WAV/WMA/MP3
Bit Rate	MP3: 8Kbps~320Kbps
	WMA: 32Kbps~384Kbps
	APE: 600Kbps~1000Kbps
	FLAC: 600Kbps~1000Kbps
	WAV: 32Kbps~1000Kbps




Key Functions




- 4 Next/Volume+ : Short press to next song . long press to increase the volume . There will be voice prompt when Max. volume and light blue flashing
- 5 Bluetooth disconnected or reconnected : Under Bluetooth connection mode, long press to disconnect , short press again to reconnect the previous device
- 6 Play / Pause : Short press to play or pause music play
- 7 TF card slot : Insert TF card
- 8 Reset button : Press to reset the device
- 9 Micro USB port :

Main Function Operation Instruction : Bluetooth Connection :



Bluetooth Connection :

Open the Bluetooth function of mobile phone , MID and other music players with Bluetooth function , and search the devices , when you find the "it", click to connect




Connected and play

The speaker says " Connected ", and the blue indicator always light up, and then you can enjoy the music with this speaker .

1. If need password , please input "0000" and confirm to connect

2. The Bluetooth can reconnect the last paired device automatically

TF Card music play



Handfree Function

- 1 The speaker connected with a mobile phone , when the call coming , short press M to answer the phone , short press again to hang up the phone , long press to reject the call .



Under line-in mode

Power on the speaker , after "Ding-dong", the speaker says " Pocket Bluetooth speaker is ready for connection " , short press M to switch to line in mode , connect the speaker to the music player to play music stored in other players .




Under line-in mode

Power on the speaker , after "Ding-dong", the speaker says " Pocket Bluetooth speaker is ready for connection " , short press M to switch to line in mode , connect the speaker to the music player to play music stored in other players .

Charging

The user can choose DC5V-500mA USB adaptor to charge the device



Speaker power supply voice prompt :

Battery low : "Battery low , please charge " , it will prompt every 30 seconds

Battery is charging "Pocket Bluetooth speaker is charging "

Battery full : "Charging done"

FAQ

Questions	Settlement
Fail to Bluetooth connect	1.Restart the speaker 2.If need password , please input "0000"
Music Play Break	Please check the Bluetooth connection valid distance or if something cut off the signal
TF card music play wrong	1. Check if the TF card format right (the speaker just can support FAT 32 format TF card) 2.Check if the music file format store in TF card right ,the speaker just can support APE、FLAC、WAV、WMA、MP3 format files
No Sound	1.Check the volume the speaker 2.Check if the speaker is in mute or pause
Line-in no sound	Check if the audio cable connect right
Fail to power on	Check if the batter is low
Speaker halt	Reset the speaker

Warranty Card

Please fill up this "Warranty Card" after purchasing this product .

Date of purchase : _____

Name: _____

Address: _____

Telephone: _____ ip code: _____

Authorized dealer stamp: _____

Dealer Address: _____

Phone: _____ Zip Code : _____

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.