

USER'S MANUAL - ROGUE SPEAKER

04/27/14

FRONT SIDE

BACK SIDE

Rogue Bluetooth Speaker Instructions:

To ensure life of the product and personal safety, please review all instructions prior to use.

1: Charging the Speaker:

Plug the supplied USB connector into your Bluetooth Speaker's Charge Port (fig. 1). The LED indicator will turn red when speaker is charging. Light will turn off when charging is complete.




fig. 1

2: Bluetooth Pairing:

Press and hold the Top Button (fig. 2) for 3 seconds. The LED indicator will flash blue when ready to pair. Follow the prompted instructions on your device to complete pairing. To pause and play music, tap the Top Button. To control volume, use the volume controls on your paired device.




fig. 2

3: Phone Pairing:

To answer calls while in pairing mode, tap the top button once. To return to music, tap top button again.

4: Audio cable connect:

Plug the 3.5mm audio cable into your device's input jack. The micro USB should then be plugged into the Rogue Bluetooth Speaker Audio Port (see fig. 1). To return to Bluetooth pairing, remove cable from speaker.



fig. 3

5: Caution and Safety

- Do not immerse in water or expose to moisture, excessive sunlight or heat
- Store in a cool, dry place
- Do not expose to flame
- Avoid excessive impact
- Discontinue use if the speaker is damaged
- Do not attempt to disassemble, modify or repair

FC Made in China

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.