



iHome Smart Tag

User Manual

Model: 2IHPA1013



Package Contents

- 1、iHome Smart Tag
- 2、User Manual
- 3、Keychain ring

Overview Introduction


iHome Smart Tag integrates with Apple Find My Network, providing a secure and user-friendly solution for finding belongings. It effortlessly locates keys, wallets and more using Apple Find My Network, prioritizing security.

Designed for user convenience, the tracker simplifies daily life. Say good bye to lost items with iHome Smart Tag and Apple Find My Network, experiencing a future of enhanced item finding and peace of mind. Trust iHome Smart Tag to redefine how you manage essentials effortlessly.

How To Pair

Note: iOS or macOS with the latest version

- 1.1 Place the iHome Smart Tag next to your Apple device like iPhone.
- 1.2 Turn on bluetooth on iPhone and connect to Internet.
- 1.3 Press the front button, hear one beep to power on.
- 1.4 Open the 'Find My' app.



(Figure1)

(Figure2)

(Figure3)

- 1.5 In 'Find My' app, Tap '+', then 'Add Other Item'. As shown in Figure 1.
- 1.6 Once your Square tag is located, tap 'connect'. As shown in Figure 2.
- 1.7 Enter a name and choose an emoji for your iHome Smart Tag and tap 'Continue'. As shown in Figure 3
- 1.8 Find My will ask for confirmation to add your iHome Smart Tag to your Apple ID. Tap 'Agree'.
- 1.9 Tap 'Finish' and your iHome Smart Tag will be set up and ready to be used.

Battery

iHome Smart Tag contains a coin shaped battery. During the product's lifespan, it may be necessary to replace the battery. By observing the correct negative and positive connections, only replace batteries of the same type (CR2032) and rating.

Battery Replacement

- 2.1 Open the back cover.
- 2.2 Replace a new battery.
- 2.3 Close the back cover.

Additional Tips

- 3.1 To switch from active mode to disable mode (airplane mode), simply remove the battery.
- 3.2 To switch from disable mode (airplane mode) to working mode, reinstall the battery the iHome Smart Tag will be successfully paired after this.
- 3.3 Press and hold the button until you hear 1 prompt tone, followed by 2 consecutive prompt tones, and then 3 consecutive indicator tones. Continue to press for 5 seconds.

When you hear a long indicator tone, release the button to restore the device to its factory settings.

3.4 To remove the iHome Smart Tag from your Apple devices, open the 'Find My' app, select 'items', find the device, and scroll down to click on 'Remove this device'.

3.5 If the iHome Smart Tag fails to connect to the 'Find My' app, follow the instructions in section 3.3 to perform a factory reset, and then restart the pairing process.

Attention: When firstly use the product, please remove the battery protection clear sheet before using.

Important Matter

The iHome Smart Tag contains delicate electronic parts, including a battery to avoid damage, loss of function, or potential harm, please refrain from dropping, hitting, puncturing, crushing, disassembling, exposing it to extreme heat or liquids, or placing it in areas with a high concentration of industrial chemicals.



WARNING: Do not swallow the battery;

There is a chemical burn hazard.

Choking Hazard Warning

The iHome Smart Tag, its battery compartment door, the battery itself, and the case may pose a choking hazard or cause injury to small children. Please keep these items out of reach of young children.

Medical Device Interference

The iHome Smart Tag contains components and radios that emit electromagnetic fields, as well as magnets. These elements may potentially interfere with pacemakers, defibrillators, or other medical devices. To ensure safety, maintain a safe distance between your medical device and the iHome Smart Tag. We strongly advise consulting your physician and the manufacturer of your medical device for information that is specific to your situation. If you suspect that the iHome Smart Tag is interfering with your pacemaker defibrillator or any

other medical device, discontinue its use immediately.

Important Handling Guidelines

It's normal for the iHome Smart Tag to show discoloration with regular use. To clean it, use a soft, dry, lint-free cloth. Avoid applying pressure with sharp objects on the rubber seal or the battery terminal contacts inside the device.

Do not allow moisture to enter any openings or use aerosol sprays, solvents or abrasive materials to clean the device.

Legal Notice

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product operation of this device or use of this product or its compliance manufacturer to meet Apple Find My Network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOs, Mac, macOS and watchOS are trademarks of Apple Inc. registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.