


SAR Test Setup




Picture 1: Front Side 1 Zone, the distance from EUT to the bottom of the Phantom is 0mm



Picture 2: Front Side 2 Zone, the distance from EUT to the bottom of the Phantom is 0mm



Picture 3: Front Side 3 Zone, the distance from EUT to the bottom of the Phantom is 0mm



Picture 4: Front Side 4 Zone, the distance from EUT to the bottom of the Phantom is 0mm