

User's Guide



SAFETY INFORMATION

Transportation Safety

Please observe all transportation laws and regulations

Hospital Safety

The Tablet PC must be turned off when you are in a hospital.

You have to abide by the relevant regulations of hospital and turn your device

off when you are near medical equipment. Any wireless transmission device will

interfere that equipment not fully-protected.

Airport Safety

Remember to follow all airport and flight safety regulations.

Water Hazard

Your tablet is not waterproof. Keep your tablet away from water or liquid to

avoid damage.

Battery Usage


For better performance and longer battery life, it is recommended that you charge

the battery fully 7 hours before using the tablet for the first time and that

you initially complete two to three charge cycles. Battery life will vary based

on device settings, usage, and others. Certain apps may reduce battery life.

KEY FUNCTIONS



Model 2: WIFI Tablet (Only One TF Card Slot)

INTRODUCTION

When you initially power on your tablet, there will be a series of steps to set

up basic features.

SELECT LANGUAGE


While on the welcome screen, please scroll to select your language.

SELECT Wi-Fi

This process allows the device to connect to the internet.

Click on the Wi-Fi name you need to link and enter the WiFi password, that the

device will be connected to. Please note that any



unsecured Wi-Fi network can be connected to directly and any secured Wi-Fi

network require a password for credentials prior to connect, it's recommended

that you connect to a Wi-Fi network to check for software update prior to startup.

SET DATE &TIME

Adjust the date and time to local time if needed


ADD YOUR ACCOUNT

Sign in to your Google account in order to keep accounts streamlined with Google

services. Your Gmail account will be used for some Google programs. If you don't

have a Google account, click to create a new account. In this step you can also

setup payment info if needed.




SET SCREEN LOCK

Please choose to skip screen lock or be sure to use the password you can remember.

And if you forgot the password or need to clear your password, please see the

RESET OPERATION.



Android technology platform

RESTORE APPS & DATA

You can restore your previous applications and data that have been backed up

from another device. You may also setup the tablet as a new device.

GOOGLE SERVICES

Click to add or remove Google services which include backup, Location Service,

and Google Now.

RESET OPERATION

If you forgot your password or need to clear your password, please follow the

below steps to do it.

1. Please turn off the tablet
2. Press the power button and the volume down button simultaneously
3. Press the volume down button to select Clear eMMC
4. Power on button confirms reset (you will see the follow picture)

Select Boot Mode :

[VOLUME_UP to Select. VOLUME_DOWN is OK]

[Recovery Mode]

[Fastboot Mode]

[Normal Boot]

Recovery Mode means restore the factory settings, press the power button to

confirm, the system will automatically complete this process, automatically

restart. (ALL DATA WILL BE LOST)

Fastboot Mode means development mode, not recommended.

Normal Boot means normal restart, no data loss.

WARNING:

Any changes or modifications without permission which operated by unauthorized

user will result in internal failure, system halted.

This device complies with parts 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may no

cause harmful interference, and (2) this device must accept any interference

that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a

Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are

designed to provide reasonable protection against harmful interference in a

residential installation. This equipment generates, uses and can radiate radio

frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However,

there is no guarantee that interference will not occur in a particular

installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and

on, the user is encouraged to try to correct the interference by one or more

of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to

which the receiver is connected.

—Consult the dealer or an experienced Radio/TV technician for help.

SAR tests are conducted using standard operating positions accepted by the FCC

with the device transmitting at its highest certified power level in all tested

frequency bands, although the SAR is determined at the highest certified power

level, the actual SAR level of the device while operating can be well below the

maximum value, in general, the closer you are to a wireless base station antenna,

the lower the power output.

Before a new tablet is available for sales to the public, it must be tested and

certified to the FCC that it does not exceed the exposure limit established by

the FCC.

For body worn operation, this model tablet has been tested and meets the FCC

RF exposure guidelines when used with an accessory designated for this product

or when used with an accessory that contains no metal and that positions the

handset a minimum of 0cm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure

guidelines.