

1. Introduction

Welcome to your new TowlTunes, the world's first intelligent paper towel holder speaker device!

TowlTunes delivers superior wireless audio without the hassle of cables and docking stations. TowlTunes also gives you the ability to charge your smart device at the same time when listening to music with four included built in USB charging ports. It is perfect for pairing via Bluetooth with any phone, mp3 player, tablet or laptop. TowlTunes can also hold any standard or jumbo size paper towel roll and safely play music at the same time. Now you can clean up, charge up and tune up!

2. Connect to TowlTunes

Bluetooth (wireless audio) / Charge USB devices using device USB charging cable

3. TowlTunes Anatomy

4 USB ports / On/Off & Pairing Switch / Front Volume Buttons / Power Plug / Wine stopper topper

4. Connect Wirelessly

Cell Phones ,Music players,Laptops,Tablets. Your TowlTunes can wirelessly stream audio from any Bluetooth device.

Prepare Your TowlTunes for Pairing

1. Hold the ON/OFF switch (near the power plug) for about 3-5 seconds. (you will hear a 3 beep noise)
2. Wait for the sound to chime (one beep)
3. Prepare your phone or your device (Turn on Bluetooth):
 - On an iPhone, iPod, or iPad: go to SETTINGS> GENERAL> and enable BLUETOOTH
 - On a BlackBerry: go to SETTINGS/OPTIONS> BLUETOOTH and enable BLUETOOTH
 - Other cell phones: go to TOWLHUB.COM/PAIRING or review the instruction manual that came with your phone.

Make the Connection (go to your device's Bluetooth settings.)

1. Add or search for new devices, when the "TowlTunes" appears, select it.
2. If asked for a password> enter "0000"
3. This is a one-time event per device. Your smart device will remember "TowlTunes" automatically after you pair it/turn on.

5. Start-Tuning-In!

Get the best sound: For best listening results, make sure your TowlTunes is resting on its base and facing down on a hard surface. Its designed to amplify the sound from a hard counter top or hard surface area. Avoid placing on a soft surface like a cloth towel as it will distort the audio signal.

When connected wirelessly via Bluetooth. Its best to turn the volume on your phone/device fully up and then use the 2 volume buttons on the base of TowlTunes to increase or decrease the volume. Or turn the volume up fully on TowlTunes and then use the volume to on your smart device to control the sound.

6. Trouble Shooting

- Hearing distortion: Lower the volume on your TowlTunes and/ or phone/device. (see section 5 Start Tuning-In)
- Make sure TowlTunes is placed on a hard surface.
- Not loud enough: Turn up the volume on your phone/device or your TowlTunes, make sure it is connected, again make sure base unit is on top of a hard surface area.
- Unable to pair with BlueTooth Device: Confirm that your phone/device is Bluetooth compatible, follow 4a instructions on pairing, visit www.towlhub.com/tunes/support
- Experiencing signal loss or dropouts via BlueTooth: move TowlTunes closer to your phone/device, turn off your TowlTunes and phone/device then power up and reconnect.

7. Specifications

- AC Power Adapter: Power-20 Watts Maximum, Output-5 VDC at 4 Amps Maximum, Frequency-50/60 Hz, Input AC voltage range 100 to 240 VAC
- Product Dimensions: 14.5 inches tall by 7 inches in diameter, Shipping weight: 6 pounds (shipping box 21 x 12 x 3 inches)
- Storage Temperature Range 60C to -20c, Operational Temperature Range: 60C to -10C

8. Safety Information

Warning: Please read these safety warnings and cautions carefully to ensure your personal safety and prevent property damage.

Fire and Electric shock hazard:

- Do not expose your TowlTunes speakers to liquid, moisture, humidity, or rain
- Do not submerge TowlTunes in water
- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects into the TowlTunes device. Such actions could result in electric shock.
- Do not expose your TowlTunes to extremely high or lower temperatures.

9. Cleaning Instructions

- Clean with mild soap and damp cloth on outside areas only.
- Do not use abrasive cleaners to clean your TowlTunes device because this could cause scratches and damage.

10. Caution

- Do not bring your TowlTunes device into contact with any sharp objects because this could cause scratches and damage.
- Fall Hazard: Do not place TowlTunes on the edge of table or counter or on high surfaces such as shelves. During music playback the TowlTunes speakers may move which could cause the TowlTunes unit to shift and fall.
- Do not insert anything into your TowlTunes unless otherwise specified in the user instructions. This may damage the internal components.
- Do not attempt to replace your TowlTunes speakers, they are permanently assembled.
- Use only the manufacturer supplied charger to power your TowlTunes. Other chargers may look similar, but using them could result in electric shock and could damage your TowlTunes.
- Observe all signs and displays the require an electrical device or RF radio product to be switched off in designated areas.

11. FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

12. FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

13. FCC Caution

1. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
2. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

14. FCC ID: 2ACKEHB5Z

To locate the FCC and IC identification numbers, please look on the underside of the TowlTunes® base. Please only use with the power supply adapter provided, TowlTunes model BITH002.