

70MM

83MM



WIRELESS KARAOKE MICROPHONE

Package Includes:

- 1 Bluetooth Speaker, 1 microphone
- 1 Type-C Charge Cable
- 1 User Manual

Safety instructions

- 1.Never disassemble the Bluetooth Speaker in an attempt to make any repairs as this could result in electrical shock, burns or product failure.
- 2.Adhere extra caution when using the Bluetooth Speaker around children; Use extra caution in high temperatures.
- 3.Products is not waterproof.
- 4.Product is not covered under warranty when the product has metal rust, surface spalling and any other natural oxidation.
- 5.Damage, shock, and/or injury can occur if these warnings are not heeded properly.

Product parameters

Model number: KARLU MIC

*output power: 5W

*Playback: 3 Hours@50% volume

*Battery type: Polymer battery

*Rechargeable: Yes

*Bluetooth version: 5.3

*Range: Aprox. 10M

*Actual playback times may vary. Battery performance may be effected by multiple factors including but not limited to ambient temperature, listening volume, and/or distance from the source audio device.

Pairing

- 1.Switch on the Power button on the speaker to power up the speaker and enter pairing mode.
- 2.On your Bluetooth enabled smartphone, navigate to the Bluetooth setting menu, turn on the Bluetooth feature, and search for new devices.
- 3.Search for "**KARLU**" on the pairing device.
- 4.Tap this model to select it and successfully pair it with the speaker. A voice prompt should confirm that the pairing was successfully. You are now paired, connected and ready to play music.

Charging

- 1.Connect the provided cable to the USB-C® port on the back of the speaker / microphone with a USB charger (not included).
2. Red light on when charging.
- 3.Red light off when finish charging

Controls Index



- 1.Short press for last song, Long press for volume down.
- 2.Switch mode.
- 3,Short press for next song. Long press for volume up.
- 4.Switch light effect.
- 5.Pause / Play / Power on / Power off
- 6.Short press to mute / resume the original sound
- 7.Microphone on / off
- 8.Microphone volume up
- 9.Microphone volume down
- 10.Short press for switch to magic sound.
- 11.Indicator light
- 12.Microphone charging port
- 13.AUX input
- 14.TF card input
15. USB-C charging port
- 16.USB port
- 17.Indicator light

Ways to listen to music

- 1.Connect your device to the speaker via Bluetooth. Open your favorite music app on your device and press PLAY on your Bluetooth device.
- 2.TF slot: Used to read the Mp3 file in FAT32 format from TF memory cards.

*You can control the music with buttons from a connected device or Bluetooth speaker

Important Safety Instructions:

- 1.Read these Instructions.
- 2.Keep these Instructions.
- 3.Heed all Warnings.
- 4.Follow all Instructions.
- 5.Do not use this device near water.
- 6.Clean only with a dry cloth.
- 7.Do not block any ventilation openings Use in accordance with the manufacturer's instructions.
- 8.Do not charge near any heat sources such as radiators, heat registers stoves, or other apparatus (including amplifiers) that produce heat.
- 9.Discontinue use if damaged
- 10.Protect the cord from being walked on or pinched particularly at plugs, convenience receptacles, to the point where they exit from device.
- 11.Only use attachments/accessories specified by the manufacturer.
- 12.Unplug this apparatus during lightning storms and when charging complete.
- 13.Refer all servicing to qualified service personnel, servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

14.Speakers are capable of producing sound levels which can be harmful to your hearing. Do not listen high volume for prolonged periods of time. Headphone may block out surrounding sounds.
*Never use speakers while operating a vehicle. Speakers may block out surrounding sounds.
*Never use speakers while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

WARNING

CAUTION: To prevent electric shock, use only compatible and certified USB charging devices.
WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
CAUTION: Use of controls or adjustments or performance of procedures other than those specified may damage your device.
WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
WARNING: Always store in a cool dry location.
WARNING: Contains small parts that may present a choking hazard. Keep away from children.

Charging your device

Only use a power adapter with applicable country regulations and international and regional safety standards. Other power adapters may not meet applicable safety standards, and using such adapters could pose a risk of death or injury. Avoid prolonged skin contact with the charging cable and connector when the charging cable is connected to a power source because it may cause discomfort or injury. Sleeping or sitting on the charging cable or connector should be avoided.

WARNING: To prevent possible hearing damage, do not listen at high volume levels for long periods. For traffic safety, do not use earphones while driving or cycling.

If you have a pacemaker or other electrical medical devices, you should consult your physician before using the product.

Choking hazard : The product, packaging and some of the included accessories may present a choking hazard to small children. Keep these accessories away from small children. The bags themselves or the many small parts they contain may cause choking if ingested. Keep product and packaging away from children
Danger : Improper battery replacement and disposal may cause an explosion and injury.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sentry Industries Inc is under license. Other trademarks and trade names are those of their respective owners.

USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum



Recycling and Reuse Guidelines for European accordance with the European Union WEEE (Waste Electrical and Electronic Equipment) directive effective August 13, 2005, we would like to notify you that this product may contain regulated materials which, upon disposal, according to the WEEE directive, require special reuse and recycling processing. Please note that the product only falls under the WEEE directive. When disposing of packaging and other shipping material we encourage you to recycle through the normal channels. Sentry Industries Inc declares that radio equipment SPBT6 is in compliance with Directive 2014/53/EU. The EU declaration of conformity is available at <https://sentryindustries.com/european-declaration-of-conformity/>

Conformity with Directives

This product is CE marked to denote conformity with Directives 73/23/EEC (low voltage) and 89/336/EEC (Electromagnetic Compatibility), as amended.

Environmental Protection

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling.

Supplier's Declaration of Conformity 47 CFR 47 CFR Part 15.21, 15.105(b)
Compliance Information
Sentry Bluetooth
Responsible Party –
SENTRY INDUSTRIES INC
ONE BRIDGES TREET, HILLBURN, NY 10931, USA
TEL +18457532910
FCC Compliance Statement

FC "This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

FCC ID: **2ACP4-KARLU MIC** Model **KARLU MIC**

"NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment." The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.

Limited 90-Day Warranty: Sentry warrants this product to be free from defects in materials and workmanship for 90 days from the date of original purchase. This warranty does not pertain to damage resulting from accident, abnormal use, misuse or neglect. Any defective product will be replaced if returned to an authorized Sentry dealer or to Sentry directly at: PO Box 885, One Bridge Street, Hillburn, NY 10931. Please enclose a \$5 check for return shipping.

Solutions to conventional problems

- Unsuccessful connection and pairing
 - 1.Check whether the speaker is in the search state, or reboot.
 - 2.Too many peripheral Bluetooth devices make searching difficult, turn off other Bluetooth devices.
 - 3.Check if there is any Bluetooth device connected to this machine around, it needs to be disconnected. Make sure the speaker and microphone are fully charged
- Low or distorted sound
 - 1.Please charge the battery when the voltage is low.
 - 2.Check the volume of the Bluetooth device and adjust the volume to a suitable sound level.(different songs have different decoding rates and different response sound effects)
- 3.Reopen the Bluetooth speaker and mobile phone digital device Bluetooth connection .
- Music breaks
 - 1.Whether it exceeds the effective connection distance of the speaker, or whether there is an obstacle between the speaker and the Bluetooth device.

Sentry® is a registered trademark of Sentry Industries, Inc. All other trademarks are property of their respective owners.

Battery chemistry: Lithium-ion
Dispose responsibly do not place in household trash
* Do not dispose of this product in household trash. This product must be recycled through an approved program
* Contains a non-removable embedded battery

⚠Warning

- Do not use the charging cable with any power adaptor, plug, or charger that exceeds the product's specified voltage or wattage.
- Only use a **certified** power adaptor or output device rated at **5V/1A or lower**.
- Do not use any other charging cables to charge this device.
- **Do not use fast chargers to charge this device.**

⚠Caution

- Using non-certified, higher-rated, or fast chargers may damage the device, reduce its lifespan, or create safety risks.
- The provided charging cable is designed exclusively for this device. Do not charge the device with other charging cables.
- Do not use the supplied cable to charge other devices.