




For Age 3+

OPERATION MANUAL



STUNT TWISTER CAR

Thank you for choosing our product. In order to safely enjoy this product, please read this manual carefully before using. Please keep the manual for future reference.
This product is recommended for ages 3+ and should always be used with adult supervision.

Controller



1. Antenna
2. Indicator
3. L/R Turn Key-press
4. F/B Run Key-press



5. Rear wheel
6. Front Wheel
7. Charging jack
8. Charging cord

NOTES:

Using a Phillips head screwdriver, remove the car from the plastic base. Remove the battery cover from the controller and place four "AA" batteries (not included) into the controller and replace the battery cover. Make sure to insert the batteries with the correct polarity. Place antenna into the hole at the top of the controller. Turn clockwise to secure antenna to the controller.

DO NOT OVER-TIGHTEN. Pull tip of antenna to extend.

OPERATING INSTRUCTIONS:

To charge the car, open the charger cover and plug the charging cord into the charging jack on the bottom of the car. The charging indicator light will come on when the car is charging. After a full charge (approximately 80 seconds) the light will turn off. Remove the charging cord from the charging jack and replace it under the charger cover.


WARNING: DO NOT ATTEMPT TO RE CHARGE THE CAR AGAIN UNTIL AFTER THE BATTERY HAS RUN LOW. RE-CHARGING A FULLY CHARGED BATTERY CAN CAUSE INJURY.

For best results operate on a smooth dry surface. Radio waves control this toy and can easily be interrupted. Avoid using near phones, electrical lines or CB's. The manufacturer is not responsible for radio or TV interference caused by unauthorized modification of this equipment. Such modifications could void the user's authority to operate the equipment.


TO OPERATE :

1. Fully extend the antenna on the controller.
2. Use the control key-press on the controller to control the car to run or perform various stunts.

1. Forward Run



2. Backward Run



4. Wheelie Stunt with Front Wheels Rotating Clockwise



3. Rollover stunts



5. Wheelie Stunt with Front Wheels Rotating Counterclockwise



SAFETY CAUTIONS

WARNING:

- Not for children under 3 years of age due to small parts.
- Do not try to stop toy while it is in motion.
- Keep hands, face and hair away from all moving parts.
- Exercise caution during use at all times.
- Do not allow children to disassemble the transmitter or controller by themselves.
- Do not operate toy in the vicinity of other people, animals or other obstructions.
- If toy is broken during use, it should be checked or repaired by an adult.
- Remove the batteries from the transmitter and controller when not in use for a longer battery life.
- All battery types must be recycled or disposed of properly.
- Please always read the instruction manual carefully before operating toy.
- Specifications and colors of content may vary from illustrations.
- Keep the transmitter and the car away from any heat sources, such as electric stove, gas stove, or strong sunlight.
- Do not play with it in a dangerous place, such as on a road, or on a slope
- Do not wet the car. Do not play with it outdoors on a rainy day.


BATTERY CAUTIONS:

- The car includes a 2.4V 130Mah Ni-MH battery and is not replaceable.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are only to be charged by an adult.
- Different types of batteries or a mix of new and used batteries are not to be used.
- Batteries to be inserted with correct polarity,
- The supply terminals are not to be short-circuited.
- Exhausted batteries are to be removed and properly discarded as they will hinder performance.
- Always use fresh and/or fully charged batteries.
- Please check the wire, plug, shell and other parts of charger periodically and if any damage, stop using until fully repaired.

Notes:

If the car slows down during actions or becomes unable to roll over smoothly, it may be caused by insufficient power.

Charge the car battery when necessary.



FCC Label Compliance Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, Uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the User's Authority to operate the equipment.

CONFORMS TO THE SAFETY REQUIREMENTS
OF CPSIA AND ASTM F963 STANDARDS.

NOT INCLUDED
AAx4



IMPORTED BY:
GVS AMERICA
21929 - 67th AVENUE SOUTH
KENT, WA, USA 98032

031HG

Made in China

WARNING:
CHOKING HAZARD - small parts,
Not for children under 3 years.