



QUICK START GUIDE

What's in the box



Ethernet Cable



HDMI Cable



Power adaptor




Optional wall mount


Device overview




Device overview




Installation




1. Decide where to position Highfive device. Recommended positioning is as close to eye level as possible




2. If positioning on top of TV, open hinge



3. Set on top of TV




4. Adjust hinge so that it holds the device securely to back of TV




5. Plug the power adaptor into (1) and connect to the Internet with the Ethernet cable plugged into (2). Finally, connect a TV to Roombox using the HDMI cable plugged into (3).

Getting started




1. Device will turn on automatically




2. Using a laptop or mobile device, navigate to setup.highfive.com




3. Follow instructions on the screen



4. When asked to set up device, enter code that appears on TV screen



5. Name your device



6. You are now ready to Highfive!

Additional Information

Highfive Limited Warranty

Highfive Technologies, Inc. (“Highfive”) warrants this Highfive-branded hardware product against manufacturing defects one (1) year from the original date of purchase (“Warranty Period”). In the event that a valid claim is received within the Warranty Period, Highfive will, at its sole discretion, either (1) repair the defect free of charge, (2) replace the product with a new or refurbished product which is at least functionally equivalent to the original product, or (3) refund the purchase price of the product. Damage resulting from use, accident, or normal wear and tear is not covered by this or any warranty.

WARNING

To avoid risk of overheating and burns:

Use indoors only, between 32-95°F (0-35°C)

Keep out of direct sunlight

Do not set anything on top of or cover device

Do not block airflow to device

Device may become hot to the touch, especially during calls

If your TV is warm to the touch, it’s recommended that you place device below TV or use included bracket

To avoid risk of fire and shock:

Use only the provided power adapter

Do not get device or power adapter wet

Do not place on or near flammable items

To avoid damage or injury:

Make sure device is securely mounted

Do not tamper with or open device

If you have any questions about these guidelines, visit <http://success.highfive.com>

Highfive device is not rated for Ingress Protection (IP) so should only be used indoors