

Wireless Display HDMI™ Extender

JVAW53



EN : Quick Installation Guide
ES : Guía De Instalación Rápida
FR : Guide D'installation Rapide
DE : Kurzanleitung Für Installation

NL : Snelle installatiegids
PT : Guia de instalação rápida
日本語 : クイックインストールガイド
繁体中文 : 快速安裝手冊

STOP!

If you have any issues with this product, please try the instructions below before returning the product.

TECHNICAL SUPPORT

Customer Service : **888-988-0488**
Technical Support : **888-689-4088**
Email : **service@j5create.com**
Service Hours : **Mon. - Fri. 10:00 - 18:00 E.S.T**
Live Chat : **www.j5create.com/livechat**
Support Ticket : **tickets.j5create.com**


SOPORTE TÉCNICO
Número gratuito : +1-888-988-0488
Horario de atención :
Lun-Vier. 10:00-18:00 U.S.A-E.S.T
Email : service@j5create.com

SUPPORT TECHNIQUE
Numéro gratuit : +1-888-988-0488
Heures d'ouverture :
lun. - Ven. 10:00 - 18:00 U.S.A-E.S.T
Email : service@j5create.com

TECHNISCHER SUPPORT
Kostenloser Anruf bei : +1-888-988-0488
Sprechstunden :
Mon. – Frei. 10:00-18:00 U.S.A-E.S.T
E-mail : service@j5create.com


English

1. Hardware Features Overview




2. Hardware Installation

- Step 1.** Plug in the power adapter and ensure the power led lights are on.
Step 2. (Optional): IR remote control setting
Connect the IR blaster cable into the IR out port.
Step 3. (Optional) Place the IR sensor on the source device, and mount the IR blaster head beside the device
Step4. Directly connect the HDMI™ cable from the Transmitter HDMI™ in connector to your HDMI™ video source device.




3. Receiver : OSD (on-screen display) status

Startup screen : OSD show connecting.




If connecting devices via HDMI™ port fails:
Please check your HDMI™ cable or signal from your source device.




Network disconnected.

You can reduce the distance between the TX and RX. If you still have trouble, please contact j5create Customer Service.




Español

1. Información general de las características de hardware




2. Instalación del hardware

- Paso 1.** Enchufe el adaptador de alimentación y asegúrese de que las luces LED de alimentación estén encendidas.
Paso 2. (Opcional): Configuración del mando a distancia de IR
Conecte el cable del IR Blaster al puerto de salida de IR.
Paso 3. (Opcional) Coloque el sensor de IR en el dispositivo fuente y monte el cabezal del IR Blaster al lado del dispositivo
Paso 4. Conecte directamente el cable HDMI™ desde el conector de entrada HDMI™ del transmisor al dispositivo fuente de video HDMI™.




3. Receptor: Estado de los menús OSD (visualización en pantalla)

Pantalla de inicio: la pantalla OSD muestra la conexión.




Si hay error en la conexión de dispositivos a través del puerto HDMI™:
Compruebe el cable HDMI™ o la señal procedente del dispositivo fuente.




Red desconectada.

Puede reducir la distancia entre el transmisor y el receptor. Si sigue teniendo problemas, póngase en contacto con el Servicio de atención al cliente de j5create.




Français

1. Aperçu des connecteurs du matériel




2. Installation matérielle

- Étape 1.** Branchez l'adaptateur secteur et assurez-vous que les voyants lumineux sont allumés.
Étape 2. (Optionnel) : Réglage de la télécommande IR
Branchez le câble du blaster IR dans le port de sortie IR.
Étape 3. (Optionnel) Placez le capteur IR sur l'appareil source, et installez la tête du blaster IR à côté de l'appareil.
Étape 4. Connectez directement le câble HDMI™ du connecteur d'entrée HDMI™ de l'émetteur à votre appareil source vidéo HDMI™.




3. Récepteur : Statut de l'OSD (affichage à l'écran)

Écran de démarrage : L'OSD indique la connexion.




Si la connexion des appareils via le port HDMI™ échoue :
Veuillez vérifier votre câble HDMI™ ou le signal provenant de l'appareil source.




Réseau déconnecté.

Vous pouvez diminuer la distance entre le TX et le RX. Si vous avez toujours des problèmes, veuillez contacter le service clientèle de j5create.




Deutsch

1. Hardwarefunktionen im Überblick




2. Hardwareinstallation

- Schritt 1.** Schließen Sie das Netzteil an und stellen Sie sicher, dass die LED-Betriebsanzeigen leuchten.
Schritt 2. (Optional): IR-Fernbedienung einrichten
Verbinden Sie das IR-Verlängerungskabel (grüner Anschluss) mit dem IR-Ausgang.
Schritt 3. (Optional) Platzieren Sie den IR-Sensor am Eingangsgerät und montieren Sie den IR-Blaster-Kopf neben dem Gerät.
Schritt 4. Verbinden Sie das HDMI™-Kabel vom HDMI™-Eingang des Senders direkt mit Ihrem HDMI™-Videoeingangsgerät.




3. Empfänger: Status der Bildschirmanzeige

Startbildschirm: Verbindungsanzeige.




Falls die Verbindung von Geräten per HDMI™-Anschluss fehlschlägt:
Bitte prüfen Sie Ihr HDMI™-Kabel oder Signal von Ihrem Eingangsgerät.




Netzwerk getrennt.

Sie können die Entfernung zwischen TX und RX reduzieren. Falls weiterhin Probleme auftreten, wenden Sie sich bitte an den Kundendienst von j5create.



Nederlands

1. Overzicht van hardwarefuncties



Opmerking:

- *① Als aansluiten van TX en RX is mislukt. U kunt de afstand tussen de TX en RX reduceren. Als u nog steeds problemen ondervindt, neem dan contact op met klantenservice van J5create.
- *⑥ Indicatielampje: Rood: inschakelen / Oranje: opstarten systeem / Groen: systeem gereed / Rood knipperend lampje: Koppelen van TX en RX

2. Hardware-installatie

Stap 1. Sluit de voedingsadapter aan en zorg ervoor dat de LED-voedingslampjes branden.

Stap 2. (Optioneel): Instelling IR-afstandsbediening

Sluit de IR-blasterkabel aan op de IR-uitgang.

Stap 3. (Optioneel) Plaats de IR-sensor op het bronapparaat, en monteer de IR-blasterkop naast het apparaat.

Stap 4. Sluit de HDMI™-kabel direct aan van de HDMI™-ingang van de zender op uw HDMI™-videobronapparaat.

Stap 1. Sluit de voedingsadapter aan en zorg ervoor dat de LED-voedingslampjes branden.

Stap 2. (Optioneel): Instelling IR-afstandsbediening

Sluit de IR-verlengkabel (groene connector) aan op de IR-uitgang.


Stap 3. (Optioneel) Plaats de IR-sensor op het bronapparaat.

Stap 4. Sluit de HDMI™-kabel direct aan van de HDMI™-uitgang van de ontvanger op uw HDMI™-monitor.




3. Ontvanger. OSD-status

Opstartscherm: OSD toont verbinden.




Indien het aansluiten van apparaten via de HDMI™-poort mislukt:

Controleer uw HDMI™-kabel of het signaal van uw bronapparaat.




Verbinding met netwerk verbroken.

U kunt de afstand tussen de TX en RX reduceren. Als u nog steeds problemen ondervindt, neem dan contact op met klantenservice van J5create.



Português

1. Especificações de hardware



Nota:

- *① Se a ligação entre o TX e o RX falhar. Pode reduzir a distância entre o TX e o RX. Se o problema persistir, contacte o serviço de apoio ao cliente da J5create.
- *⑥ Indicador: Vermelho: ligado / Laranja: sistema a arrancar / Verde: sistema pronto / Luz vermelha intermitente: Emparelhamento entre o TX e o RX

2. Instalação do hardware

Passo 1. Ligue o transformador e certifique-se de que as luzes led de energia estão acesas.

Passo 2. (Opcional): Configuração do controlo remoto por infravermelhos

Ligue o cabo transmissor de infravermelhos na porta de saída de infravermelhos.

Passo 3. (Opcional) Coloque o sensor de infravermelhos no dispositivo e instale a cabeça do transmissor de infravermelhos ao lado do dispositivo.

Passo 4. Ligue diretamente o cabo HDMI™ do conector de entrada do transmissor HDMI™ ao seu dispositivo de fonte de vídeo HDMI™.

Passo 1. Ligue o transformador e certifique-se de que as luzes led de energia estão acesas.

Passo 2. (Opcional): Configuração do controlo remoto por infravermelhos

Ligue o cabo de extensão de infravermelhos (conector verde) na porta de saída de infravermelhos.


Passo 3. (Opcional) Coloque o sensor de infravermelhos à frente do dispositivo.

Passo 4. Ligue diretamente o cabo HDMI™ do conector de saída do recetor HDMI™ ao seu monitor HDMI™.




3. Recetor: Estado do OSD (apresentado no ecrã)

Ecrã inicial: O OSD exibe a ligação.




Se a ligação dos dispositivos através da porta HDMI™ falhar:

Verifique o cabo HDMI™ ou o sinal do seu dispositivo.




Rede desligada.

Pode reduzir a distância entre o TX e o RX. Se o problema persistir, contacte o serviço de apoio ao cliente da J5create.



日本語

1. ハードウェア機能の概要



注意:

- *① TXおよびRX接続に失敗した場合、TXとRXの間の距離を近づけてください。問題が解決しない場合は、J5createカスタマーサービスにお問い合わせください。
- *⑥ インジケータ: 赤色: 電源オン / オレンジ色: システム起動中 / 緑色: システム準備完了 / 赤色点滅: TXとRXのペアリング中

2. ハードウェアの設置


ステップ1: 電源アダプターを接続し、電源LEDライトが点灯していることを確認します。

ステップ2: (オプション): IRリモコンの設定

IR出力ポートにIR延長ケーブル(緑色のコネクタ)を接続します。


ステップ3: (オプション) デバイスの前面にIRセンサーを配置して取り付けます。

ステップ4: HDMI™モニターに送信機HDMI™出力コネクタのHDMI™ケーブルを接続します。




3. 受信機: OSD (オンスクリーンディスプレイ) のステータス

起動画面: OSDに接続中であることが表示されます。




HDMI™ポート経由でのデバイス接続に失敗した場合:

TXとRXの間の距離を近づけてください。問題が解決しない場合は、J5createカスタマーサービスにお問い合わせください。




ネットワークに接続されていません。

TXとRXの間の距離を近づけてください。問題が解決しない場合は、J5createカスタマーサービスにお問い合わせください。



繁体中文

1. 硬體功能概述



注意:

- *① 如果TX和RX連接失敗，您可以縮減TX和RX之間的距離。如果仍有問題，請聯繫J5create客戶服務。
- *⑥ 指示燈: 紅燈: 開機 / 橙燈: 系統正在啟動 / 綠燈: 系統就緒 / 紅色閃爍燈: TX和RX配對中

2. 硬體安裝

步驟1. 插入電源變壓器，並確保電源指示燈點亮。

步驟2. (選用): 紅外線遙控器設置: 將紅外發射器電纜連接到紅外訊號輸出孔。


步驟3. (選用) 將紅外線訊號發射器放置在HDMI™輸入設備旁。

步驟4. 將HDMI™線直接插入HDMI™影像來源設備的接口。




3. 接收器: OSD (螢幕顯示) 狀態

開機畫面: OSD顯示正在連接。





如果HDMI™連接設備失敗:

請檢查您的HDMI™電纜或來源設備的信號。



連線配對失敗:

您可以縮減TX和RX之間的距離。如果仍然有問題，請聯繫J5create客戶服務。



■ The User Manual

Contains detailed instructions and a troubleshooting section, many common issues can be easily resolved by reading the user manual.

■ Online Support

Please visit the J5create website (www.j5create.com) to find the latest software for your device. If you are still experiencing issues, you can submit a trouble ticket through our J5 support. Your ticket will be responded to within 24 hours.

■ Telephone Support

Please call our +1-888-689-8288 and one of our support technicians will be very happy to assist you. We stand behind our products and it is our goal to provide you with world class support.

■ Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

You are cautioned that any changes or modifications to this product not explicitly approved by the manufacturer in writing could void the user's authority to operate the equipment and any assurances of Safety or Performance, and could result in violation of Part 15 of the FCC Rules.

■ FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

■ FCC-Erklärung zur Strahlenbelastung

Dieses Gerät entspricht den FCC-Grenzwerten für Strahlung unkontrollierter Umgebung.

Dieses Gerät sollte so installiert und betrieben werden, dass es eine Mindestentfernung von 20 cm zwischen dem Kühler und Ihrem Körper.

■ Limited Warranty

J5create offers a limited 1-year warranty. User's wear & tear damage is not included. The user shall call or email J5create customer service with the defect information of the product and obtain a return authorization number. Users are responsible for one-way return freight cost and we will take care of one-way freight back. In order to obtain a return authorization number, users should have the following information handy when calling or emailing the service team:

- (i) a copy of the original purchase invoice to verify your warranty
- (ii) a product serial number
- (iii) a description of the problem
- (iv) customer's name, address, and telephone number

J5create does not warrant that the operation of the product will be uninterrupted or error-free. J5create is not responsible for damage arising from failure to follow instructions relating to the product's use. This warranty does not apply to: (a) consumable parts, unless damage has occurred due to a defect in materials or workmanship; (b) cosmetic damage, including but not limited to scratches, dents, and broken plastic on ports; (c) damage caused by use with non-J5create products; (d) damage caused by natural disasters; (e) damage caused by human misuse (lost, accident, abuse, misuse or other external causes); (f) damage caused by operating the product outside the permitted or intended uses described by J5create; (g) damage caused by service (including upgrades and expansions) performed by anyone who is not a representative of J5create or a J5create Authorized Service Provider; (h) a product or part that has been modified to alter functionality or capability without the written permission of J5create; or (i) if any J5create serial number on the product has been removed or defaced. If such a situation occurs, J5create will calculate the cost of materials and repair for your reference. This warranty is given by J5create in lieu of any other warranties expressed or implied.

J5create offers a limited 1-year warranty. User's wear & tear damage is not included. The user shall call or email J5create customer service with the defect information of the product and obtain a return authorization number. Users are responsible for one-way return freight cost and we will take care of one-way freight back. In order to obtain a return authorization number, users should have the following information handy when calling or emailing the service team:

- (i) a copy of the original purchase invoice to verify your warranty
- (ii) a product serial number
- (iii) a description of the problem
- (iv) customer's name, address, and telephone number

J5create does not warrant that the operation of the product will be uninterrupted or error-free. J5create is not responsible for damage arising from failure to follow instructions relating to the product's use. This warranty does not apply to: (a) consumable parts, unless damage has occurred due to a defect in materials or workmanship; (b) cosmetic damage, including but not limited to scratches, dents, and broken plastic on ports; (c) damage caused by use with non-J5create products; (d) damage caused by natural disasters; (e) damage caused by human misuse (lost, accident, abuse, misuse or other external causes); (f) damage caused by operating the product outside the permitted or intended uses described by J5create; (g) damage caused by service (including upgrades and expansions) performed by anyone who is not a representative of J5create or a J5create Authorized Service Provider; (h) a product or part that has been modified to alter functionality or capability without the written permission of J5create; or (i) if any J5create serial number on the product has been removed or defaced. If such a situation occurs, J5create will calculate the cost of materials and repair for your reference. This warranty is given by J5create in lieu of any other warranties expressed or implied.

J5create offers a limited 1-year warranty. User's wear & tear damage is not included. The user shall call or email J5create customer service with the defect information of the product and obtain a return authorization number. Users are responsible for one-way return freight cost and we will take care of one-way freight back. In order to obtain a return authorization number, users should have the following information handy when calling or emailing the service team:

- (i) a copy of the original purchase invoice to verify your warranty
- (ii) a product serial number
- (iii) a description of the problem
- (iv) customer's name, address, and telephone number

J5create does not warrant that the operation of the product will be uninterrupted or error-free. J5create is not responsible for damage arising from failure to follow instructions relating to the product's use. This warranty does not apply to: (a) consumable parts, unless damage has occurred due to a defect in materials or workmanship; (b) cosmetic damage, including but not limited to scratches, dents, and broken plastic on ports; (c) damage caused by use with non-J5create products; (d) damage caused by natural disasters; (e) damage caused by human misuse (lost, accident, abuse, misuse or other external causes); (f) damage caused by operating the product outside the permitted or intended uses described by J5create; (g) damage caused by service (including upgrades and expansions) performed by anyone who is not a representative of J5create or a J5create Authorized Service Provider; (h) a product or part that has been modified to alter functionality or capability without the written permission of J5create; or (i) if any J5create serial number on the product has been removed or defaced. If such a situation occurs, J5create will calculate the cost of materials and repair for your reference. This warranty is given by J5create in lieu of any other warranties expressed or implied.

J5create offers a limited 1-year warranty. User's wear & tear damage is not included. The user shall call or email J5create customer service with the defect information of the product and obtain a return authorization number. Users are responsible for one-way return freight cost and we will take care of one-way freight back. In order to obtain a return authorization number, users should have the following information handy when calling or emailing the service team:

- (i) a copy of the original purchase invoice to verify your warranty
- (ii) a product serial number
- (iii) a description of the problem
- (iv) customer's name, address, and telephone number

J5create does not warrant that the operation of the product will be uninterrupted or error-free. J5create is not responsible for damage arising from failure to follow instructions relating to the product's use. This warranty does not apply to: (a) consumable parts, unless damage has occurred due to a defect in materials or workmanship; (b) cosmetic damage, including but not limited to scratches, dents, and broken plastic on ports; (c) damage caused by use with non-J5create products; (d) damage caused by natural disasters; (e) damage caused by human misuse (lost, accident, abuse, misuse or other external causes); (f) damage caused by operating the product outside the permitted or intended uses described by J5create; (g) damage caused by service (including upgrades and expansions) performed by anyone who is not a representative of J5create or a J5create Authorized Service Provider; (h) a product or part that has been modified to alter functionality or capability without the written permission of J5create; or (i) if any J5create serial number on the product has been removed or defaced. If such a situation occurs, J5create will calculate the cost of materials and repair for your reference. This warranty is given by J5create in lieu of any other warranties expressed or implied.

J5create offers a limited 1-year warranty. User's wear & tear damage is not included. The user shall call or email J5create customer service with the defect information of the product and obtain a return authorization number. Users are responsible for one-way return freight cost and we will take care of one-way freight back. In order to obtain a return authorization number, users should have the following information handy when calling or emailing the service team:

- (i) a copy of the original purchase invoice to verify your warranty
- (ii) a product serial number
- (iii) a description of the problem
- (iv) customer's name, address, and telephone number

J5create does not warrant that the operation of the product will be uninterrupted or error-free. J5create is not responsible for damage arising from failure to follow instructions relating to the product's use. This warranty does not apply to: (a) consumable parts, unless damage has occurred due to a defect in materials or workmanship; (b) cosmetic damage, including but not limited to scratches, dents, and broken plastic on ports; (c) damage caused by use with non-J5create products; (d) damage caused by natural disasters; (e) damage caused by human misuse (lost, accident, abuse, misuse or other external causes); (f) damage caused by operating the product outside the permitted or intended uses described by J5create; (g) damage caused by service (including upgrades and expansions) performed by anyone who is not a representative of J5create or a J5create Authorized Service Provider; (h) a product or part that has been modified to alter functionality or capability without the written permission of J5create; or (i) if any J5create serial number on the product has been removed or defaced. If such a situation occurs, J5create will calculate the cost of materials and repair for your reference. This warranty is given by J5create in lieu of any other warranties expressed or implied.

J5create offers a limited 1-year warranty. User's wear & tear damage is not included. The user shall call or email J5create customer service with the defect information of the product and obtain a return authorization number. Users are responsible for one-way return freight cost and we will take care of one-way freight back. In order to obtain a return authorization number, users should have the following information handy when calling or emailing the service team:

- (i) a copy of the original purchase invoice to verify your warranty
- (ii) a product serial number
- (iii) a description of the problem
- (iv) customer's name, address, and telephone number

J5create does not warrant that the operation of the product will be uninterrupted or error-free. J5create is not responsible for damage arising from failure to follow instructions relating to the product's use. This warranty does not apply to: (a) consumable parts, unless damage has occurred due to a defect in materials or workmanship; (b) cosmetic damage, including but not limited to scratches, dents, and broken plastic on ports; (c) damage caused by use with non-J5create products; (d) damage caused by natural disasters; (e) damage caused by human misuse (lost, accident, abuse, misuse or other external causes); (f) damage caused by operating the product outside the permitted or intended uses described by J5create; (g) damage caused by service (including upgrades and expansions) performed by anyone who is not a representative of J5create or a J5create Authorized Service Provider; (h) a product or part that has been modified to alter functionality or capability without the written permission of J5create; or (i) if any J5create serial number on the product has been removed or defaced. If such a situation occurs, J5create will calculate the cost of materials and repair for your reference. This warranty is given by J5create in lieu of any other warranties expressed or implied.

J5create offers a limited 1-year warranty. User's wear & tear damage is not included. The user shall call or email J5create customer service with the defect information of the product and obtain a return authorization number. Users are responsible for one-way return freight cost and we will take care of one-way freight back. In order to obtain a return authorization number, users should have the following information handy when calling or emailing the service team:

- (i) a copy of the original purchase invoice to verify your warranty
- (ii) a product serial number
- (iii) a description of the problem
- (iv) customer's name, address, and telephone number

J5create does not warrant that the operation of the product will be uninterrupted or error-free. J5create is not responsible for damage arising from failure to follow instructions relating to the product's use. This warranty does not apply to: (a) consumable parts, unless damage has occurred due to a defect in materials or workmanship; (b) cosmetic damage, including but not limited to scratches, dents, and broken plastic on ports; (c) damage caused by use with non-J5create products; (d) damage caused by natural disasters; (e) damage caused by human misuse (lost, accident, abuse, misuse or other external causes); (f) damage caused by operating the product outside the permitted or intended uses described by J5create; (g) damage caused by service (including upgrades and expansions) performed by anyone who is not a representative of J5create or a J5create Authorized Service Provider; (h) a product or part that has been modified to alter

建檔日期：2020-04-30

修改日期：2020-05-20

製作版本：V1- 版

料 號：5EDVAW53100101

客戶名稱：j5create

產品名稱：JVAW53

需求內容：QIG

尺 寸：756X297mm

材 質：70p模造紙，
黑白雙面印刷

成型尺寸：84x148.5mm

W摺後對摺