

Quick Manual

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Important notice

Support

- Air 10s Commander
- Air 1 Commander (partially*)

Usage

- **On-Camera**
 - set up with bracket
 - diffuser installed for zooming
- **Off-Camera**
 - screw onto ball head
 - remove diffuser for maximum flash output efficiency

Battery

26650 Lithium ion battery x 2 / AA battery x 8

HSS / FP

- **Nikon / Fujifilm**
controlled by camera menu setting
- **Olympus / Panasonic / Sony**
hold HSS button on commander
- **Canon**
controlled by camera menu setting or commander

Energy saving

2 min sleep mode 60 min turn off

*details please refer to User Instruction Manual:
<http://www.nissindigital.com/download.html>



Pairing

- 1 OFF Turn off **MG10**
 Switch to **Auto Channel**
- 2 +] **HOLD 3 Sec MG10**
↓
 blink + beep
- 3 +] **HOLD 3 Sec Air10s**
↓
 + beep stop
- 4 Paired
↓
 Setting Memorized

Control Panel

OPEN Mode

PRESS MG10 **M/TTL** **HOLD 1 Sec Air10s**

Basic Group **ABCD** Advance Group **ABCD**

Modeling Light

press **modeling** button
Air10s

Adjust power & TTL

select group & rotate **dial**
Air10s

Adjust Zoom Position

M.zoom **HOLD M.zoom** button & rotate **dial**
Air10s

Flash exposure

- **Basic groups**
All groups work in the same mode
- **M/TTL**
press to change between **M / TTL** mode
Air10s
- **Advanced groups**
M / TTL mode can be mixed
- **HOLD 3 Sec** change to Advanced Group
Air10s

Shutter release remote control

Connect **MG10** with camera by the synchronization cable

switch to **Red Dot**

"half-way" press to auto focus
"full-way" press to take picture