X68-i

Octa-Core Industrial Hardware Solution

Multi-Language Setup Guide

Specifications

Processor	Octa-Core ARM Cortex A53 processor
GPU	PowerVR GE8110
Memory	2GB DDR3
Internal Storage	16GB eMMC 5.0 Storage (MLC)
OS	Android Lollipop 5.1.1
Video Output	HDMI™ 2.0, up to 4K 60Hz, supports HDMI-CEC
Audio Output	Via HDMI™ 2.0, S/PDIF, 3.5mm stereo jack
Peripheral Interface	RJ-45 Gigabit Ethernet Micro SD card reader USB 2.0 port x 3, OTG port x1, Kensington Lock ready Microphone jack, Headphone jack, IR receiver
Power	DC 5V, 3A adapter included (CE, FCC certified)

Contents



Overview

Overview

Overview

Power LED - The LED glows blue when the X68-i is on.

Power button - To power on the X68-i, press and hold the power button for 2-3 seconds until the power LED glows. To power off the X68-i, press and hold the power button and the display will prompt out the power off options, select OK to confirm your choice. Alternatively, hold the power button for 8 seconds to force power off.

SD/MMC card slot - Increase the storage size or read files directly from a SD/MMC card, supports up to 64GB max.

Recovery button - The recovery button is to be used together with the OTG port when connecting to a PC for services/manual upgrade purposes.

Earphone Jack - Connect to an external audio output device such as earphones etc...

Overview

Microphone Jack - Connect to a microphone for voice input.

Ethernet Jack - Connect the Ethernet cable for internet access. If you need advanced settings such as PPPoE dial-up, go into the settings page at "Settings" > "More..."... While connected with the Ethernet cable, the X68-i can be used as a router and also a Wi-Fi hotspot. If you need to use the Wi-Fi hotspot feature, please make sure that the Wi-Fi feature is OFF before you enable the Wi-Fi hotspot service at "Settings" > "More".

DC 5V Power-in Jack - Connect the 5V power adapter supplied in the package to this port. The X68-i requires less than 1A to operate, however the included power adapter provides 3A, in consideration that you may require extra to connect other power-drawing external devices such as an external hard drive.

USB 2.0 Ports - Connect an external USB device to the X68-i, such as USB flash drive, receiver of wireless keyboard and mouse, USB wired mouse, receiver of wireless headset, air mouse etc...

Overview

HDMI port - Connect the X68-i to the HDMI port of a high-definition TV or PC monitor using an HDMI cable.

Optical Audio Port - Connect to the optical audio input of an external sound processing unit, such as an amplifier.

OTG Port - Connect the micro end of the Micro-USB cable to this port and the other end to the computer for synchronization and manual upgrade purposes.

Control

Different Control Methods - You may control the X68-i with the following input devices:

1.) Wired mouse
2.) 2.4GHz USB wireless mouse and keyboard set
3.) 2.4GHz USB wireless air-mouse (air-mouses sold separately)
4.) IR-Remote

Basic Setup

What you need:

High-Definition TV or PC monitor - that can display 720p, 1080p or 4K video with at least one HDMI input.

HDMI Cable - To connect the X68-i to your TV (HDMI cable included).

Wireless Network - Assisted network cable or Wi-Fi wireless network, your wireless network name and password.

Software and accounts - To play content(videos, photos, music) from a smartphone or PC on the X68-i you will need:

- A UPnP/DLNA software pre-loaded on your smartphone or PC.
- A Google account to signin to Google Play Store to download the corresponding applications (e.g. MediaShare, eHomeMediacenter) neccessary for streaming the content from a smartphone or PC.
- Other accounts may be required for full accocess to some internet contents.

Basic Setup

The X68-i connects to your TV or PC monitor through an HDMI port that delivers both audio and video. Before you set up the X68-i, look at the ports on the side/back of your TV or PC monitor to ensure you have the right cable:
- An HDMI cable. You can connect the X68-i to an HDTV or home theater receiver that has an HDMI port, using an HDMI cable for video and audio.

Step 1: Connecting the cable
1. Connect one end of the HDMI cable to the HDMI port of your TV / PC monitor.
2. Connect the other end of the cable to the HDMI port of the X68-i.

Step 2: Connecting the power
- Connect the tin power adapter supplied in the package to the relevant port. Press and hold the power button for 2-3 seconds to power on the X68-i, the blue power LED should then glow.

Step 3: Turn on your TV / PC monitor and select the input
- Simply turn on your TV or PC monitor and select the corresponding HDMI port connected to the X68-i.

Basic Setup

Language Setup
You may choose the desired system language by following these steps:
Launcher Home Screen > Settings > Language & Input > Language
The default language is English, you may choose your desired language and confirm.

Time Zone Setup
You should adjust the time zone according to your current location by the following steps:
Launcher Home Screen > Settings > Date & Time > Select Time Zone
Choose your time zone and confirm.

Wi-Fi Setup (basic)
To connect to your wireless network follow these steps:
Launcher Home Screen > Settings > Wi-Fi > Check the option
"To see available networks turn Wi-Fi on"
Wi-Fi will turn on and automatically scan the wireless networks available, then select the wireless network that you wish to connect to and confirm. key in the password at the Wi-Fi network when the virtual keyboard prompts. finally hit the "Connect" button.

Google Play Store

Sign in to your Google Account.
Launch the Google Play Store by the following steps:
Launcher Home Screen > Google Play Store, select and confirm.

To use the Google Play Store you will need a Google Account. If you already have a Google Account, select "Sign In" and login with your Google Account. If you don't have a Google Account yet, select "Get a Google Account" and complete the rest of the process.

Upon completion of the sign in process you will be brought to the Google Play Store, allowing you to download and install the applications you want.

Copyright © 2016 MINIX Tech. All rights reserved.

No part of this guide, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of MINIX. This clause does not apply to such software which is licensed under the General Public License ("GPL") or other Free Open Source Licenses. Copies of the respective license terms, and where required an offer to provide the respective source code, are included in the product.

Google, Android, Gmail, Google Maps, Chrome, Google Play, YouTube, Google+, and other trademarks are property of Google Inc.. A list of Google trademarks is available at http://www.google.com/permissions/guidelines.html. MINIX and the MINIX logo are trademarks of MINIX Tech. All other marks and trademarks are properties of their respective owners.

The content of this guide may differ in some details from the product or its software. All information in this documentation is subject to change without notice.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.