
MINI SPEAKER FOR SMARTPHONE

SENSE AND SIMPLICITY




Manual


M4

■ Proclamation: All product drawing & function instruction is used for reference only, the finally correct details please see in instruction and packing kinds, we reserved the finally explanatory rights.



■ Thanks for buying our speaker. This manual will help you to take proper use of this device .Please read it carefully before use .



AUX (3.5MM) input port,
which support iphone, ipad,
MP3, MP4...



TF card On/Off/Bluetooth



1.FUNCTION

- Support TF and MMC card, high quality MP3/WMA.
- Sound card function, can be used for controlling the track and play/pause
- Duplicate supply, Removable Li-battery and USB power
- FM Radio, Auto search
- Support mobile phone, PC, MP3/MP4 or any music player with standard 3.5mm jack
- Linking speakers multiplies mono to get stereo sound by audio cable and make a new powerful 2.0 high bass sub-woofer speakers
- Support bluetooth function (optional)

2.ACCESSORIES

- Speaker: 1pc
- User Manual: 1pc
- Certificate: 1pc
- Mini-USB line: 1pc
- 3.5mm stereo audio line: 1pc

3.SPEC.

- 2.0 Channel
- Speaker system: Full-range audio system, magnetic shielding
- Speaker unit: 2
- Output: 5W
- Frequency: 90HZ-20KHZ
- SNR: 85 dB
- Impedance: 3 ohms
- 3.5mm input/output audio cable
- Built-in Li-battery: 900mAh
- Bluetooth module: V2.1+EDR
- Speaker size: 60*61cm
- N.W: 258g

4.HOW TO USE

Bluetooth mode

- Turn on: Slide the switch to "  " position
- Put the speaker on platform
- Turn on your player
- Matching: Bluetooth Name: POWEREAL
Password: 0000
- Turn off : Slide the switch to "off" position

MP3 Mode

- Long press "-/+" to adjust volume
- Short press "-/+" to choose the song

FM Mode

- Long press "  " to start FM function and switch between MP3, FM and Line in mode
- Short press "  " to search FM station
- Short press "-/+" to switch the FM Radio frequency

Line in Mode

- Turn on the speaker, connect the AUX port and PC via audio cable

Sound Card Function

- Line-in: Connect the USB cable to PC or laptop, slide the Power ON/Off to the ON position, the speaker will play the sound from your PC or laptop automatically. The volume can be adjusted via.

Download from computer:

- Connect the speaker to PC laptop, slide the Power On/Off Switch to the "ON" position, and insert the TF card into the TF card slot, now the speaker will act as a removable USB disk, you can download, copy and delete the documents between the computer and TF card.

Technology in series connection

- Linking speakers multiplies mono to get stereo sound by audio cable and make a new powerful 2.0 high bass sub-woofer speakers
- Buddy-Jack(built-in cable): it allows several speakers to be linked together in series, to increase the sound times two or more times over.

Charging

- Charge the speaker by connecting the supplied USB cable, as battery power may not be sufficient immediately after purchasing

Remarks:

- * For the first time using, please make sure more than 8 hours charging
- * With over charge protection, it will be off automatically when charging is complete.

5.NOTES

- Do not use the device in humid ,dusty ,smoky areas or other bad environments
- Do not contact with water and other liquids
- Do not clean it by water or chemical reagent, please use soft cloth
- Make sure the power supply is not exceeding 5V when charging
- Do not drop or squeeze the device
- Put the device away from the magnetic field
- Do not disassemble the device

6.CUSTOMER SERVICE CENTER

- After-sales: 86-15013500186
- Email: jessica@rockwell-electronics.com
- Website: www.szrockwell.en.alibaba.com

FCC STATEMENT:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Digital mini speaker Warranty card

Name:_____			
Purchase date:_____			
Invoice No.:_____			
TEL:_____			
Add.:_____			
Product name:		Model No.:	
Repair date:		Factory No:	
Repair record:		Authorized service :	(stamp)

WARRANTY DESCRIPTION

1. Warranty Period: 12 months from the purchasing day on the invoice.
2. Documents required:
 - Warranty Card (original with company chop)
 - Commercial invoice (original with company chop)
3. The below situations are excluding from the warranty guarantee:
 - No Warranty card(with company chop)
 - No Commercial invoice(with company chop)
 - Any damage against the force majeure during the transportation.
 - Any damage caused by the wrong operation by end-user.
 - Accessories in the package is lacked or broken.
 - Warranty period is expired