

Manual



Model: Find Tag Pro

Bedienungsanleitung

- 1. Einschalten:** Lange drücken Sie den Knopf für 5 Sekunden; Eine Bestätigungsglocke klingt und das Licht blinkt dreimal.
- 2. Gerätestatus überprüfen:** Drücken Sie den Gerätekopf zweimal schnell hintereinander. Wenn das Gerät piept, ist es eingeschaltet. Wenn kein Ton ertönt, ist es ausgeschaltet.
- 3. Timeout konfigurieren:** Wenn das Gerät eingeschaltet ist, aber innerhalb von 10 Minuten keine Verbindung hergestellt wird, verlässt es den Pairing-Modus. Drücken Sie einmal auf den Knopf (ein Bestätigungston ertönt), dann können Sie es über die *Find Hub*-App koppeln.
- 4. Seriennummer abfragen:** Drücken Sie schnell die Gerätetaste 6 mal in Folge, das Gerät piept
- 5. Werksreset:** Drücken Sie den Knopf schnell 4 Mal (ein Ton bestätigt die Aktion). Halten Sie den Knopf dann gedrückt (ein weiterer Ton ertönt), ohne loszulassen, bis eine zweite Melodie abgespielt wird.
- 6. Ausschalten:** Drücken Sie schnell die Gerätetaste 5 mal in Folge, das Gerät piept, es ist ausgeschaltet.
- 7.** Nach dem Entbinden des Geräts mit Ihrem Telefon, führen Sie bitte eine Werkseinstellung durch, bevor Sie das Gerät an ein neues Telefon binden.

Charge your device

Type-c output end cable charging, charging power upto 0.45W.

The product supports charging with a 5v/1A charger. Please use a compliant charger, as fast charging may cause damage to the product.

Open the protective sleeve of the smart tag charging port and insert the Type-c charging cable as shown in the figure.

The red light turns on during charging, the light will turn off when the tag is fully charged. Full charge takes approximately 3 hours.

*4-month battery life. Usage time may vary depending on conditions.

Important Note:

1. Does the Tag work with Apple devices?

No, Tag does not work with Apple devices.
Google Find Hub network only works on android devices.

2. Does Tag have GPS?

It doesn't have GPS. It reports its location through Find Hub network.

3. Will the bluetooth connection Tag affect the connection and use of other bluetooth devices?


It doesn't take up your mobile phone's bluetooth, you can bluetooth connect your other bluetooth devices such as headphones, speakers, etc. as usual.

Operation Instructions

- 1. Power on :** Long press the button for 5 seconds; A confirmation chime will sound and the light will blink three times.
- 2. Device status confirmation:** Double click the device button, the device beeps, it is on. If it does not beep, it is off.
- 3. Pairing timeout:** When the device is on, if it is not paired within 10 minutes, the device will exit pairing mode, please click the device button once, the device beeps, then you can pair it with the Find My or Find Hub app.
- 4. How to query serial number:** Quickly press the device button 6 times in a row,, the device beeps.
- 5. Factory reset:** Press the device button 4 times quickly, the device will sound. Long press the device button, and the device will beep, do not release it, continue pressing until the second piece of music is played.
- 6. Power off:** Quickly press the device button 5 times in a row, the device beeps, it is off.
- 7.** After unbinding the device with your phone, please perform a factory reset before binding the device to a new phone.

Instrucciones de Operación

- 1. Encender:** Pulse el botón durante 5 segundos; Sonará una campana de confirmación y la luz parpadeará tres veces.
- 2. Confirmación del estado del dispositivo:** Presione dos veces el botón del dispositivo rápidamente. Si el dispositivo emite un pitido, está encendido. Si no emite pitido, está apagado.
- 3. Timeout de emparejamiento:** cuando se enciende el dispositivo, si no se completa el emparejamiento en 10 minutos, el dispositivo saldrá del modo de emparejamiento. Haga clic una vez en el botón del dispositivo. Cuando el dispositivo emita un pitido, podrá emparejarlo a través de la aplicación Find Hub.
- 4. Consulta del número de serie:** Presione rápidamente el botón del dispositivo 6 veces seguidas, el dispositivo emite un beep.
- 5. Restablecimiento de fábrica:** Presione rápidamente el botón del dispositivo 4 veces; el dispositivo emitirá un sonido. Luego, mantenga presionado el botón hasta que suene un pitido, pero no lo suelte. Continúe presionando hasta que se reproduzca la segunda melodía.
- 6. Apagar:** Presione rápidamente el botón del dispositivo 5 veces seguidas, el dispositivo emite un beep, está apagado.
- 7.** Dopo aver sbloccato il dispositivo con il telefono, eseguire un reset di fabbrica prima di collegare il dispositivo a un nuovo telefono.



Note:

· If the device is powered on but Google Find Hub cannot detect it, restore the device to factory settings. If it still cannot be found, restart your phone to locate the device.

· If you dismiss the Fast Pair pop up twice or frequently pair and unpair a tag, you might trigger the banning logic, which prevents unnecessary Fast Pair pop ups. To resolve this, you can either wait for five minutes for the Fast Pair pop up to be re-enabled or reboot your phone.


· Some of these steps are applicable only on Android 12.0 above.

Any problem or suggestion, please
contact : nutservice@nutspace.com.

Mode d'emploi

- 1. Mise sous tension:** Appuyez longtemps sur le bouton pendant 5 secondes; Une cloche de confirmation sonnera et la lumière clignotera trois fois.
- 2. Vérification de l'état de l'appareil :** Double-cliquez deux fois sur le bouton de l'appareil. Si l'appareil émet un bip, il est allumé. S'il ne bip pas, il est éteint.
- 3. Timeout d'accouplement:** Lorsque l'appareil est allumé, s'il n'est pas appairé dans les 10 minutes, il quittera le mode d'appairage. Appuyez une fois sur le bouton de l'appareil (un bip confirme l'action), puis vous pourrez l'appairer via les applications Find Hub.
- 4. Consultation du numéro de série :** Appuyez rapidement sur le bouton de l'appareil 6 fois de suite, l'appareil sonne.
- 5. Réinitialisation aux paramètres d'usine :** Appuyez rapidement 4 fois sur le bouton (un bip confirme l'action). Maintenez ensuite le bouton enfoncé (un bip retentit), sans relâcher jusqu'à ce qu'une seconde mélodie se déclenche.
- 6. Extinction :** Appuyez rapidement sur le bouton de l'appareil 5 fois de suite, l'appareil sonne, il est éteint.
- 7.** Après avoir découplé l'appareil avec votre téléphone, veuillez effectuer une réinitialisation d'usine avant de lier l'appareil à un nouveau téléphone.

Product Overview



Specifications

Dimension	45.8*40.4*8.1mm
Weight	10.9g
Range	10-20 metres indoors, 20-50 metres outdoors
Standby Time	Up to 4 months
Charging Time	Approx. 3 hours
Waterproof Rating	IP64
Compatibility	Android™ 12.0 and above
Battery	90mAh


This product has been certified by Google to meet Find Hub network accessory specifications. Google is not responsible for the operation of this product. Google is also not responsible for ensuring that the product complies with any applicable safety standards or other requirements. Find Hub network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android 9+ on select devices [devices or phones] and in certain countries for age-eligible users. Google, Android, and Find Hub are trademarks of Google LLC.

⚠ WARNING

· **INGESTION HAZARD:** This product contains a button cell or coin battery.
· **DEATH** or serious injury can occur if ingested.
· A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
· **KEEP** new and used batteries **OUT OF REACH OF CHILDREN**.
· **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



Introduction




Mode D'emploi




使用说明




Anweisungen



Instrucciones de Uso



Istruzioni per l'uso



FCC Caution. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the

equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. **The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.**

FCC ID:2ADD5-F22X

Regulatory Safety Information



WARNING: KEEP BATTERIES OUT OF REACH OF CHILDREN

Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the esophagus. If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poison Information Centre for fast expert advice. Immediately dispose of used batteries and keep away from children.

Do NOT dispose of batteries in household trash. Even used batteries may cause severe injury or death. Call a local poison control center for treatment information.

Safety Statement

KEEP BATTERIES OUT OF REACH OF CHILDREN Keep in original package until ready to use. Call a local poison control center for treatment information. Australia: 13 11 26 Canada: 1-800-268-9017(Ontario), 1-800-567-8911(BC), 1-800-463-5060 (Quebec) US: 800-498-8666. Ver ify suitable. emergency call numbers for your country. Do not use if the compartment is not secure. Dispose of used button batteries promptly and safely. Flat batteries can still be dangerous.

European Union-Disposal Information The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate. b) Even used batteries may cause severe injury or death. c) Call a local poison control center for treatment information. d) Type-C charging e) The product supports charging with a 5V/1A charger. f) Non-rechargeable batteries are not to be recharged. g) Do not force discharge, recharge, disassemble, heat above 60 °C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns. h) Ensure the batteries are installed correctly according to polarity (+ and -). i) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations. j) Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children. k) Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries. Risk of fire and burns. Do not recharge, disassemble, heat (-20°C +70°C) or incinerate.

Article 12 Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery. Article 14 The application of low power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists. The foregoing legal communication refers to the wireless telecommunication operated according to the telecommunications laws and regulations. The low power frequency electric machinery should be able to tolerate the interference of the electric wave radiation electric machineries and equipment for legal communications or industrial and scientific applications.

Nutale®

此页不打印

80g双胶纸，彩色印刷

展开尺寸255*200mm

折叠后尺寸85*50mm

实线为切线，虚线为折痕不打印

风琴折

“Manual ” 为折叠后封面