



80.00 mm

55.00 mm

AMS

CT500 DAB



connection step:
First:Insert simultaneously the A&B connector
Second:Insert simultaneously the C&D connector

When connecting the speakers. The speakerwires +/- must be connected with the speaker +/- directly. Any speaker wire can't connect with the iron or ground. Otherwise the unit may be damaged.

NO.	NOTE	NO.	NOTE
A1	CAN HIGH	B1	RR+
A2	CAN SHIELD	B2	RR-
A3	CAN LOW	B3	FR+
A4	IGNITION/ACC	B4	FR-
A5	ANTENNA REMOTE	B5	FL +
A6	ILLUMINATION	B6	FL -
A7	BATTERY+	B7	RL +
A8	POWER GROUND	B8	RL -
C1	LINE_OUT_L	D1	MIC +
C2	SWRC_GND	D2	RAUX_R
C3	LINE_OUT_GND	D3	MUTE PHONE(H)
C4	AMPLIFIER REMOTE	D4	RAUX_L
C5	LINE_OUT_R	D5	MIC-
C6	SWRC +	D6	RAUX_GND

FCC ID:2ADE7-CT500DAB

12V ⎓ 10A max
⊖ GROUND

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference,and
(2) This device must accept any interference received, including interference that may cause undesired operation.

SERIAL NO.:

P/N: 127072009XXXX

CE E4 10R-05 4XXX

AMS diffusion
ZA Du Chevalement, Rue des Galeries,
59286 Roost-Warendin - France