

If you have questions or comments, contact us.

888-480-9885

INSTRUCTION MANUAL

DEWALT®

DXMA1410016

PMN: MAGNETIC WIRELESS CHARGER WITH KICKSTAND

HVIN: DXMA1410016

Instruction Manual

⚠ WARNING: TO REDUCE THE RISK OF INJURY, USER MUST READ ALL INSTRUCTIONS BEFORE OPERATING THIS PRODUCT

SAVE THESE INSTRUCTIONS

Thank you for purchasing the **Magnetic Wireless Charger**


With this product, you can:

- Enjoy fast and convenient wireless charging
- Ensure secure wireless charging with a strong magnet connection
- Easily mount the wireless charger for hands-free charging

Package Contents

- 1 Magnetic Wireless Charger
- 2 Metal Slide-and-Lock Mounting Bracket
- 3 6ft DEWALT Type C with USB Adapter Charging Cable
- 4 3M mounting adhesive
- 5 Cable Wrap
- 6 User Manual
- 7 M4 Screws (4mm)
- 8 Drywall Anchors

2



DEFINITIONS: SAFETY GUIDELINES

The definitions below describe the level of severity for each signal word. Please read the manual and pay attention to these symbols.

⚠ DANGER: Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

⚠ WARNING: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

⚠ NOTICE: Indicates a practice not related to personal injury which, if not avoided, may result in property damage.

IF YOU HAVE ANY QUESTIONS OR COMMENTS ABOUT THIS PRODUCT, CALL US TOLL FREE AT 888-480-9885.

WARNING: Read and understand all instructions. Failure to follow all instructions listed below may result in electric shock, fire and/or serious personal injury.

MAGNETIC WIRELESS CHARGER SAFETY WARNINGS

FCC Warning: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to

part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.

ISED Caution:Radio Standards Specification RSS-Gen,

issue 5

- English:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:

The equipment complies with ISED Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 10cm between the radiator and your body.

- French:

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

Cet appareil ne doit pas causer d'interférences.

Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement

4


indésirable de l'appareil.

Déclaration d'exposition RF:

L'équipement est conforme à la limite d'exposition aux radiations de la ISED établie pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 10cm entre le radiateur et votre corps.

CHARGING PROCEDURE

1. Insert the Type C end of the charging cable into the power source. If you have a power source with a USB port, you will need to place the USB adapter on the Type C connector before plugging into the USB charging port.



NOTE: For best results, 20W or higher output charger is recommended.

2. Insert the Type C end of the charging cable into the port of the Magnetic Wireless Charger.

3. Align Magnetic Wireless Charger with the charging coil on the back of your iPhone 12 series or newer.

NOTE: Only compatible with MagSafe cases. When using a non-MagSafe case, remove case before charging.




MOUNTING PROCEDURE

1. To insert the charger into the wall-mount bracket, turn the Magnetic Wireless Charger so that the DEWALT logo is facing the bracket.

2. Slide the Magnetic Wireless Charger down into the bracket from the top until it reaches the bottom edges.

NOTE: Charging can still take place from the mounted position.



OPTIONAL WALL MOUNT:


Using 3M Adhesive:

1. Peel off paper from one side of adhesive sticker and adhere firmly to the back of the wall-mount bracket.

2. Peel off paper from the second side of adhesive sticker and adhere firmly to desired mounting location.

Using 4mm/M4 Screws:

1. Screw the wall-mount bracket into the wall using two 4mm/M4 screws and drywall anchors.



IMPORTANT CHARGING NOTES

1. Longest life and best performance can be obtained if a device is charged when the air temperature is between 65°F and 75°F (18° – 24°C). DO NOT charge a device in an air temperature below +40°F (+4.5°C), or above +105°F (+40.5°C). ***This is important and will prevent serious damage to the device.***
2. The Magnetic Wireless Charger and device may become warm to the touch while charging. This is a normal condition and does not indicate a problem. To facilitate the cooling of the Magnetic Wireless Charger after use, avoid placing the Magnetic Wireless Charger in a warm environment such as in a metal shed or an uninsulated trailer.
3. If the Magnetic Wireless Charger does not charge properly:
 - a. Check operation of the receptacle by plugging in a lamp or other appliance.
 - b. Check to see if the receptacle is connected to a light switch which turns the power off when you turn out the lights.
 - c. Move the charging pad to a location where the surrounding air temperature is approximately 65°F – 75°F (18° – 24°C).

4. Foreign materials of a conductive nature such as, but not limited to, grinding dust, metal chips, steel wool, aluminum foil, or any buildup of metallic particles should be kept away from the Magnetic Wireless Charger.
5. Unplug the Magnetic Wireless Charger before attempting to clean it.
6. Do not freeze or immerse the Magnetic Wireless Charger in water or any other liquid.

STORAGE RECOMMENDATIONS

1. The best storage place is one that is cool and dry, away from direct sunlight and excess heat or cold.
2. For long storage, it is recommended to store the Magnetic Wireless Charger in a cool dry place for optimal results.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications made to this device not expressly approved by E-filliate Incorporated may void the FCC authorization to operate this device. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

LIMITED LIFETIME WARRANTY

In case of product failure, E-filliate, Inc. will issue a replacement. **DO NOT RETURN PRODUCT TO STORE.** Instead, please call **888-490-9885, 8:00 a.m.-5:00p.m. PT, Monday – Friday**, or e-mail us using **dewaltinfo@efilliate.com**.

CUSTOMER SERVICE

We're here to help. If you are not satisfied with this product or have questions on how to use it, please contact us. **YOU DO NOT NEED TO CONTACT THE RETAILER.** Please contact one of our service representatives, using the contact info listed above, before shipping merchandise to us. Please provide the product number when contacting us.

E-filliate, Inc.
11321 White Rock Road
Rancho Cordova, CA 95742 USA