

User's Manual

Version Number: 1.0.0

2015-07-03

Model: LIFE

Contents

1	PREFACE	4
2	INSTALLED APPLICATIONS	4
3	KEY EXPLAIN.....	4
4	IDLE DESKTOP	5
5	CALLING FUNCTION	5
5.1	PHONE	5
5.2	ANSWER CALL	6
5.3	OPTION IN THE CALL	6
6	CALL LOG	6
7	EMAIL.....	8
8	CALCULATOR.....	9
9	NOTE.....	9
10	CONTACTS	9
11	BROWSER.....	10
12	SOUND RECORDER	11
13	STOPWATCH	11
14	ALARMS.....	12
15	CANLENDAR.....	12
16	SETTINGS	12
16.1	WIRELESS & NETWORKS.....	12
16.2	DEVICE	14
16.3	PERSONAL	16
16.4	ACCOUNTS	17
16.5	SYSTEM	18
17	WORLD CLOCK.....	18
18	VIDEO	19
19	FM RADIO.....	19
20	SEARCH.....	19
21	APPLICATION MANAGER	19
22	GOOGLE SETTINGS.....	20
23	PLAY STORE.....	20
24	GALLERY	20

25	FILE EXPLORER.....	21
26	DOWNLOADS.....	21
27	FLASHLIGHT.....	21
28	CAMERA	21
29	MESSAGING.....	21
30	MUSIC.....	24
31	SIM TOOLKIT	24

1 PREFACE

Hello! Dear customer, congratulations on you own a PDA multimedia phone that support handwritten input and touch screen operation. Welcome you to read this user manual for understanding of your mobile phone function characteristics and operating methods.

This phone is Android platform products, with super compatible function expansion and reliability, you can install your favorite program, bring more cool dazzle of the experience.

Many functions need access to the Internet and the resulting certain data flow cost. In the environment of WLAN, suggest priority connection WLAN, so as to save your cost data flow.

You can also through the network settings disable data access functions, avoid unnecessary flow cost, and also extended the mobile phone standby time.

If you have unclear place to this product writing explained, please consultation to the company or the business agent or the seller. The company does not bear the responsibility If the product description bring any inconvenient or the loss undertakes.

Since the company has introduced updated edition, user manual carries the content will have the modification, makes the changes are subject to change without notice.



Tip *In view of the mobile phone network configuration and provide the services, some function may not be allowed to use, please inquires to distributors or network operating company.*

2 INSTALLED APPLICATIONS

This phone support expanding application, can be installed file format for the application of the APK. For first installation, you need to enter in the "set-security" and checked the "unknown sources".

- ✧ Online download in mobile phone: enter into play store, find the application and click download, After the completion of the download, system will be prompted to install.

3 KEY EXPLAIN

Key	Funciton
Power (Lock)	Press the key to lock screen in any interface. Long press to power

	on or off.
Home	Press the key to enter into idle screen in any interface. Long press to view the running task.
Menu	In the menu operation interface, according to the key can open operation menu.
Back	Press to return to the upper layer.

4 IDLE DESKTOP

- ✧ Drag left or right can switch over the page, different pages can put different widgets or shortcut function.
- ✧ Add widget: in idle interface, long press on idle desktop, then select the widgets menu, long press a widget can create shortcut on the desktop, and then through the shortcut icon on the desktop, you can quickly enter the corresponding application.
- ✧ Add shortcut: In the main menu, long press a function icon, it will add to the icon on the desktop.
- ✧ Change wallpaper: Long press on idle desktop, or press menu key and then select "wallpapers", support system built-in wallpapers, live wallpapers and gallery of the photos, and other wallpaper.

5 CALLING FUNCTION

Know how to use the phone functions, such as call and answer the call, while in communication using available options.

5.1 Phone

In the idle screen, press the phone icon to dial-up interface, input number, press 'dial-up icon' to call. To make a video call, press 'video call' icon. video call feature requires network operators to support.

When the call after connect, the screen can see call the timer. If the dial the number has been stored in the phone book, so called name will be displayed on the screen. If the call not established, the possible reasons are:

- ✧ "line busy" said was called busy or network not have free line.
- ✧ "Be refused" said do not been allowed to call, or you start the dial out limit, please check your network Settings.
- ✧ Each other phone is power off or outside the service area, so the can't make a phone call, the network system will inform you.
- ✧ Each other in communication, please press hang up, and dial again later.

5.2 Answer call

- ✧ When people call in, mobile phones can hint you according to your set.
- ✧ To answer the call, slide to the green icon to answer.
- ✧ To reject the call, slide to click the red icon to hang up.

5.3 Option in the call

Click the icon corresponding communication can realize add calls, hang up, dial keyboard, bluetooth, mute, hands-free, keep/recovery etc.

Call records will list all missed calls, dialed calls and connected calls.

During the call, you can press the 'HOME key' go back to the idle screen for other operations.

Click state bar to slide down, choose the current calling, you can return to call interface.

6 CALL LOG

Call log will list all missed calls, outgoing calls and received calls.

- ✧ Add the number of call record to phonebook.

Long press on one of record, and choose "add to contacts" in the pop-up menu, then click "create new contact".

✧ Clear all call records

Press 'MENU' key and choose 'clear call logs', enter the multi-selection list, check the record, then click menu 'clear all the call log' or 'clear selected all log' to remove the call records.

✧ View

Select the view all the call records, SIM1 call records or SIM2 call records.

✧ Call contact

Click the phone icon at the right of record, or enter into detail interface, and then choose 'call ****'.

✧ Send message

Long press on one of record, and choose "send text message" in the pop-up menu, or enter into detail interface, then choose 'send message' icon.

✧ Call settings

You can use voicemail, call forwarding and call waiting. If you would like to understand the service of detailed information, please consult your network service providers.

✧ Vibration

It is turn on, the phone will vibrate when answers or hangs up.

✧ Voicemail service

Use service provider voice mail service.

Voicemail settings

Input number to start voicemail service, you can obtain this number from the service provider.

✧ Fixed Dialing Numbers

➤ Enable FDN: Start or cancel the fixed dial mode; you can only call fixed dial list number if start it.

➤ Change PIN2: Change to PIN2 code that used to protect PIN code.

➤ FDN list: To set fixed dial contact list.

✧ Call forwarding

The call transferred to another number.

✧ Call Barring

By limiting the outgoing, incoming telephone to control the purpose of using. The opening and closing functions are required to enter the barring password from your service provider, select it, you can enquire, enable and disable the relative functions.

 **Caution:** *Call barring needs the network support and your application.*

✧ Additional settings

- Caller ID: To set whether display your number in outgoing calls.
- Call waiting: To set whether notify you of incoming calls during a call.

7 EMAIL

You can use email to send and receive messages.

✧ Add Email accounts

You must set up your email address, then you can send and receive E-mail. E-mail need through the network connection to send and receive messages.

- Input email address and password information, click next or manual Setup.

Note: if you select manual Setup, specific parameter settings need to consult your mail service provider.

- According to the screen prompt operation, finish the setting.

✧ Delete Email accounts

- In the account list, long press one of accounts, then choose delete in pop-up menu.
- Confirm to delete account.

✧ Send Email

- In inbox interface, press 'MENU' key, choose write in the pop-up menu.
- In the receiver fields, input the recipient's email address.

- In theme fields, input the mail subject.
- In writing email fields, input mail contents.
- Click "send" to send mail.
- ✧ View Email
 - Press 'MENU' key, choose refresh in the pop-up menu, the new E-mail message will be updated to the inbox.
 - Click the Email that you want to view.

8 CALCULATOR

Use the calculator to do basic arithmetic. Calculator can do four basic operation (add, subtract, multiply and divide). Click the 0-9 to input value, click the "." button to input point.

Slide to the left to use scientific calculator.

9 NOTE

- ✧ Simple note function, click the icon at the top right corner to add new note.
- ✧ If you finish editing, please press back key and it will be saved.
- ✧ Click one of notes, you can view and modify.
- ✧ Long press a records can be deleted, move into a folder and share.

10 CONTACTS

View contacts that saved in phone or SIM

- ✧ Search

You can search record by contact name. After inputting correct name, it will show the contact.

- ✧ New contact

Click the "new contact" icon, you can choose to add the contact to phone or SIM. After choosing storage location, input name and number can be added, the phone contact also can increase the email, address, remarks, nickname, web, instant message etc...

✧ Contacts to display

Set display all or part of the contacts.

✧ Import/Export

You can import contacts from the SD card or export the contact list to SD card.

✧ Account

If you do not add account, account management is empty, If you have to add the account, you will see the account information, of course, you can add multiple accounts in the settings, to achieve multiple account synchronization. After adding the account, click on this account can synchronize your mobile phone contacts.

✧ Batch delete

Delete part of contact records that selected or delete all records.

✧ Call contact

Click contact to enter into detail interface, then click the number.

✧ Send message to contact

Click contact to enter into detail interface, then click the message icon.

✧ Setting

Sort list by

Set the sort list by fist name or last name.

View contact names as

Set the view contact name as fist name first or last name first.

11 BROWSER

You can use the browser to visit a web page and network application.

Note: access to the network will produce the extra cost, detailed tariff please consult your network service providers.

✧ Open browser

Enter into main menu, choose browser, the home page will be displayed, you can input address to access other website. Click address bar to input or edit address.

✧ Browse webpage

- Input website address, and click link icon, it will open the website.
- On the webpage, you can slide finger to access and view the rest of the page.
- When browsing the web, you can also use two fingers to scale: two fingers on the screen, slow fold or separate.

✧ Bookmarks

You can set the commonly used website to bookmarks, the method as follows: (1) press menu key and select “save to bookmarks”. you can modify address and name. (2) In the bookmark list and select “add”, the current webpage will be added to the bookmark.

The next time, if you want to visit the webpage that have added to bookmark, you can directly into bookmarks list, and click the corresponding bookmark, it will automatically link to this page.

12 SOUND RECORDER

Enter into main menu, and select sound recorder. The function as follows:

- ✧ Display recording duration.
- ✧ Display recording volume.
- ✧ Start recording your voice.
- ✧ Play or stop the recording.
- ✧ Stop the recording or stop to play recording.

NOTE: After stopping the recording, click the ‘save’ can save this recording to file management corresponding folder, press ‘Discard’ will clear recorded sound file.

13 STOPWATCH

Select the stopwatch.

Select ‘start’ start the stopwatch.

Choose ‘lap’ record time.

After completion, select 'pause'.

Select 'reset' can remove the record time.

14 ALARMS

✧ Set new alarm:

- Enter into main menu, and select "alarm".
- Select "add alarm" to edit alarm.
- Set the alarm detail information.
- When you finish, please select "done".

✧ Stop alarm: When alarm clock is ring.

- Select dismiss to close alarm clock.
- If you select snooze, the alarm clock will ring in a certain time.

15 CANLENDAR

View the calendar.

You can create a calendar and notepad.

16 SETTINGS

16.1 Wireless & networks

Change the wireless and network connection.

✧ WIFI

- WLAN: Turn on or off WLAN device.
- Network notification: Notify you when an open network is available.
- Add WLAN network: Add WLAN access points.

✧ Bluetooth

- Bluetooth: Turn on or off Bluetooth device.

- Discoverable: Set your phone to make it can be found by other Bluetooth devices.
- Scan for devices: Search available Bluetooth device.
- Rename phone: To set your bluetooth device name.
- Visibility timeout: Can be set to search for the time.
- Show received files: Show received files through the bluetooth device.
- Show sent files: Show sent files through the bluetooth device.

✧ Data usage

Can be opened or closed mobile data, open GPRS then the mobile phone can use the Internet function. You can set the mobile data traffic restrictions, can also view usage flow in a certain period of time and each application usage.

✧ More...

➤ Airplane mode

Touch “Airplane Mode” to switch between “On” and “Off”. If Airplane mode is On, all the wireless networks will be disconnected automatically in this mode.

➤ Tethering & portable hotspot

Portable WLAN hotspot: Start portable WLAN hotspot, share mobile network connection to computer or other equipment through the WLAN function.

Portable WLAN hotspot settings: To set and manage portable WLAN hotspot.

➤ VPN settings

In VPN settings, you can add a new VPN, set VPN server, enable Encryption, DNS search domains, etc.

After adding a new VPN, touch it in the VPNs list, and you can connect it to network.

➤ Mobile networks

Data enabled: The set can be allowed to use network service.

Data roaming: To set connected to other network when mobile in in roaming or out of local network.

Access Point Names: To change the access point name.

Network operators: Search available network.

16.2 Device

- ✧ Audio profiles: Lets you choose how your phone behaves in different environments by setting.

Vibrate: vibration feedback for calls and notifications.

Volume: Adjust the volume of ringtone, media, alarm and notification. Drag the slider to the left to reduce the volume, or drag the right to increase the volume.

Phone ringtone: Choose incoming ringtone.

Default notification: Choose new message ringtone.

Dial pad touch tones: Set dial pad touch tones.

Touch sounds: Set touch tone tone.

Screen lock sounds: Play sounds when locking and unlocking the screen.

Vibrate on touch: Vibrate when pressing soft keys and on certain UI interactions.

- ✧ Display

Brightness: Adjust LCD brightness. Drag the slider to the left to reduce the brightness, or drag the right to increase the brightness.

Wallpaperset: Support system built-in wallpapers, live wallpapers and gallery of the photos and other wallpaper.

Auto-rotate screen: To set whether automatically rotating interface when rotating the phone.

Sensor horizontal alignment: after entering the menu, then place the screen upward, and then press the MENU key to select Horizontal alignment.

Sleep: Adjust the delay before the screen automatically turns off.

Daydream: Daydream can be set to clock, colors, photo frame, photo table. To control what happens when the phone is sleeping, turn daydream on.

Font size: Can be set to display fonts for the small, ordinary, large or super-large.

Cast screen: The video phone, image files and other resources is projected to watch on television and other display devices.

Font : You can set the system font, you can set the built-in fonts or add fonts.

✧ Storage

SD Card

- ✧ Total Space: View the capacity of SD card when SD card is inserted.
- ✧ Available Space: View the available space of SD card.
- ✧ Unmount SD Card: You can unmount SD Card for safe removal.
- ✧ Erase SD Card: Erase all data on the phone's sd card,such as music and photo.

Note: If you format SD card, it will erase all the data in SD card, please be prudential to use this feature.

Internal Phone Storage

- ✧ Available Space: View the capacity of RAM.

Note: *If you format Local disk, it will erase all the data in Local disk, please be prudential to use this feature.*

Change the preferred installation location for new apps, you can select 'internal device storage', 'removable SD card',or 'let the system decide'. You can also view free space of the mobile phone memory and SD card.

Release the phone memory: if the phone is out of memory, please try the following methods:

Move the file and E-mail attachments to SD card.

In the browser, remove all cache pages content and browse records information.

Unloading no longer use application.

Factory data reset.

✧ Battery

Display power and use the machine battery.

✧ Application program

View downloaded, on SD card, running, all app. You can uninstall the application, clear the data of generation in using, an also change the program storage location, move the app from ROM to local disk or from local disk to ROM.

Download: the third app has been installed, can be unloaded, clear the data and so on.

SD card: program installed in memory card, can be uninstall, clear the data and so on.

Running: the system is running program, can view the occupied memory space and other related data.

All application: all procedures of the current system, including system pre install program and the third party applications.

16.3 Personal

✧ Dual Sim settings

This phone support dual SIM card, you can choose to start one card, or can start double card.

Also can set SIM card that be used to access network.

✧ Location services

Let apps use data from sources such as WLAN and mobile networks to determine your approximate location. Let apps that have asked your permission use your location information.

✧ Security

➤ Set up screen lock: to set the style of screen lock.

None: cancel the screen lock.

Slide: set slide to unlock.

Pattern: set to unlock pattern.

PIN: set PIN code to unlock the screen (Figure).

Password: set password to unlock the screen(alphanumeric).

➤ Owner info: show owner info on lock screen.

➤ Encrypt phone: You can encrypt your accounts, settings, downloaded apps and their data, media, and other files. Once you encrypt your phone, you need to type a numeric PIN or password to decrypt it each time you power it on. You can't decrypt your phone except by performing a factory data reset, erasing all your data.

- Set up SIM card lock

Lock SIM card: Start or cancel the PIN lock; The functional need provide PIN before using it.

Change SIM PIN: Change PIN that used to access the data.

- Visible passwords: Display password when inputting password.
- Device administrators: Check installation manager in the mobile.
- Unknown sources: It will allow to install any source applications if you check the item. Otherwise, only allow to install applications that download from Android Market.
- Trusted credentials: Use of certificates and documents to ensure the safe use of each application.
- Install credential: Install encrypted certificates from SD card.
- Clear credential: Clear credential storage of all contents and reset its password.

✧ Language & input

Select language: Set display language of all applications and menu.

Text settings: Choose the need to use input method, and may carry on input method settings.

Text-to-speech output: Install the application of voice broadcast, need to install the voice engine and voice pack, after installation, here can be related settings.

✧ Backup and reset

Restore factory settings: Reset to factory default, will not delete the application program and data.

✧ Schedule power on/off

To open or close the timer switch machine and set the time.

16.4 Accounts

Add account

This function is used for account management, add account, delete account, can also set the synchronization frequency, control notice etc...

16.5 System

✧ Date & time

Automatic date & time: Use network-provided time.

Automatic time zone: Use network-provided time zone.

Set date: Set current date manual.

Set time: Set current time manual.

Select time zone: Choose local time zone.

Use 24-hour format: Show time by 24-hour.

Select date format: Choose date display format.

✧ Accessibility

Huge text: Set interface display for large font.

Power button ends call: During a call, pressing power ends call instead of turning off screen.

Touch & hold delay: set delay time of touch and hold.

Install web scripts: set apps to install scripts from Google that make their web content more accessible.

✧ Printing

After link to a print device ,we can start printing.

✧ About phone

View about mobile phone information.

17 WORLD CLOCK

Select 'world time', enter the world clock interface. This function is used to query the local time of world famous city.

Click the search icon of right top, then input city name to add city.

Long press a add city executable to replace and delete operation.

18 VIDEO

Enter into gallery, choose video directory, click one of video, then it will be played.

During playing, drag progress bar can fast forward or backward, press the side key to adjust volume.

19 FM RADIO

Before the use of FM radio, please make sure that the headphone have inserted, otherwise unable to properly use the function.

On the FM radio interface, the function of buttons as follows:

- ✧ : Open or close the FM radio.
- ✧ : Switching the audio come from earphone or loudspeaker.
- ✧ : Enter into the menu.
- ✧  : Switching to the previous or next channel.

20 SEARCH

You can search all communication on the mobile, contacts, call log, application, as well as specific information on the internet.

Input the search content, click on the button to the right of the input box to start the search and display the results.

21 APPLICATION MANAGER

View downloaded, on SD card, running, all app. You can uninstall the application, clear the data of generation in using, an also change the program storage location, move the app from ROM to local disk or from local disk to ROM.

Download: the third app has been installed, can be unloaded, clear the data and so on.

SD card: program installed in memory card, can be uninstall, clear the data and so on.

Running: the system is running program, can view the occupied memory space and other related data.

All application: all procedures of the current system, including system pre install program and the third party applications.

22 GOOGLE SETTINGS

On main menu, enter google settings interface, it includes functions as location, search, ads, verify apps, android device manager, etc.

23 PLAY STORE

Play Store lets you download useful application and games, if you install applications and games from play store, they appear in the menu.

First, set up a google account. enter your name and password.

After signing in, you can download useful application and games.

24 GALLERY

Management pictures and video files.

It will automatically search photos and videos, and classification in the corresponding folder.

✧ View picture

- Click the picture folder that you want to view.
- Click the picture.
- You can switch next or previous picture by sliding to left or right on the screen.

✧ Operation

- You can delete, slideshow, edit, rotate left, rotate right, crop, set picture as contact photo, set picture as wallpaper, details and so on.
- The picture will be amplified or reduced by apart or collapsed two fingers.

25 FILE EXPLORER

The file manager to view folders and files in the phone and memory card. The files and folders support to copy, delete, rename, sharing, view property and other common operations.

You can browse mobile phone file: music, pictures, video, documents and APK setup files.

26 DOWNLOADS

To view and management download content.

27 FLASHLIGHT

We can open flashlight in dark place.

28 CAMERA

You can use this function to shoot picture or record video. The picture and video will be stored automatically.

- ✧ Switch to video record: Slide the dot to video icon, then you can recording video.
- ✧ Select camera: To set back camera or front camera.
- ✧ Color effect: Can be set to none, mono, negative, sepia, cold.
- ✧ Scene mode: Can be set to auto, normal, action, night, portrait or landscape.
- ✧ Focus mode: can be set to auto, macro, multi.
- ✧ White balance: To set auto, incandescent, daylight, fluorescent, cloudy.
- ✧ Flash mode: Can be set to open or closed.
- ✧ Other settings: To set picture size, picture quality, scene mode, burst, countdown time, storage path, antibanding, exposure, ISO, brightness, contrast, saturation and so on.

29 MESSAGING

You can send and receive SMS or MMS. You can view through slip screen in the message list.

The message content displayed in conversation, also can be displayed in the folder form.

In the message list, press 'MENU' key, you can compose new message, delete conversation, search, setting.

✧ Compose new message

You can send new message to designated one or more contacts, and also save to draft by pressing back menu if you don't want to send it. In the message editing screen, click the receiver field, input the recipient number; Or click the icon at the right of the bar enter into contacts to choose recipient.

- Add subject: choose this item, it will turn to the MMS editing interface.
- Attach: To add data, Example: pictures, capture picture, videos, capture video, audio, record audio, slideshow.
- Discard: Exit message editor, return message list interface.
- Insert contact: Insert the information of any contacts in the phone book.
- Insert the phrase: Enter the common phrases list interface, select the message can be brought to the content domain.

✧ Reply message

When you receive the new message, the top of the state bar will show the corresponding icon and send out hints. You can reply after viewing the message.

- Enter into message list.
- Choose the record that you want to reply.
- Click the editor field, input the content.
- When you finish editing, click send.

✧ Delete message

Enter into message list, click on one of messages, long press in the content, choose 'delete' in the pop-up menu, then it will be deleted.

✧ Delete conversation

Enter into message list, long press one of messages, click on the trash icon, pop-up 'the message will be deleted', select 'delete' then all messages of this number will be deleted.

✧ Search

Enter into message list, select the search icon, input part of the message content, then the message will be searched.

✧ Settings

Storage settings

- Delete old messages: Delete old messages as limits are reached.
- Text message limit: To set limit number of SMS for each conversation.
- Multimedia message limit: To set limit number of MMS for each conversation.
- Mms/free/total: To view the MMS size/ available memory space/ total memory space.

SMS forwarding number

Forwarding information, together with the sender the forwarding.

Encode type: Set the encode type is auto, 7bit coding or 16bit coding.

Creation mode: Set the encode type is restricted, warning or free.

Signature settings

Optional signature: automatically append signature to every mms message you send.

Edit signature: enter here to set your signature.

SIM card setting

SMS setting

- Delivery reports: Request a delivery report for each message that you send.
- Manage SIM messages: View the messages that storage in SIM card.
- SMS save to SIM card: set up to receive the message to SIM card.
- SMS service center: To set number of SMS service center.

MMS settings

- Delivery reports: Request a delivery report for each MMS that you send.
- Multimedia message validity: 1H, 12H, 24H, 2days or maximum.
- Auto-retrieve: Automatically retrieve messages.

- Roaming auto-retrieve: Automatically retrieve messages while roaming.
- Priority: set to high, normal and low.

Notification settings

- Notifications: Display message notifications in status bar.
- Sound: To set the ringtone when new message incoming.
- Vibrate: set to always, only when silent and never.

other

- common phrases

This machine factory built some common phrases, you can delete, add or edit.

- Open SMS retry machine

Before sending is successful, open the can resend the information.

30 MUSIC

Play mp3 files. When playing music, if you want to use other application, you can press 'HOME' key, then the music will play in the background. Slide state bar, click the mini player to return music player.

- ✧ Enter into main menu, choose music.
- ✧ Music files are classified storage according to the artist, album, songs and playlists . Click music category that you want to play.
- ✧ Open music list.
- ✧ Click the music file that you want to play. Press side key to adjust volume.

31 SIM TOOLKIT

The SIM Application Toolkit (SAT), or SIM Toolkit, is a set of command specifications that define how applications on a Subscriber Identity Module (SIM) card must interact with any Mobile Equipment (ME).

XPX TECHNOLOGY CO., LTD
RM689B, HUAFA 411 Bldg. Huafa N. Road, Futian
Contact Person: ALICE
Tel: 0755-61622011 Fax:0755-83326511
E-mail: alicekyan@ gmail.com

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types 3G Mobile phone (FCC ID: 2ADIZ-LIFE) has also been tested against this SAR limit. The highest reported SAR values for head, body-worn accessory, wireless router(hotspot),and simultaneous transmission conditions are 0.233 W/kg, 1.166 W/kg , 0.712 W/kg, and 1.246W/kg respectively. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.