



User Manual



Wingman P5 Introduction



USB Type-A port to
connect to console



LED button
RGB light display





USB Type-A port for
connecting controllers

Console Settings

Before use Wingman P5, please confirm that the PS5 console is set to the following settings to ensure normal connection and use.

Path:

Setting> Accessories> Controller> Communicate Method> Use USB Cable




Wired connection method




First, plug the USB-C to USB-A cable into the corresponding USB-C port on the PS5 controller.



Then plug the USB-A port of the adapter into the USB-A port of the Wingman P5.



And plug the other end of the adapter's USB-A port into the USB port of the powered-on PS5 console.



When you see the connection icon appear in the upper right corner of the screen, confirm that the connection is successful and you can use the wired method to operate the controller on the PS5.

Wireless connection method



Please complete the instructions on the previous page first.

After confirming that the wired connection is successful, separate the PS5 controller from the Wingman P5.



Press and hold the PS button for three seconds to connect the wireless controller to the host.



You can use the joystick to control the screen, confirm that the connection is successful, and then you can use wireless mode to operate the controller on the PS5.

*Since the device and host have been paired during the wired connection process, the pairing success icon will not appear on the screen again.

*If the device becomes unresponsive during operation, please reconnect the Wingman P5 converter and reconnect, or confirm that the PS5 is set to accessory USB cable mode according to the instructions above.

LED light display



Flashing green light	Device reading
Blue light flashes slowly	The controller has not been connected successfully yet
Solid blue light	Device connection completed

LED button function: Press and hold for three seconds when connected to the wireless handlebar to disconnect the connection and slowly flash the blue light



FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

FCC and ISED Radiation Exposure Statement

This equipment complies with FCC and ISED radiation exposure limits set forth for an uncontrolled environment, This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement est conforme aux limites d'exposition au rayonnement FCC et ISED établies pour un environnement non contrôlé, cet équipement devrait être installé et exploité avec une distance minimale de 20cm entre le radiateur et Votre corps.

ISED STATEMENT:

- English: "

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device."

- French:"

Cet appareil est conforme aux normes RSS exemptées de licence d'innovation, sciences et développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

(1) l'appareil nedoit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."



FCC ID: 2ADKM006W
IC: 29174-ZPP006W

P/N: Wingman P5
M/N: ZPP006W

For the latest user guide and more information, visit our website:
www.brookaccessory.com

202510V1



Brook Gaming





簡易使用手冊



Wingman P5

本體介紹



USB Type-A 接口
連接主機



LED 按鍵
RGB燈號顯示



USB Type-A 接孔
連接控制器


主機設定

使用前請先確認PS5主機設定至以下指示之狀態，以確保正常連線及使用。

操作路徑(中/英)

設定>周邊機器>控制器(一般)>通訊方法>使用傳輸線連線

Setting>Accessories>Controller>Communicate Method>**Use USB Cable**




有線連接方式



先將USB-C to USB-A 線插入
PS5手把對應USB-C接口。



再將轉接線USB-A 接口 插上
Wingman P5 USB-A 接孔。



並將另一端轉接器USB-A 接口插入
已開機的PS5主機USB插孔中。



看到螢幕畫面右上角出現連線圖示，
確認連線成功，即可使用有線方式在
PS5上操作手把。

無線連接方式



請先完成上頁指示，確認有線連接成功後，將PS5手把與Wingman P5分離。



長按PS button按鍵三秒，無線手把即與主機連線。



可用手把搖桿操控畫面，確認連線成功，即可使用無線方式在PS5上操作控制器。

*因有線連線過程已將裝置和主機進行配對，故螢幕不會再次出現配對成功圖示

*若操作過程中裝置無反應，請將Wingman P5轉接器重新插拔後嘗試連線，或者確認PS5是否依照上述指示設定配件USB cable模式。

LED燈號顯示



閃綠燈	裝置讀取中
藍燈緩慢閃爍	手把尚未連接成功
藍燈長亮	裝置連接完成

LED按鈕功能：
在連線無線手把時長按三秒會中斷連線，並緩慢閃爍藍燈



※根據 NCC 低功率射頻器材技術規範 3.8.2 規定：

-取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自

變更頻率、加大功率或變更原設計之特性及功能。

-低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象

時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信

管理法規定作業之無線電通信。

-低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。



P/N: Wingman P5

M/N: ZPP006W

最新版說明書 / 更多詳細操作請上 Brook 官網查詢

www.brookaccessory.com

202510V1



Brook Gaming





シンプルなユーザーマニュアル



ウィングマン P5の紹介



ホストに接続するための
USB Type-Aポート



コントローラー接続用の
USB Type-Aポート




LEDボタンRGBライ
レイ

ホスト設定

ご使用前に、正常な接続と使用を確保するために、PS5 本体が以下の設定になっていることを確認してください。

パス
設定>アクセサリ>コントローラー>通信方法>USBケーブルを使用する




有線接続




まず、USB-C - USB-A ケーブルを PS5 コントローラーの対応する USB-C ポートに接続します。



次に、アダプタの USB-A ポートを Wingman P5 の USB-A ポートに接続します。



アダプターの USB-A ポートのもう一方の端を、電源が入った PS5 コンソールの USB ポートに差し込みます。



画面の右上に接続アイコンが表示されたら、接続が成功し、有線方式を使用して PS5 でコントローラーを操作できることを確認します。

無線接続方法



まずは前のページの手順を完了してください。有線接続が成功したことを確認したら、PS5コントローラーをWingman P5から取り外してください。



PS ボタンを 3 秒間押し続け、ワイヤレスコントローラーをホストに接続します。



ジョイスティックを使用して画面を操作し、接続が成功していることを確認してから、ワイヤレスモードを使用してPS5のコントローラーを操作できます。

*デバイスとホストは有線接続プロセス中にペアリングされているため、ペアリング成功アイコンは画面に再度表示されません。


※操作中にデバイスが応答しなくなった場合は、Wingman P5アダプターを接続し直して再接続するか、上記の手順に従ってPS5がアクセサリUSBケーブルモードに設定されていることを確認してください。

LEDライトディスプレイ



点滅する緑色のライト	デバイスの読み取り
青い光がゆっくり点滅する	ハンドルが正常に接続されていません
青色点灯	デバイスの接続が完了しました

LEDボタン機能：ワイヤレスハンドルバーに接続しているときに3秒間押し続けると、接続が切断され、青色のライトがゆっくり点滅します。



P/N: Wingman P5
M/N: ZPP006W

詳細につきましては以下のリンクをご確認ください。

www.brookaccessory.com

202510V1



Brook Gaming





간단한 사용자 매뉴얼



윙맨 P5 소개



호스트에 연결하기 위한
USB Type-A 포트



컨트롤러 연결용 USB Type-A
포트





LED 버튼 RGB
라이트 디스플레이

호스트 설정

사용하기 전에 정상적인 연결과 사용을 보장하기 위해 PS5 본체가 다음 설정으로 설정되어 있는지 확인하십시오.

경로 설정 > 액세서리 > 컨트롤러 > 통신 방법 > USB 케이블 사용




유선 연결



먼저 USB-C - USB-A 케이블을 PS5 컨트롤러의 해당 USB-C 포트에 연결합니다.



그런 다음 어댑터의 USB-A 포트를 Wingman P5의 USB-A 포트에 연결합니다.



어댑터의 USB-A 포트의 다른 쪽 끝을 전원이 켜진 PS5 콘솔의 USB 포트에 꽂습니다.



화면의 오른쪽 상단에 연결 아이콘이 표시되면 연결이 성공하고 유선 방법을 사용하여 PS5에서 컨트롤러를 조작할 수 있는지 확인합니다.

무선 접속 방법



먼저 이전 페이지의 단계를 완료하십시오. 유선 연결이 성공했는지 확인한 후 PS5 컨트롤러를 Wingman P5에서 분리하십시오.



PS 버튼을 3초 동안 길게 눌러 무선 컨트롤러를 호스트에 연결합니다.



조이스틱을 사용하여 화면을 조작하고 연결이 성공했는지 확인한 다음 무선 모드를 사용하여 PS5 컨트롤러를 조작할 수 있습니다.

* 장치와 호스트가 유선 연결 프로세스 중에 페어링되므로 페어링 성공 아이콘이 화면에 다시 표시되지 않습니다.

※조작중에 기기가 응답하지 않는 경우는 Wingman P5 어댑터를 재연결하거나 위의 순서에 따라 PS5가 액세서리 USB 케이블 모드로 설정되어 있는지 확인하십시오.

LED 라이트 디스플레이



깜박이는 녹색 불빛	기기 읽기
푸른 빛이 천천히 깜박임	핸들이 제대로 연결되지 않았습니다.
청색 점등	기기 연결이 완료되었습니다.

LED 버튼 기능: 무선 핸들바에 연결되어 있을 때 3초간 누르고 있으면 연결이 끊어지고 파란색 표시등이 천천히 깜박입니다.



R-R-ZP0-ZPP006W

P/N: Wingman P5

Registrant : ZEROPLUS TECHNOLOGY CO., LTD.

M/N: ZPP006W

추가적인 자세한 사항은 저희 공식 웹사이트인
www.brookaccessory.com 을 방문하시기 바랍니다.

202510V1



Brook Gaming

