


Date: 06 07 2026 Product: EP-0748 Plush DT TWS IM	R1	
Size: 222.75(W) x 105(H)mm		

FRONT SIDE




Disney MINNIE MOUSE
INSTRUKTION MANUAL
Thank you for purchasing the True Wireless Earbuds.
This manual provides more information about this product,
please read the instructions before using.

©Disney
www.disney.com

Product Overview

True Wireless Earbuds Portable Charging Case



1. LED Indicator 4. Charging LED Indicator
2. Microphone 5. USB Type-C Charging Port
3. Touch Control Area
On/Off, Play/Pause Music
Answer/End Call

Package Contents

- 1 (One) Pair of Earbuds
- 1 (One) USB Type-C Charging Cable
- 1 (One) Portable Charging Case
- 1 (One) Portable Charging Case Carabiner
- 1 (One) Instruction Manual

Specifications

- Driver Diameter: 13 mm
- Impedance: 32 Ohms
- Frequency Response: 20 Hz - 20 kHz
- Sensitivity: 98 dB ±3 dB
- Charging Case Battery Capacity: 200mAh
- Power Supply: Li-ion Battery 3.7V 30 mAh Per Earbud
- Total Playtime: 10 Hours
- Charging Time: 2 Hours
- Bluetooth Range: 32 Feet
- Bluetooth Version: 5.4
- USB Type-C Charging Cable Length: 9.8in. (25cm)
- USB Type-C Charging Cable Rating: Max. 5VDC, 5W

Power On/Off

Power On
Press and hold the button of Earbuds for 3 seconds.

Power Off
Press and hold the button of Earbuds for 5 seconds.

Pair the wireless Earbuds with your mobile device

1. Keep the distance between the Earbuds and mobile device within 32.8 feet.
2. De-activate the Bluetooth function on your mobile device.
3. Put the Earbuds back to charging case before use.
Take both Earbuds out from charging case and wait for 3 to 5 seconds for auto pairing. Both Earbuds will have a beep sound when auto pairing is done successfully.
4. Activate the Bluetooth function on your mobile device and select **"EP-0748 TWS"** from the list shown.
5. After pairing is successful, both Earbuds will have another beep sound.

***Attention:** If the auto pairing is not successful, manual pairing between Earbuds is essential by following below procedure:

1. Make sure the Earbuds are charged.
2. De-activate the Bluetooth function on your mobile device. (If you had been paired the Earbuds to some other mobile device(s) nearby, please sure to de-activate those device(s) too).
3. Power on both Earbuds simultaneously by press and hold the button for 3 seconds and wait for 3 to 5 seconds for auto pairing. (Keep the Bluetooth function off on your mobile device before this operation.)
4. Activate the Bluetooth function on your mobile device and select **"EP-0748 TWS"** from the list shown.
5. After pairing successfully, both Earbuds will have a beep sound.

Reconnect the wireless Earbuds to your mobile device

When powered on, the wireless Earbuds will automatically connect with the last successfully paired device.

Disconnect the wireless Earbuds from your mobile device

Power off the wireless Earbuds; or
Switch off the Bluetooth on your mobile phone; or
Leave the Earbuds 60ft away from your mobile phone or further.

BACK SIDE

Answer / Reject a call

When receive a call, press the button once (on either earbud) to accept the call, or answer the call normally via your mobile phone.
Press and hold the button 2 seconds to reject it.

End a call

To end the call, just press the button at any side of Earbuds.

Functions

Pause / Play Music: Press on Left or Right button.
On hold to previous song: Double press on Left button.
Advance to next song: Double press on Right button.
Voice Assistant: Press and hold on Left or Right button for 2 seconds.

Charging your Earbuds

1. Open the charging case cover.
2. Insert the Earbuds into the charging case.
3. The Earbuds will start the charge automatically.
4. LED indicator light of the charging case will be turned on when charging.
5. Once fully charged, the LED will stop flashing.

Recharge Charging Case

⚠ For your safety, please always use appropriate EV output charger/adaptor to charge the product. DO NOT USE Quick Charging USB Adapter to charge this product, as it might damage the product.

1. Use the USB Type-C charging cable provided with the packaging.
2. Connect the USB Type-C plug to USB Type-C charging port on the charging case, then connect the USB plug to a USB port on a wall adapter to begin charging.
3. The LED on the charging case will flash during charging.
4. Once fully charged, the LED will be stop flash.
5. The LED will be on during earbuds is charging and will be off after fully charged.

NOTE:

- You must select a qualified charger from a regular manufacturer.
- You must charge the charging case and earbuds if it has been not used for more than 6 months.



⚠ **CAUTION:** FOR YOUR SAFETY, the charging cable included with this item is intended for use with this product only.

FAQ

If the wireless Earbuds cannot be paired with your device, please try the following:

- Ensure that your Earbuds are in pairing mode or reconnection mode.
- Ensure that Bluetooth search function of your mobile device is activated.

If the wireless Earbuds will not turn on:

- Make sure the Earbuds are fully charged.
- Make sure the protective stickers are removed from the Earbuds.

Can't I change the battery for the Earbuds and the charging case?

The wireless Earbuds and the charging case use a built-in non-detachable battery which cannot be removed.

If the charging case cannot be recharged:

- If you use a power outlet, ensure that the power supply is connected securely and the outlet works.

⚠ Safety instructions for the lithium battery and charging the product.

- The input voltage to the product is 5VDC, 1A.
- In order to charge the product in a safe manner and reliable conditions, please only adopt certified appropriate charger/adaptor for charging the product.
- Only charge the product at ambient temperatures between 10°C/ 50°F and 40°C/104°F.
- Do not heat above 70°C/158°F, eg. Do not expose to sunlight or throw into fire.
- Switch off the product after use.
- Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.
- In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

FCC Statement

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by 1616 Holdings, Inc. is under license. Other trademarks and trade names are those of their respective owners.

FCC

ITEM# EP-0748-MINNIE

Distributed by 1616 Holdings, Inc.
701 Market Street, Suite 200
Philadelphia, PA 19106
Made in China

FCC ID: 2ADMS-EP-0748

Keep all relevant information for future reference