

GA-0100_IM

Size: 297(W) x 105(H)mm

18Jun2025

FRONT SIDE

PINK OMBRE FADE WIRELESS KEYBOARD

INSTRUCTION MANUAL

Thank you for purchasing the Pink Ombre Fade Wireless Keyboard. This manual provides more information about this gaming keyboard, please read the instructions before using.

Product Overview

Package Contents

1(One) Ombre Fade Wireless Keyboard
11.7in. x 5.2in. x 1.42in. (29.7cm x 13.1cm x 3.6cm)
1(One) Instruction Manual

Specifications

Keys: 63
Frequency: 2.402G - 2.480GHZ
Distance: Approx. 10m
Working Voltage: 2.2 - 3.2V
Working Current: ≤5mA
Battery: 1 x AAA 1.5V (not included)
Bluetooth Version: 5.2
Bluetooth Channel: 3 Channels
Support System:
Windows (except Windows 7), Linux, Mac OS, Android, iOS

Batteries Installation For Remote Controller

To install battery into the Wireless Keyboard, take out the battery box cover to open the battery compartment. Insert 1 x "AAA" 1.5V battery (Not included) into the battery box. Battery should be placed as shown on the diagram. Put back in place the battery box cover.

Notice:
When placing the battery, you must insert according to the correct polarity, the Wireless Keyboard won't function if battery is reversed.

When the battery is low, the power indicator will turn a red light. Please replace the battery in time.

Pair the Wireless Keyboard with your device

- Keep the distance between the device within 32.8 feet.
- De-activate the Bluetooth function on your device.
- Press and hold the Fn + A / S / D buttons to select the Bluetooth channel (3 Channels) and enter the pairing mode and the Bluetooth Indicator will flash in blue. Activate the Bluetooth feature on your Bluetooth device and start searching.
- Activate the Bluetooth function on your mobile device and select from the list shown:
FN+A (BT1) : GA-0100 BT KB-1
FN+S (BT2) : GA-0100 BT KB-2
FN+D (BT3) : GA-0100 BT KB-3
- The Bluetooth Indicator will flash in blue rapidly for few seconds after you have paired successfully.
- You can connect maximum 3 devices by 3 Bluetooth channels. When you successfully connected 2 or 3 devices, you can switch among the devices easily by pressing the buttons Fn + A / S / D.

***Attention:** If the auto pairing is not successful, manual pairing between Wireless Keyboard is essential by following below procedures:
1. Make sure the battery is enough and the keyboard is within the effective working distance.
2. De-activate the Bluetooth function on your device. (If you had been paired the keyboard to some other device(s) nearby, please sure to de-activate those device(s) too).
3. Delete the pairing logs, and then pair the keyboard and the device again.
4. Activate the Bluetooth function on your devices and select from the list shown:
FN+A (BT1) : GA-0100 BT KB-1
FN+S (BT2) : GA-0100 BT KB-2
FN+D (BT3) : GA-0100 BT KB-3
5. After pairing successfully, Bluetooth Indicator will be off.

Please Note: This Bluetooth keyboard will be asleep if you don't use it for more than 10 minutes. If you want to wake it up, please press any buttons on the keyboard, the Bluetooth will re-connecting automatically.

BACK SIDE

Reconnect the Wireless Keyboard to your devices

Press the Fn + A / S / D buttons. This keyboard will automatically connect to the device again. (The device Bluetooth must be on) if you connect the keyboard to 2 or 3 devices, press the Fn + A / S / D buttons, it will automatically connect to the last connected device.

Disconnect the Wireless Keyboard from your devices

Switch off the Bluetooth on your devices; or
Leave the Wireless Keyboard 60ft away from your devices or further.

Function

For Windows (except Windows 7), Linux, Mac OS, Android, iOS

Key combination	Function	Key combination	Function
FN + 1	F1	FN + A	Bluetooth Channel 1
FN + 2	F2	FN + S	Bluetooth Channel 2
FN + 3	F3	FN + D	Bluetooth Channel 3
FN + 4	F4	FN + Win	Window Lock
FN + 5	F5	FN + ▲	Page Up
FN + 6	F6	FN + ▼	Page Down
FN + 7	F7	FN + ◀	Home
FN + 8	F8	FN + ▶	End
FN + 9	F9	FN + Esc	-
FN + 0	F10	FN + Shift + Esc	-
FN + *	F11		
FN + =	F12		

For Mac OS only

Key combination	Function
Win	⌘ Command
Alt	Option

Hints and Tips

When the Wireless Keyboard is not working:

- Replace the battery if the keyboard no longer reacts to input.
- Ensure your Bluetooth-enabled device's wireless function is active.
- Ensure there are no other wireless devices in discovery mode.
- Move the keyboard closer to the device.
- Pair again the keyboard and the device.

Maintenance and Warnings

- Do not squeeze, distort or pat on the keyboard.
- Do not scan the keyboard with a microwave. Keep it away from the magnetic field.
- Keep the keyboard away from liquid. Use it in a dry environment.
- Use a soft cloth to clean your keyboard.

For AAA Battery

⚠ WARNING: TO AVOID BATTERY LEAKAGE

1) The battery used with this product is a small part and should be kept away from small children who still put things in their mouths. If it is swallowed, promptly see a doctor and leave the doctor phone American Association of Poison Control Centers (1-800-222-1222).

2) Always purchase the correct size and grade of battery most suitable for intended use.

3) Do not mix old and new batteries, alkaline, standard (Carbon - Zinc) or rechargeable (Nickel-cadmium) battery.

4) Clean the battery contacts and those of the device prior to battery installation.

5) Ensure the battery is installed correctly with the regard to polarity (+ and -).

6) Always remove battery if consumed or if product is to be left unused for a long time.

FCC Statement

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by 1616 Holdings, Inc. is under license. Other trademarks and trade names are those of their respective owners.

Item# GA-0100-WT

Distributed by 1616 Holdings, Inc.
701 Market Street, Suite 200
Philadelphia, PA 19106

Made in China

FCC ID: 2ADM5-GA-0100

Keep all relevant information for future reference