

64.5mm

Sound Top

Wireless Table Speaker

EXCELLENT PERFORMANCE • EASY USE

Instruction Manual

Thank you for purchasing the Sound Top Wireless Table Speaker. This manual provides more information about this wireless speaker. Please read the instructions before using.

Product Overview

Front

Back

How to Assemble

Step 1 Fix the legs on the hole at the bottom center of the table speaker.

A

Step 2 Register the assembly sequence at the bottom of the table speaker.

B

Check all legs are on the feet.

C

Step 3 Check a stick (also, recharge it) is inserted into the USB port. (If the stick is not inserted, the speaker cannot be used.)

D

Package Contents

Sound Top Wireless Table Speaker x 1

USB Type-C Charging Cable x 1

Stick x 1

CVA Sticker x 3

Technical specification

① LED Indicator ② Power On/Off Button ③ Music Button (Shuffle/Play/Pause) ④ USB Type-C Charging Port ⑤ Volume Up/Down Button ⑥ Volume Up/Down Button	- Speaker Power: 100 mW - Frequency: 60 Hz - Power: 10 W - Line: Battery 2 x 7000 mAh - Power: 4.4 V - Charging Time: 2-3 hours	- Bluetooth Range: 30 M - Bluetooth Version: 4.2 - Bluetooth Profile: A2DP, AVRCP, GATT - Power: 10 W - Line: USB Type-C Charging Cable - Power: 4.4 V - Charging Time: 2-3 hours
---	--	---

MAXIMUM 12.8 lbs
(5.8 kg)

MAXIMUM 36.1 lbs
(16.4 kg)

背面