



Date: 13 OCT 2023
Product: SP-0235 IM

SKU:



SP-0235 IM
Size: 387(w) x 100(h) mm

 DUAL LED WIRELESS SPEAKER Instruction Manual Thank you for purchasing the DUAL LED Wireless Speaker. This manual provides more information about this wireless speaker, please read the instructions before using.  	Product Overview Front  Back  Wireless Speaker Charging Dock 1. USB Type-C Charging Port 2. LED Indicator 3. On/Off/Mode Button 4. Volume Up/Next Song Button 5. Volume Down/Previous Song Button 6. USB Type-C Charging Port 7. LED Indicator
--	---

Package Contents

Dual LED Wireless Speaker 2.36in. x 2.2in. x 2.36in.(6cm x 5.6cm x 6cm) each
Charging Dock 6.3in. x 3.15in. x 0.6in. (16cm x 8cm x 1.52cm)
(One) Charging Cable 19.7in. (50cm) / 1(One) Instruction Manual

Power On/Off

Power on:

Press and hold 2 second on the On/Off Button.

Power off:

Press and hold 4 second on the On/Off Button.

Note:

Always power off the speaker when not in use.

Pair Wireless speaker with your mobile device

1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet.

2. Power on the wireless speaker.

3. Activate the Bluetooth function on your phone within range and select "SP-0235 SPK" from the list shown.

4. You will hear a beep sound when pairing is successful.

Reconnect Wireless speaker to your mobile device

When powered on, the wireless speaker will automatically connect with the last successfully paired device.

Approval:

Date: