SP-0304 IM
Revised: Aug10/16

BASS JAXX

RETRO MIC AUDIO BLUETOOTH SPEAKER INSTRUCTION MANUAL



Table of contents

1 Introduction·····1
2 Packaging Contents ·····2
3 Connection Diagram·····2
4 How to use ·····3
4.1 General function ·····3
4.2 Pairing to mobile phone ·····4
4.3 Charging your speaker ·····6
5 Product Specification·····7
6 FAQ·····8

1.Introduction

Congratulations, and thank you for choosing the Retro Mic Audio Speaker. This manual will help you operate the Bluetooth Speaker, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Retro Mic Audio Speaker.

Safety Rules

1 Please follow the rules depicted in this manual closely to ensure your safety. Before using this Bluetooth speaker, we would strongly encourage you to read through this user manual.

2 Be more wary of any edges, uneven surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage.

3 Do not modify, repair or dismantle this Bluetooth speaker. Doing so may result in fires, electric shocks, complete breakdown of this Bluetooth speaker, etc. All of which, are not covered under warranty.

4 Do not use any diluents or volatile liquid to clean the Bluetooth speaker.

5 Do not use the Bluetooth speaker in a hazardous location.

2.Packaging Contents

1X Retro Mic Audio Speaker

1X Micro USB Cable

1X Instruction Manual

3.Connection Diagram



4.How to use

4.1.General Functions

Desired Result	Required Action
Turn on & Enter the pairing mode	Press the button to the right.
Pairing	You should use a Bluetooth function mobile phone or other Bluetooth Master Device and to perform pairing action.
Turn off	Press the button to the left.
Charging	Plug the Micro USB cable to port of the device.

4.2.Pairing to Mobile phone or other device

To use your Bluetooth speaker, you must first pair your speaker with a phone or a computer. Once your Bluetooth speaker is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

Pairing to a phone and Entertainment:

- Turn on your phone and ensure its Bluetooth function is activated
- Turn on the speaker go to the pairing mode.
- Search your Bluetooth devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
- After a few second the phone will list the "Retro Mic Audio Speaker" as a discover device. Select it and follow your phone instruction to select this pairing.
- Your phone will confirm the pairing, and then press Yes/Ok.
- Finally, select to connect with Round speaker from your phone.
- You can play music; watch TV/movie and play game with your phone, then your can hear all the sound or music form the speaker. Also you can control the player by operating the speaker. Example, volume up and next music.

Pairing to a computer and Entertainment:

- If there is no Bluetooth function supported by your computer, a Bluetooth adapter is necessary. Fix the adapter with your computer and ensure its Bluetooth function is activated.
- Turn on the speaker go to the pairing mode.
- Open the Bluetooth software (such as BlueSoleil) installed on your computer, and selects "Search your Bluetooth devices" function. Refer to user manual of the Bluetooth software for more information.
- After a few second the "Retro Mic Audio Speaker" will list in Bluetooth software of your computer as a discover device. Select this icon and click right button of mouse to select "pairing" item, then select "connect with audio device" with same operation.
- Open your media player soft to play music, watch TV/movie and play game, then all the sound will be playback on your speaker.

4.3.Charging your speaker

The speaker is convenient to connect to Micro USB charger with Micro USB port marked with . Make sure that your speaker is full charged for at least 6 hours before initial use. Insert one terminal of your charger to USB port of PC and other terminal to Micro USB cable.

Warning:

- You must select a qualified charger from a regular manufacturer.
- You must charge the Bluetooth speaker if it has been not used for more than 12 months.

5. Product Specification

Parameter	Value
Driver Diameter	40mm
Impedance	4 Ohms
Bluetooth Version	3.0
Battery Capacity	300 mAh Li-Ion
Bluetooth Range	10m
Battery Working Hours	1-2 Hours

6.FAQ

1. Why is there no power even when the Speaker is power on?
Ans: Ensure the battery is being charged up to 6 hours for first time using.

2. There is no sound when playback.
Ans: Check the connection between speaker with phone or computer, if the connection is not established, please reconnect again. Make sure the speaker is paired and connected with your target phone or other master device.

Distributed by Five Below Merchandising, Inc.
1818 Market Street, Suite 2000
Philadelphia, PA 19103
Made in China
Visit Us At:
www.fivebelow.com

iPod®, iPhone® and iPad® are trademarks of Apple Inc. registered in the U.S. and other countries. Android™ is trademark of Google, Inc.

Keep All Relevant information for Future Reference

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ●Reorient or relocate the receiving antenna.
- ●Increase the separation between the equipment and receiver.
- ●Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ●Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by Zeeva International Limited may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.