





 AGES 8+ KIDS WALKIE TALKIES INSTRUCTION MANUAL  Works up to 500 feet under ideal conditions.	Product Overview FRONT BACK Power Indicator On/Off Switch Talk Button Microphone and Speaker Kids Walkie Talkies Instruction Manual	Batteries Installation  To install batteries into the Kids Walkie Talkie, unscrew the screw on the battery box cover to open the cover. Insert 3 x "AAA" 1.5V batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram. Replace the battery box cover and tighten the screw.	Batteries Installation  Notice: When inserting the batteries, you must insert according to the correct polarity, the Kids Walkie Talkie won't function if batteries are reversed.
How to Use 1. Rotate the "On/Off Switch" anti-clockwise to turn on the Kids Walkie Talkie. 2. Press and hold the "Talk Button" to start to talk. 3. Unhold the "Talk Button" to end the talk. 4. Double press the "Talk Button" to send a call tone to all Kids Walkie Talkies which are in range. 5. Rotate the "On/Off Switch" clockwise to turn off the Kids Walkie Talkie. 6. You can communicate with another color version of Kids Walkie Talkie.  Specifications Frequency: 462.5625 MHz Kids Walkie Talkies Requires: 3(Three) x AAA 1.5V Alkaline Batteries (Not Included) Care and Maintenance Before using this product, please read all the instruction and warning in this manual: 1. Do not remove the electronic components from the product any time. 2. Do not immerse the product in water. 3. Do not place the product near a heater or any electrical equipment. 4. Cleaning the product with a soft and dry cloth. Do not use any abrasives or cleaning agents to clean the product. 5. Make sure to wipe the product dry after clean. 7. Manufacture does not bear any responsibility for any damage from failure to comply with this product guide.	Important: Battery Information For AAA Batteries ⚠ WARNING: TO AVOID BATTERY LEAKAGE 1) The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222). 2) Always purchase the correct size and grade of battery most suitable for intended use. 3) Do not mix old and new batteries, alkaline, standard (Carbon - Zinc) or rechargeable (Nickel-cadmium) batteries. 4) Clean the battery contacts and those of the device prior to battery installation. 5) Ensure the batteries are installed correctly with the regard to polarity (+ and -). 6) Always remove batteries if consumed or if product is to be left unused for a long time. FCC Part 95 warning This device operates on the Family Radio Service (FRS) frequencies in accordance with FCC Part 95B rules. No FCC license is required to operate this device. Users are permitted to operate the channel selector, volume control, and push-to-talk (PTT) button as described in this manual. Internal adjustments, repairs, or replacement of transmitter components may result in violation of FCC rules and must only be performed by qualified service personnel.	Warning This product is suitable to be used by people who has operating experience in remote toy or aged no less than 8 years old. Please do not put the product in your mouth to prevent choking hazard of small parts. Please do not put the finger into available interspaces. Please do not play the product in a brutal way such as throwing, crashing or twisting it. Please store the smaller-sized product accessories in places that are out of reach of children, in order to avoid the occurrence of accidents. Avoid placing the batteries in places in high temperatures and avoid exposure to heat. When young children are operating the product, it shall be ensured that the adults are guiding and making sure the product control is within the viewing range of the controller (or instructor) so that it makes the control of the toy more convenient. When the product is not in use, please switch off the power supplies of the toy, and remove the batteries from the product. Please note that we won't take any responsibility for any wrong operation as this may result in severe injury or loss of property, and we cannot control the operating process during the time when the user assembles or uses this product. Once this product is sold, we won't be responsible for any safety responsibility during the time the user operates or uses controls this products.	FCC Statement This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation, if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or experienced radio/ TV technician for help. RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. FCC FCC ID: 2ADM5-WT-0001 Distributed by: 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106 Item# WT-0001 Made in Shantou, China Keep All Relevant Information For Future Reference