

TROUBLESHOOTING

No power	Recharge your headphones using the included Micro USB charging cable.
Music is not playing over bluetooth	Make sure your Bluetooth® device has A2DP profile. Check if both devices are paired and connected over Bluetooth®. Restart the headphones to reconnect your Bluetooth® device.
Bluetooth® device will not reconnect with the earbuds	Navigate to your Bluetooth® settings menu on your Bluetooth® device, tap “MERKURY-BTH13,” and select “Forget.” Now follow the steps to pair your device again.

Specifications:

Bluetooth® Version: 4.2
Wireless Range: Up to 30ft
Impedence: 32Ω
Battery Capacity: 300mAh
Driver Size: 40mm

Battery Playback: Approx. 6 hrs*
Battery Standby: Approx. 50 hrs*
Charging Time: Approx. 1-2 hrs*

*Depends on individual use.

User's Manual for

Included:
Bluetooth® Headphones
USB Charging Cable
User Manual



Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by Shenzhen Kingstar Industrial Co.,Ltd. may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

CHARGE IT

- Plug the micro USB cable into the micro USB port on the bottom of the right headphone, and connect the other end of the cable to either a computer USB port or a USB-compatible charger.
- A solid red LED light will appear to indicate when the headphones are charging, even while headphones are turned off.
- When charging is complete, the LED light will turn off.
- Charging time is approximately 1-2 hours.

PAIR & CONNECT WITH A NEW DEVICE

- With your headphones powered OFF, press & hold the “⏻” button for 2-3 seconds until the LED light flashes red and blue. Your headphones are ready to be paired.
- On your Bluetooth®-enabled device, navigate to the Bluetooth® settings menu, turn on the Bluetooth® feature, and search for new devices.
- After a few seconds you will see “MERKURY-BTH13” listed.
- Tap this model to select it. The LED will begin to slowly blink blue, and the headphones will emit a tone to indicate that it has been successfully paired with your device.

NOTE: You only need to pair your Bluetooth® device with the VERVE headphones once.

NOTE: If your device asks for a password to connect to the headphones, enter “0000.”

PLAY

- Connect your device to the VERVE headphones via Bluetooth® (see “Pair & Connect with a New Device”).
- Open your favorite music app and press play.
- Control the track & volume from your device, or using the in-line controls on the VERVE headphones. Press the “▶” button once to play/pause music & answer calls.
- Press the “+” or “-” button once raise/lower the volume on the headphones. Press and hold to skip to the next/previous track.
- All audio, including music, games, videos, and notifications will be routed through the VERVE headphones.

NOTE: Volume on your device and on the headphones are controlled separately.

RECONNECT WITH YOUR DEVICE

- Press & hold the “⏻” button on the VERVE headphones for 2-3 seconds.
- The headphones will power on, a blue LED light will flash, and will automatically reconnect to the last Bluetooth® device they were connected to.
- If you haven’t paired the headphones to any device follow the steps in the “Pair & Connect” section.
- If the headphones don’t auto-reconnect to your device, navigate to the Bluetooth® menu and tap “MERKURY-BTH13.”

POWER OFF

- Press and hold power button for 2 seconds.
- The headphones and LED light will turn off.

