

English

1 APPEARANCE

- 1. Test/Silence Button
- 2. Alarm/Test/Signal Indicator
- 3. Tamper Switch
- 4. Battery Holder

2 ENROLLMENT

3 INSTALLATION

- I. Check signal strength.
- II. Install the detector.

4 TEST

User Manual

Scan the QR code for more information and operation help.

Specification

Detection Method	Chamber with photoelectric sensor
Operation Mode	Independent & wireless reporting
Siren Volume	≥ 85 dB @ 3 m
LED Indicator	Blue (alarm)
Operating temperature	-10 °C to 55 °C (14 °F to 131 °F)
Storage temperature	-20 °C to 60 °C (-4 °F to 140 °F)
Operating humidity	10% to 90%
Dimension (D x H)	42 x 42 x 48.4mm
Transmission frequency	433 MHz
RF range	800 m (free space)
Battery	Non-Replaceable CR17450 x 1 for Main Sensor CR123A x 1 RF Module, 3V, 10 Years Life Span

1

User Manual

2

3

4

1

User Manual

2

3

4

