

Golf/Sport Watch

Quick Start Guide



Function Buttons Description



Hold "Power" button for 2-3 seconds to turn On / Off




Changing the Clock Face




- 1.
- 2.
- 3.
- 4.


Golf / Running / Cycling / Swimming Mode



Steps / Mileage / Calories / Bluetooth Button



How to Charging



Battery / Charging Information

Battery Specifications : 3.7V / 450mAh
Charging Specifications : 5V / 500mA

Notice

Please use the 5V output USB charger must comply with the CE directive and standards.
This warranty does not cover any damage or defects sustained on the device as a result of a non-certified charger.

ゴルフ・トライアスロン ウォッチ

クイック スタート ガイド




ボタンの機能説明




電源ボタンを2～3秒押すとオン/オフ

文字盤を変更する




- 1.
- 2.
- 3.
- 4.


ゴルフ / ランニング / サイクリング / スイミング / トライアロン モード



ステップ / マイル数 / カロリー / Bluetooth ボタン



充電方法



バッテリー / 充電 仕様

バッテリー : 3.7V / 450mAh、充電 : 5V / 500mA

注意

「CE認証」に準拠したDC5V出力充電器を使用してください。「非CE認証のDC 5V充電器」が製品に損傷をうければ、弊社は無償保証責任を免れることができます。

高爾夫三鐵錶 Golf/Sport Watch




按鍵基本功能



按住電源鍵2~3秒開/關機




時間面盤切換




- | | |
|----|----|
| 1. | 2. |
| 3. | 4. |

快速使用手冊 Quick Start Guide


高爾夫/跑步/自行車/訓練 模式



計步/里程/卡路里/藍芽開關



充電方式



電池/充電資訊

電池規格：3.7V / 450mAh；充電規格：5V / 500mA

注意

請務必使用符合CE認證之5V輸出充電器充電，如使用非CE認證之5V輸出充電器造成產品故障損壞，本公司可免除保固維修之責任。

高尔夫三铁表 Golf/Sport Watch




按鍵基本功能



按住电源键2~3秒开/关机




时间面盘切换




- | | |
|----|----|
| 1. | 2. |
| 3. | 4. |

快速使用手冊 Quick Start Guide


高尔夫/跑步/自行车/训练 模式



計步/里程/卡路里/藍芽開關



充电方式



電池/充电資訊

電池規格：3.7V / 450mAh；充電規格：5V / 500mA

注意

请务必使用符合CE认证之5V输出充电器充电，如使用非CE认证之5V输出充电器造成产品故障损坏，本公司可免除保固维修之责任。

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.