


EXHIBIT B - EUT EXTERNAL PHOTOGRAPHS

EUT – Front View (Model: LKV388A)



EUT – Rear View (Model: LKV388A)



EUT – Top View (Model: LKV388A)



EUT – Bottom View (Model: LKV388A)



EUT – Left View (Model: LKV388A)



EUT – IR Top View



EUT – IR Bottom View



EUT – Adapter View



EUT – Adapter Label View



EUT – Front View (Model: LKV388)



EUT – Rear View (Model: LKV388)



EUT – Top View (Model: LKV388)




EUT – Bottom View (Model: LKV388)



EUT – Left View (Model: LKV388)



EUT – Right View (Model: LKV388)



EUT – Front View (Model: LKV688-200M)



EUT – Rear View (Model: LKV688-200M)




EUT – Top View (Model: LKV688-200M)




EUT – Bottom View (Model: LKV688-200M)



EUT – Left View (Model: LKV688-200M)



EUT – Right View (Model: LKV688-200M)



EUT – Front View (Model: LKV388SDI)



EUT – Rear View (Model: LKV388SDI)



EUT – Top View (Model: LKV388SDI)



EUT – Bottom View (Model: LKV388SDI)



EUT – Left View (Model: LKV388SDI)



EUT – Right View (Model: LKV388SDI)



EUT – Front View (Model: LKV388VGA)



EUT – Rear View (Model: LKV388VGA)



EUT – Top View (Model: LKV388VGA)




EUT – Bottom View (Model: LKV388VGA)




EUT – Left View (Model: LKV388VGA)



EUT – Right View (Model: LKV388VGA)



EUT – Front View (Model: LKV388DVI)



EUT – Rear View (Model: LKV388DVI)



EUT – Top View (Model: LKV388DVI)



EUT – Bottom View (Model: LKV388DVI)



EUT – Left View (Model: LKV388DVI)



EUT – Right View (Model: LKV388DVI)

