

beFree JOYCE
the freedom of sound.

BFS-33X

2.1 CHANNEL WIRELESS MULTIMEDIA LED DANCING WATER BLUETOOTH SOUND SYSTEM

OWNER'S MANUAL

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

PACKAGE CONTENT

Please take a moment to ensure that everything listed in the list below is included in your package



2.1 CHANNEL SOUND SYSTEM



DC 5V 2A POWER ADAPTER



3.5mm PLUG CABLE

PACKAGE CONTENT | BF5-33X | 3

REAR SPEAKER CONNECTION

Speakers Output

Power Adapter

Right

Left

Auxiliary Input

4 | BF5-33X | REAR SPEAKER CONNECTION

SPECIFICATIONS	
Power Output	5W+3W*2
Supply Voltage	DC 5V 2A
Bluetooth	5.0
Material	Acrylic + ABS
Base unit	220mm*132.5mm
Treble unit	60mm*268mm
Bass unit	2330g ± 20g
Treble unit	21'(370g ± 20g)
Frequency Response	75Hz-18KHz
S/N	72dB
Main driver unit	4 inches
Satellite driver unit	1.75 inches
Operation Temperature	32°F - 104°F
Storage Temperature	5°F - 140°F
Storage Humidity	20%-90% RH
20 Multi-colored LEDs in total (Red, Yellow, Blue, Green)	
Buttons : Volume+/-, Volume-/-, Play/Pause, Power On/Off	
Accessories: 3.5mm Audio Cable, 5V 2A Power adapter	
Bluetooth and AUX connections	
Note: Product are improved continually. We reserve the right to modify the product and specifications without prior notice.	
FOR WARRANTY INFORMATION AND FEEDBACK, PLEASE VISIT WWW.BEFRESOUND.COM Support & Warranty (323) 306-3885	
SPECIFICATIONS BFS-33X 9	

4. The main unit front panel can be used in "AUX mode" to start/pause the streaming, or adjust the volume.

TROUBLESHOOTING GUIDE

This guide lists common problems and their solutions. Please refer to this guide before requesting service. If you need further assistance, please contact Bofee Technical Support.

The device is unable to connect to the speaker via Bluetooth:

- Turn the speakers off and back on. Try pairing again. Ensure that no other device is connected simultaneously to the speaker system as it will not pair with two devices at once.
- If you are consistently unable to pair your Bluetooth® device to the speaker, please ensure that any other Bluetooth® device in your vicinity, that has previously been connected to the speaker, has their Bluetooth® turned off.
- If you have previously paired your device with the speaker system and it is failing to connect to your device, try unpairing the speaker from your device through the Bluetooth® mode on your device. (Please refer to your device manual on how to unpair devices)
- The Bluetooth® may be disabled on your device. Enable the Bluetooth® on your device and try pairing again.
- Your device may be beyond the effective connecting range of the speakers. Move closer to the speakers. Range may be affected adversely by environmental conditions.

The device is connected but there is no sound.

- Disconnect all cables from the AUX input connector from the back of the speaker.
- Your device may be beyond the effective playback range of the speakers. Move closer to the speakers. Range may be affected adversely by environmental conditions.
- Ensure that the sound is actually playing on your device and not on pause.
- The volume on your device or on the speaker may be to its lowest.

8 | B5-33X | TROUBLESHOOTING GUIDE

SPEAKER OPERATION

CONNECTING POWER

In order to be able to use the 2.1 Channel Multimedia LED Dancing Water Bluetooth® Sound System, you will need to use the included power cord and plug it to an outlet.

Do not disassemble, incinerate, or heat the unit. Do not leave the unit in a place subject to direct sunlight, or in a car with its windows closed.

Do not connect the unit to a power source other than that which is indicated here or on the label as this may result in the risk of fire or electric shock.

TURNING YOUR SOUND SYSTEM ON AND OFF

To turn the speakers on, simply press the  button. Water will splash inside of the unit as it illuminates, and will be followed by a cue-tone.

To turn the speakers off, simply press the  button. Water will splash inside of the unit as if the LED lights go off.

SPEAKER OPERATION | BFS-33X | 5

PAIRING A DEVICE WITH BLUETOOTH®

A Bluetooth® enabled device must first be paired with the sound system before any music can be streamed.

To pair a Bluetooth® enabled device with the sound system:

1. Turn the speakers on.
2. Ensure that the Bluetooth® is enabled on your device. Enable it if it isn't.
3. Use your device to search for nearby Bluetooth® devices. (This function is usually in the Bluetooth settings menu; refer to your device's instruction manual to learn more.)
4. Select "BF3533K" in the list of available devices on your phone.
5. Once the pairing is successful, the sound system will play a sound alerting the user that music is now ready to be streamed.

If the pairing process fails, turn the speakers off and repeat the process. For faster trouble-free pairing, we recommend keeping the device within 3 feet of the speakers while pairing.

6 | BF35-33K | PAIRING A BLUETOOTH® DEVICE

USING THE SPEAKERS

When the speakers are connected to a Bluetooth® device, you can stream music wirelessly to the speakers from the device. For convenience, you can control the music directly from the main speaker unit with the following buttons:



Control light and water jumping



Decrease the volume level (press)



Increase the volume level (press)



Skip to the previous track (press and hold)



Skip to the next track (press and hold)



Turn the speaker on/off (press)

USING THE AUX INPUT CONNECTOR

You can connect devices without Bluetooth® by using the AUX 3.5 mm cable.

1. Use the included AUX cable to connect the device's headphone or line-out jack to the auxiliary input found at the back of the main speaker unit.
2. A cue-tone will indicate that the AUX mode is now enabled.
3. Set the device volume to 80% of its maximum and start playback from your device. If the music doesn't stream automatically even after pressing start on your device, try pressing the  button on the main unit and the music should start playing.

USING THE SPEAKERS | BF5-33X | 7