

 User Manual  Model :OJJI lite	SAFETY PRECAUTION 1. Use a wireless hands-free system (headphone,headset) with a low power Bluetooth emitter. 2. Make sure the cell phone has a low SAR. 3. Keep your calls short or send a text message (SMS) instead, This advice applies especially to children,adolescents and pregnant women 4. Use cell-phone when the signal quality is good. 5. People having active medical implants should preferably keep the cell phone at least 15cm away from the implant	Camera During the view-findings mode, press the left soft key, to carry out the following operations: Gallery: To display the file list. Settings: Modify some parameters set. For more information please read the help menu. Storage: To set the default storage path. Help: Some help information about camera. ⚡ Note: Please click the blank to show the OSD menu, then you can confirm them. Video recorder For more information please read camera details. Video The video supports 3GP and MP4 documents. If the document is the standard format not supported, use the tools to convert into standard format. ⚡ Note: You can add the videos in the memory card. Audio This function enables you to play songs. Select option to access the Play List, Select a song and then select Options to perform the following functions: ⚡ Note: The current system does not support some MP3 with a non-standard format. 1. Play: To play the specified music. 2. Details: Filename, Quality, Size, Time, and so on. 3. Add to Ringtones: You can use MP3 music as the ring tone for incoming calls. 5. Repeat>You can select Off, One or All. 6. Shuffle>You can select On/Off. Background Play > Press Red key to enter Background Play, the music will continue to play even if 7	you exit the Playing Screen (music will stop when a call is coming). ⚡ Note: Press Side Key to adjust the volume. FM Radio You can use your phone to listen to FM radio stations once the original Headset is plugged into the accessories connector. Sound Recorder The mobile phone supports recording. If there is a record, press the left soft key you can select: New Record, Settings and so on. Image browser Enter the “Image browser” to view the image files in the default folder “photos”. ⚡ File Manager You can use the function to manage all types of files saved in the memory card. ⚡ Organizer Bluetooth You can use Bluetooth transmission of documents directly. Search equipment to the transfer, In accordance with the onscreen instructions can operate, and accepts data, choose to receive the same, document will be automatically stored in the directory. Open Bluetooth: Bluetooth Switched on or off. Bluetooth Visibility: You can search audio device. Paired device: Can inquiry new device. My Bluetooth name: You can rename your Bluetooth. Address info: Check the Bluetooth address. 8
Thank you for choosing this mobile phone, this device will offer you unprecedented surprise for it can support GSM cards and multiple cards standby. Meanwhile, this phone is equipped with a 3 megapixel HD digital camera, a MP3 Mobile Music and a MP4 video player. Enjoy yourself! ⚡ Mounting The SIM Card/ T-Flash Card Keep all miniature SIM cards out of children’s reach. Please consult with your SIM card dealer on SIM card services and its usages. The SIM card dealer could be the service provider, network operator or other related dealers. ⚡ Note: Always make sure the phone is switched off before you insert or remove the SIM card, otherwise it may damage the SIM card. 1. Remove the battery cover by sliding it, insert the SIM card, with the notch at the upper left and the gold contacts face down, into the card slot. 2. Open the gold cap from the Hinge Type Connector. Lay the T-Flash card which gold contacts face down on the Connector; then close it. Align the card to the arrow sign as the following picture shows: 3. Replace the battery and close the cover tightly. ⚡ Charging The Battery 1. Connect the connector of the travel adapter to the phone. 2. Plug the travel adapter into a proper AC wall outlet. 3. When your phone indicates that the battery is fully charged, please pull the travel adapter out from the I/O socket. ⚡ Switching Your Phone On/Off 1. Press and hold Power key for a few seconds to switch your phone on/ off.	2. If the phone asks for a phone lock code, enter the phone lock code, and press OK. The default code is 1234. ⚡ Making/Answering Calls Enter the phone number (with the area code). According to your need, enter the country code or the extension number. Press the Pick up key to make a call. To answer an incoming call, press the Pick up key or the left soft key. To end or reject an incoming/ongoing call, press the Hang up key. ⚡ Using The Personal Hands free Handset Connect the hands free handset to your mobile phone, you can still answer calls and use the microphone without holding the phone. Travel Charge You can charge the phone with the Travel Charger when you are on the move. ⚡ Note: Please use approved accessories to get the most out of your phone. ⚡ Guidance On Entry Methods This phone provides input methods of ABC, abc, Numeric (123) and so on, etc. which can be used in editing the phone book, short messages, alarms and other text applications. Switch Input Methods Please click the  to switch the input methods. Press 0 to enter a blank space or “0”. Input Special Symbols If you want to input special symbols, such as “ . ! ? = < > ” , etc.Please follow the steps as below:	Help: Can read information about my devices. Alarm The mobile phone provides several alarms and you can set them as you need. Calendar You can view date with this function. Calculator The calculator can add, subtract, multiply and divide. Press “*”key to enter the decimal point. Press Clear to delete the figure. STK Service This service is offered as the SIM card service provided by the network operator. ⚡ Entertainment There is several interesting application in the phone. Please refer to instructions from the game help for more details. Some network don’t support the function. Please consult your network for more information. ⚡ Internet Internet is an application platform integrating wireless communication and Internet technology, which makes it possible for you to access to rich Internet information source and e-commerce application etc. ⚡ Safety Precautions Before using your phone, please read the following important information to eliminate or reduce any possibility causing damage and personal injury. ● Do not use wireless phones while driving.	● Switch off wireless devices in aircraft. The signal may cause interference. ● Do not use mobile phones at refueling point. Don’t use near fuel or chemicals. ● Follow regulations or rules in hospital and health care facilities. ● All wireless devices may get interference that could affect performance. ● Only qualified service personnel can install or repair this device. ● Use only approved accessories and batteries. ● Use only in normal position. ● Do not expose your phone to extreme high temperatures above+60℃(+140 F). ● Do not use anything static to clean your phone. ⚡ Battery Information Information Charging and Discharging ● Do not charge the phone in wet and damp conditions. ● Use only batteries approved by the phone manufacturer and recharge your battery only with the charges approved by the manufacturer. ● We strive to produce products in compliance with global environmental standards. ● The charger meets the standard for safety of information technology equipment and office equipment use. It must be used for this purpose only. ● When the battery level is low, “Low Battery” will be display on the screen. ● Do not leave the battery connected a charger for longer than 12 hours. ● Temperature extremes will affect the ability of your battery to charge. Tips for Battery ● Use the battery only for its intended purpose.
Press the “123*” key to display the symbols. ⚡ General Information Network Service A lot of features described in this manual are called network service. They are special services provided by wireless service providers. You should subscribe to these services from your home service provider and learn instructions onuses before you select the network you want to use. Phone Lock Code The factory setting for the phone lock code is 1234/0000. ⚡ Messages ⚡ Note: This service is supplied by the network. It enables the caller to leave messages when you can’t or unwilling to answer the incoming call. Please consult your network operator for more details. Text message Write Message: You can edit the SMS. Inbox: The phone will prompt you when you receive a new message. Outbox: This function is used to check messages in outbox. Drafts: This function is used to check messages in drafts. Templates: Your phone saves messages both for SMS in common use. SMS Settings: You can configure the default information about SMS properties. ⚡ Phone Book Quick Search You can fast locate the number of the person you want to contact. Please enter the initial letter of the person’s name, and related records about it will display in the middle of the screen.	Search Contact You can find the desired phone number from the phone book easily and quickly. Add New Contact 1. To SIM: Press the left key to select OK to start to edit the contact’s name and phone number. 2. To Phone: You can add the contact’s name, phone number and so on. Mark This function enables you mark one or mark all Phone Book List from the SIM card or the phone, then you can select copy, delete or other options. Delete You can select to delete entries from the SIM card, the phone or one by one. Copy All This function enables you copy all entries both from the SIM card and the phone. The copy content takes the smaller one as standard. Caller Groups You can set group name (like family), caller ringtone, caller picture and group members for different caller group. Others You can check the memory status, and configure the Caller ID, Show number style. Caller Picture / Ring Tone Each of picture / ring tone can be selected to the new contact / the selected contact caller group. ⚡ Call Log The phone registers missed calls, dialed calls, received calls, and also registers the approximate	● Do not disassemble or modify the battery by yourself. ● Do not clean the battery with water or any organic solvent. Always keep the battery dry. ● Do not short-circuit the battery. ● Do not dispose of batteries in fire. ● If you smell anything strange from the battery or find that the battery is overheated, you should stop using it immediately. ⚡ Emergency Calls This phone, like any wireless phones, operates using radio signals; wireless and landline networks which cannot guarantee connection in all conditions. Therefore, you should never rely solely upon any wireless phone for essential communications (e.g. medical emergencies) To make an emergency call: 1> Switch your phone on. Some networks may require that a valid SIM card is properly inserted in the phone. 2> Dial the official emergency number. Emergency numbers vary by location. While making an emergency call, please remember to give all information as particularly as possible. Never hand off the call please until you are given permission to do so. ⚡ Troubleshooting The section lists some problems that you might meet while using your phone. Can not answer or make a call : ● Make sure that the phone has been switched on. ● Make sure that the signal intensity is high enough.	● Make sure that the line switch in call setting is the system preset line. Default is line 1. ● Check whether you have set up call barring or fixed dialing or any other safety function. ● Check whether you have set up call divers. Low voice : ● Check whether the ring volume is not too low. No ring : ● Check whether you have set up the “Silent” option. ● Move away from a noisy place to check if you can hear the phone ringing. ● Check whether you have set up call divers. ⚡ Manual Statements 2012. All rights are reserved. No part of this document may be reproduced without permission. All trademarks and brand names mentioned in this publication are property of their respective owners. While all efforts have been made to ensure the accuracy of all contents in this manual, we assume no liability for errors or omissions or by statements of any kind in this manual, whether such errors are omissions or statements resulting from negligence, accidents, or any other cause. The contents of this manual are subject to change without notice.  Protect your environment! We strive to produce products in compliance with global environmental standards. Please consult your local authorities for proper disposal.
length and cost of your calls and the amount of sent or received messages (network service). SIM1/SIM2 call history Missed Calls: displays the list of recent missed phone numbers; Dialed Calls: Displays the list of recent dialed phone numbers; Received Calls: Displays the list of recent received phone numbers. Delete Call Logs: You can delete all records of missed calls, dialed calls or received calls with this function or Delete all folders drastically. Call duration: Recording the call duration. Call Cost: You can check the whole call’s fee. ⚡ Note: This function is related with the SIM card. PIN2 is provided from the network operator. Please consult your network operator to obtain the number. ⚡ Settings ⚡ Standby mode You can set three modes. When flight mode is opened, all wireless devices will be closed. Call Settings SIM1/SIM2 Call Settings (Net work Service) Hide ID> The default status is the Set Display ID by Network. Network Selection> You can configure the following options: Auto Select, Manual select. Call Divert: This network service allows you to divert your incoming calls to another number. Call Barring: This network service allows you to restrict incoming calls from your phone. Call Waiting: The network will notify you of a new incoming call while you have a call in progress.	Select Line: Switch to Line 1 or 2, the default one is Line 1. Others: the settings item include 50 secs warning, Auto redial, Vibration for outgoing calls . Phone Settings Time and Date: You can set Time/Date, Time Format and Date display type. Select Language: Select the desired language for the display text. Auto Power On/Off: You can set the time for auto power on/off. Power Management: Display the battery power information. Restore Factory Settings: All settings can be restored to factory settings with this function. The factory setting for the password is 1234/0000. Display Settings You can configure the wallpaper, Idle display settings, Contrast, Backlight, Power on/off display and so on. Security Setup Your phone is equipped with a versatile security system to prevent unauthorized use of the phone or the SIM card, such as SIM1/SIM2 security setup, Phone Lock, Data security, Auto keypad Lock, and Change Password. User Profiles You can select General, Meeting, Outdoor or Indoor. For each mode, you can configure the Ring settings, Adjust Volume, Call alert, Message alert, Extra ringtone according to your need. ⚡ Note: Insert the earphone to access the Headset mode automatically. This mode has no Activate option. ⚡ Multimedia		

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

This 3G Smart phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: OJJI lite (FCC ID: 2AE2XOJJILITE) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.344W/kg and when properly worn on the body is 0.982W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.