



The Smart Way to Manage Your Restaurant Operations

GoLabel is a wireless label printer designed to work with a tablet running GoOps or SubOps.


GoLabel simplifies your food prepping and labeling procedures. This Quick Start Guide will help you familiarize yourself with GoLabel before you get started.




www.zippyuum.com
support@zippyuum.com
(888) 636-7557

SETUP


- 1 Plug in and turn on your GoLabel printer




- 2 Insert the spindle into the roll of labels, then insert the roll into the printer aligning the spindle into the slots



- 3 Download and install the GoOps or SubOps app on a compatible tablet



GOOPS
⚙️⚙️



SUBOPS
⚙️⚙️

SETUP

4

Enter your credentials and log into the app

If you've registered, sign in
using your credentials

Restaurant#

Password

Sign In




5

From the main menu, go to "Settings," then select "Printer" and "Connection Settings" Make sure your printer is turned on. Tap on the printer to connect to it.

General	Connection Settings
	Printers Settings
Printers	Allowed Printers
User Sessions	
Bread & Prepping Settings	
Configuration	
Dev Options	

GETTING TO KNOW YOUR GOLABEL HARDWARE

- 1 Cover Release Button
- 2 Connection Indicator
- 3 Error Indicator
- 4 Pause Button
- 5 Feed Button
- 6 Power Button
- 7 Paper Loading Axis



Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

