



FRS TACTICAL WALKIE TALKIES

User's Manual

5+




Thank you for purchasing your Nerf FRS Tactical Walkie Talkies. You can use these walkie talkies to easily talk to your friends at distances up to 1000 feet away. In addition, your walkie talkies glow in the dark, helping you see them even in low lighting. For best results, read this instruction manual first before using.



ITEM #
WT3-01056A

INSERTING BATTERIES

Each walkie talkie requires four AAA batteries for power. To insert or replace batteries, use a screwdriver to remove the screw on the battery compartment door. Note that the battery compartment is located on the rear of each walkie talkie. Once the battery compartment is open, insert batteries with the correct polarity (+, -) as displayed in the battery compartment. When batteries have been inserted, close the battery compartment, and once again use a screwdriver to screw the battery compartment door in place.



USING YOUR WALKIE TALKIES

Once batteries are inserted you can follow the steps below to use your walkie talkies:

1. Slide the ON/OFF Switch on each walkie talkie to the ON position. The indicator light will illuminate.
2. Hold one walkie talkie close to your mouth.
3. Press the PUSH TO TALK button, and speak clearly to transmit a message to the other walkie talkie.
4. Release the PUSH TO TALK button when you are finished talking so that you can hear any incoming messages from the other walkie talkie.
5. When you are finished using your walkie talkies, make sure the ON/OFF Switch is in the OFF position.
6. Put your walkie talkies in sun light or bright light, glow in the dark effect will be better.

SETTING THE TIME

The LCD Screen can display the current date and time. To set the date and time, follow the steps below.

1. Press the left clock setup button repeatedly to toggle between the settings (month/date/hour/minute).
2. Press the right clock setup button repeatedly to adjust the (month/date/hour/minute) setting to your liking.
3. When complete, the time will display on the LCD Screen. Tap the right clock setup button at any time to display the date.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B

digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Safety Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. Your wireless handheld portable transceiver contains a low power transmitter. When the talk button is pushed, it sends out radio frequency (RF) signals. The device is authorized to operate at a duty not to exceed 50%. For body-worn operation, this radio has been tested and meets the FCC RF exposure guidelines when used with manufacturer accessories supplied or designated for this product. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. Use only the supplied antenna. Unauthorized antennas, modifications, or attachments could damage the transmitter and may violate FCC regulations. Hold the transmitter approximately 2 inches (25mm) from your face and speak in a normal voice, with the antenna pointed up and away.

Sakar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but not limited to, repair by unauthorized parties, tampering, modification or accident.

To obtain Warranty Service and Troubleshooting information:
Call 1-877-397-8200 visit our website at www.sakar.com.

WARNING:
CHOKING HAZARD
This article contains small parts which pose a hazard to children under 3 years.

BATTERY WARNING:
Do not mix old and new batteries.
Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
Batteries are not to be inserted with the wrong polarity.
Exhausted batteries are to be removed from the toy.
The supply terminals are not to be short-circuited.

Please recycle or dispose of the battery properly. Contact local recycling facilities and/or the manufacturer of your battery for further information.

PACKAGING CONTENTS:
2 WALKIE TALKIES,
USER MANUAL

Keep Manual and All Relevant Information
for Future Reference

NERF is a trademark of Hasbro and is used with permission.
© 2020 Hasbro. All Rights Reserved. Licensed by Hasbro.

©2020 Sakar International
195 Carter Drive
Edison, NJ 08817

Licensed By:

