



Key Schematic Diagram



Operation Guide

Tips
1. Before using this product for the first, please charge the battery for 4-6 hours to activate the battery completely.
2. To connect the Bluetooth, please turn on the Bluetooth of the mobile phone first, and then turn on the power of the Bluetooth phone.
Turning on
Turn the power switch to ON, and the device makes alert tone and connects automatically (detection time: 5sec)
Pairing prompt
After turning on, the answer key flashes red and blue alternatively, pairs with the mobile phone that has enabled Bluetooth in 150 seconds automatically, and makes alert tone after pairing successfully.
Pairing two mobile phones simultaneously
Turn on the first mobile phone and enter the pairing state, press and hold the Bluetooth key for 5 seconds after having paired to enter the pairing state again, and the first mobile phone will be disconnected; then, pair the second mobile phone, and then tap Connect on the first mobile phone, and the two mobile phones are paired simultaneously.**The passwords is:0000(if needed)**
Schedule off
In pairing state, if there is no mobile phone connected in 150 seconds, the device will turn off automatically (soft off) and make alert tone; the switch is in the OFF position at this moment.
In addition, if there is connection in 10 minutes after the mobile phone is disconnected from Bluetooth, the device will turn off automatically.

Restart vibrated

In the swith off stage, if you want to restart the device,you just need to shake anything nearby and it will work(shock like closing the door is available)
Answering/ending a call
When there is incoming call, the device makes ringtone alert, and you can press the Answer key to answer the call, and press the key again when the call ends.
Low battery alert
The red indicator flashes quickly for three times every 3 seconds, and the charging time is about 2 hours.
Charging indicator
Whether the switch key is in ON or OFF position, the red indicator is constantly lighted while charging, and is turned off after having charged.
Turning off
When the switch key is moved to OFF position, the device cuts off the power supply, turns off and doesn't make any alert tone.
Mobile voice navigation
When using the map navigation phone beep can be expanded via Bluetooth intercom voice navigation, long press the volume key for volume adjustment and subtraction, there is a beep.

Accessories

Car charger	1pcs
USB data cable	1pcs
Manual/Warranty Card	1pcs

Parameters

Output power	2W
Frequency response	180Hz~16KHz
Impedance	8Ω
SNR	≥70dB
Distortion	0.5%
Battery specification	BL-4C/3.7V/600mAh
Charging voltage	DC 5V
Dimensions	L115*W60*H48 mm
Net weight	89±3g (excluding clip)

Warranty Card

When you buy the product, please fill in the card and keep it properly. The accessories are not covered by the warranty.

Client Name		Sex		Age	
Address					
Phone No.				Postal Code	
Place of Purchase					
Date of Purchase			Sales Order No.		
Product Model			Product No.		
Dealer Stamp			Client Name		

Shenzhen Soaiy Technology Co., Ltd
ADD: 4/F, Bldg D,Fuxinlin Industrial Park, Hangcheng Industrial Zone,Xixiang Street,Bao'an District,Shenzhen,China
Hotline: +86 400-042-1588
For more information, please visit the official website:
www.soaiyaudio.com

* The pictures and function text of the product on the package have been checked in detail. If there is any printing error, the Company shall assume no responsibility. The actual product shall prevail.
* The trademark and logo of "Soaiy" have been register and are protected by the intellectual property law. Without permission of the Company, any counterfeiting is prohibited. All rights reserved.
* The product is subject to change without prior notice. The right of final interpretation is reserved by Guangzhou Soaiy Digital Technology Co., Ltd.

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirement , The device can be used in portable exposure condition without restriction.