

Bluetooth Speaker

S-35

User manual

Turning on

Turn the power switch to the ON position to turn on the player.

Playing music

If a memory card has been inserted when the player is turned on, it will enter the music mode automatically, play an alert tone, and then play the music stored on the memory card automatically. Press  or  and there will be appropriate alert tone. Press and hold  or  to adjust the volume. Press  to pause / play music.

Pairing mobile phone

When turned on, the player will enter pairing mode automatically if there is no memory card inserted. You can also press the M key to enter the pairing mode if a memory card is inserted. The player will play an alert tone, and the red and blue background lights flash alternately, indicating that the player is searching for Bluetooth mobile phone for pairing. After connecting, it will play an alert tone (password: 0000).

Connecting Bluetooth call

When there is an incoming call, press the  key directly to answer the call, or press and hold the  key to hang up.

When the call is connected, press and hold the  or  key to adjust the volume, and press the  key again to end the call.

Double tap the  key to call the last dialed number directly.

Mobile voice navigation and audio transmission function

The voice prompt of mobile phone navigation can be increased via Bluetooth intercom.

While playing music after the mobile phone is connected to the player via Bluetooth, press  or  to switch to the previous/next track, press and hold the  or  key to adjust the volume, and press the  key to pause/play music.

Low battery alert

There will be voice prompt when the battery voltage is low.

Turning off

When the power switch is turned to OFF, the player cuts off all power, shuts down and doesn't play alert tone.

Product Parameters

Output power: 3W	Frequency response: 120~18KHz	Impedance: 4Ω	SNR ≥ 70dB
Battery specification: 3.7V/800mAh	Charging voltage: DC-5V	Dimensions: 76*76*63 mm	Net weight: 183g

Parts List

Player*1	AUX audio*1	Micro data cable*1	Manual*1
----------	-------------	--------------------	----------

Key Function Diagram

① Mode switch key	② Press to play previous track; press and hold to decrease volume	③ Press to play next track; press and hold to increase volume
④ Pause / play	⑤ Answer / end a call via Bluetooth	⑥ Microphone hole
⑦ Power switch	⑧ Charging port	⑨ TF card slot
⑩ AUX audio cable port		

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirement , The device can be used in portable exposure condition without restriction.