

Bluetooth headphone

Thank you for selecting our latest Bluetooth headset, please read this User's Manual carefully before you operate this headset, and please save this Manual for further reference. Before operating, please read all the Safety notice to make sure the safe and appropriate use.




Safety Notice:

- Please observe the rules of the Country or Region which you are in while driving.
- Do not disassemble or modify the headset at any reason, otherwise, It may damage or burn the headset.
- If there is any quality problem, please send the headset to authorized service center for repairing.
- Please keep the equipment along with all the accessories out of the reach of children and pets. It will cause suffocation and serious injury.
- Do not put the device under the environment which the temperature is too low or too high (Below 0°C or over 45°C).
- Extreme temperatures will cause the device deformation, reduce the charging capacity and shorten the working life.
- Please do not wet the device, for the liquid can cause serious damage to the device. Please do not touch the device by wet hands. It is out of the maintenance range for the damage caused by water.
- Please avoid closing to the eyes of children and pets when using the flash indicator of the device.
- Please do not operate the device in thunderstorm weather.

07

1. Guide

■ Headset introduction



08



It will damage your hearing if you listen with high volume for a long time. It is recommended that only use the lowest volume which is necessary for speaking and listening to music.

2. Instruction

■ Key Function

Power on Pairing	Press the key for 5 seconds to switch on and enter into pairing mode (The red indicator flashes once and the blue indicator flashes twice, and then the red and blue indicators take turns to flash)
Power off	Press the key for 3 seconds to switch off (the red indicator flashes once)
Receive Hang up phone call	When calls coming, press the key once to receive phone calls, press again to hang up phone calls, Press the key for 2 seconds to reject phone calls
Play/Pause	In music mode, press the key once to pause, and press it again to play. (when phone call comes, the music will be off. When phone call is off, the music will continue)
SIRI	When the bluetooth is on, press the key twice shortly can activate siri function

3. Bluetooth Indicator Status

Work Status	Indicator Light Status	Remark
Switch on	Red indicator flash once Blue indicator flash once	
Switch off	Red indicator flash once	
Pairing Mode	Red and blue indicators take turns to flash	
Connection	Blue indicator will flash once every 6 seconds	
Phone call	Blue indicator will flash once every 6 seconds	
Play Music	Blue indicator will flash once every 6 seconds	

09

Low battery warning	Red indicator will flash once every 60 seconds	
Charging	Red indicator is on all the time when charging; the light is off when charged full	

4. SIRI :

The function only applies to phone with siri itself

- (1) Turn on the bluetooth function of the phone.
 - (2) Press "⏻" for 5 seconds to switch on and enter into pairing mode when the red and blue indicators take turns to flash.
 - (3) Find "180s BT" from the device list of the phone and make connection.
 - (4) Press the key twice shortly to activate siri function.
- 3) Microphone on the phone will appear at that time, and you can use siri directly.




10



5. Headset Charging

This headset is equipped with built-in non-detachable and rechargeable battery. Please make sure that the battery is charged full for the first time use.

- Connect the charger to the charging port.
- Insert the charger into the standard power outlet. During the charging, indicator will turn to Red. If without charging, please plug out the travel charger first, then connect it again.
- After full charging, red indicator will be off. Please plug out the travel charger from the power outlet and headset.
- It will reduce the battery performance after long time / repeatable charge and dis-charge.
- And it is normal phenomenon for all the rechargeable battery. Please do not dial or receive phone call during charging, and please plug out the charger from the headset, then receive the phone call. When the battery is low, the headset will appear the prompt and the red indicator will flash.



11

6. Project Specification and Instruction

- Bluetooth Version : V4.0
- Supported devices: Bluetooth mobile phones, Bluetooth speakers Bluetooth PC and other Bluetooth devices
- Maximum work range: 33 Feet (10 Meters)
- Talk time: About 15 Hours
- Music play: About 13 Hours
- Charging time: 2.5 Hours
- Charging Voltage: DC 5V
- Work Voltage: 3.7V 250MAH
- Sensitivity: 105±3dB
- Frequency Response: 20Hz~20KHz

※ The actual time may vary from mobile phone types and functions.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential

installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.