



3G flip

User Manual

Basic Knowledge

- Introduction**
- Thank you for choose our digital color screen mobile phone. By reading these guidelines before using your mobile phone you will have an overall knowledge of this phone set and understand its simple but outstanding functions.
 - This phone set is designed for GSM/GPRS networks. On top of basic functions, it enables you to use name card style contacts, clock/ alarm, calendar, calculator, games, audio player, camera , video recorder , image,FM radio and other functions. It serves your work and leisure time. Having unique interface and perfect feature designing this phone set meets all your expectation.
 - Our phone set meets the GSM/GPRS standard and has the qualification from related organizations worldwide.
 - Our company reserves the rights modifying the content in this Instruction without pre-notify.
 - Safety information**
 - Under the circumstance of stealing and lost, contact the telecom branch or sales outlet immediately.
 - When you contact with telecom branch and sales outlet, it is necessary to provide them with IMEI number (printed on the back of the phone set, remove the battery to discover it). Please record the IMEI number and keep it safe for future use.
 - To prevent miss usage of your phone set please take precautions such as:
 - Set the PIN number of the SIM card, and update it timely
 - When get off the car. Please do not leave the phone set unattended, keep it with you or in the suitcase.
 - Set call barring.

- Safety and health precautions**
- Read the guidelines before using your phone. Failure to comply with them may be dangerous.

Description of Keys	
Name of key	Letters or functions
1key	*1*~*9* ; / / 1
2key	ABCabc
3key	DEFde f3
4key	GHIghi4
5key	JKLjkl5
6key	MNOomn6

7key	PQRSpqrs7
8key	TUVtuv8
9key	WXYZwxyz9
0key	0
key	1.after inputting telephone number, if you want to input extension number, please press twice asterisk key, after the display screen shows "+", please input your extension number. 2...?!@:~#\$/-.....
#key	1. In text editing interface, press "#" key to switch text the inputted location. 2. On the standby interface Press and hold "#" key to transfer the profile of General/Silent/Vibrate.
Scrolling Up	Move cursor up
Scrolling down	Move cursor down
Scrolling left	Move cursor left
Scrolling right	Move cursor right
Left soft key/Right soft key	In the standby mode, press Left Soft key to access Main menu, Right Soft key to access Contacts.
Ok key	determining options
Dial key	dial telephone numbers and receive incoming calls
End	1.Return to idle screen 2.End calls or reject incoming calls.

Description of functions

	The SIM1 card's signal strength of the cellular network
	The SIM2 card's signal strength of the cellular network at your current location.
	The battery charge level.
	Contacts

	Message
	Call logs
	Settings
	Multimedia
	File manager
	Application
	Profiles
	Internet
	FM Radio
	Audio
	Calendar

In the main display, you may see several icons shown on your status bar.

1. Contacts

You can use the Contacts features business card information will be stored to mobile phones.

1.1.Quick search
Enter the name of the first letter in the contacts to find qualified records.

1.2.New
In the options, add a telephone number to phone or SIM card.

1.3.Delete multiple
choose to delete phone numbers from SIM or Phone, you can mark all of the phone numbers then choose "OK" to delete . you can also choose to delete them one by one.

7. Application

7.1. Calculator
This function enables you to add, subtract, multiply and divide.
The screen will initially display the number "0". Enter the first number to be calculated.

7.2.Alarm
To set a new alarm, alarm clock icon will be displayed when an alarm is active.
At the same time, three groups can be set up alarm clock.

7.3.Bluetooth
Your phone provides the following selections for your option: Bluetooth/Bluetooth visibility/Paired device/Transferring files/device name/Bluetooth file storage/help
According to the menu, will enter the corresponding function set.

8. Profiles

Normal: Suitable for normal use.
Silent:Suitable for silent use.
Meeting: During the meeting, suitable for use.
Outdoor: Suitable for outdoor use
Indoor: Suitable for indoor use.

9. Internet

The service is provided by network operator. If SIM card or network operator fails to provide the service, the function can not be available. Contact network service operator, if you want to have more information.

10. FM radio

You can listen to Fm radio freely with plug in the earphone. Enter the radio interface, search the frequency. (87.5-108.)
Auto search and save/Channel list/save/Manual search/closed/open speaker/background play
~Auto search and save/Search frequency available automatically.

1.4.Import/Export

Copy
Copy contacts from phone/SIM card to SIM card/phone.

Import contacts
Import contacts file from phone or memory card to Contacts.

Export contacts
Choose some phone numbers in contacts then export them to phone or memory card.

1.5.Others

Own number
To edit the name and the number of your SIM card.

Service number
Support the steps for reaching actual people to solve your problem.

Memory status
To view the capacity of SIM card and phone.

1.6.groups
You can view and edit the details of the group and members of the group to remove or add operation.
Your phone provides the following selections for your option:
Family/Friends/Business/Classmates
New group
Add a new group
Mass texting
Send SMS to many phone numbers that you select from Contacts.

2. Message

2.1.Write message
You could write new message by using this function. When you input the message to be sent, press left soft key to send, to insert the templates, to add contact person information, to add phiz and to save, etc. Within the write message menu you can write and edit text message up to 160 characters.

2.2.Inbox
After you have an incoming text message. The phone stores the message in the inbox folder of the SMS menu.

2.3.Outbox
When you fail to send a message. The phone stores the message in the outbox folder.

~ Channel list: You can view all the broadcasting stations you saved.
~save:Save a channel to channel list.
~Manual search: Search the broadcasting station by input frequency manually.
~closed/open speaker:You can start up loudspeaker to make the sound louder.
~background play:you can do other operations while listening to the radio.
~Record-to record a channel.
~Timing record to set the time of recording and the channel.
~Record file list:the record file you have recorded.

11. Audio

Key Audio Play Function
Press can play or pause MP3
Short press can choose the previous and next MP3, long press can fast back or fast forward.
Note: You can adjust this volume +/- through scrolling up/down key.
Music list:to list the musics of your phone and memory card.
Add-to saved play list:to new play list
Set as ringtone:set as incoming call ringtone/set as alarm ringtone
Shuffle:whether to shuffle play
Repeat:set the play mode,off/repeat all/repeat one
Settings:Equalizer/BT stereo output/BT stereo headset
Open review:to review MP3

12. Calendar

To view the calendar.

1.4.Import/Export

Copy
Copy contacts from phone/SIM card to SIM card/phone.

Import contacts
Import contacts file from phone or memory card to Contacts.

Export contacts
Choose some phone numbers in contacts then export them to phone or memory card.

1.5.Others

Own number
To edit the name and the number of your SIM card.

Service number
Support the steps for reaching actual people to solve your problem.

Memory status
To view the capacity of SIM card and phone.

1.6.groups
You can view and edit the details of the group and members of the group to remove or add operation.
Your phone provides the following selections for your option:
Family/Friends/Business/Classmates
New group
Add a new group
Mass texting
Send SMS to many phone numbers that you select from Contacts.

2. Message

2.1.Write message
You could write new message by using this function. When you input the message to be sent, press left soft key to send, to insert the templates, to add contact person information, to add phiz and to save, etc. Within the write message menu you can write and edit text message up to 160 characters.

2.2.Inbox
After you have an incoming text message. The phone stores the message in the inbox folder of the SMS menu.

2.3.Outbox
When you fail to send a message. The phone stores the message in the outbox folder.

2.5.Drafts
When you save a message you have written. The phone stores the message in the drafts folder.

2.6.Security inbox
You can move a message from inbox ,outbox,drafts,sendbox to security inbox.

To enter the security inbox,you should input the security inbox password.

2.7.Templates
Your phone offers you a list of templates that you can use in replying to short messages. You can also use templates when writing messages.

2.8.Broadcast message
Send or receive message to same area subscribers in Broadcast Message mode. You also can turn this function on/off here.

Receive mode: ON/OFF broadcasting function.
Language: Turn On/Off all languages.
Channel Setting: Set Broadcasting Message parameter.

2.9.Voice mail server
Line 1 number /Fax number/Data number

2.10.SMS Settings
SIM1 message center/SIM2 message center:to show your text message center

2.11.Message capacity
to view the SMS memory of SIM card and phone.

Warning

- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
~Reorient or relocate the receiving antenna.
~Increase the separation between the equipment and receiver.
~Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
~Consult the dealer or an experienced radio/TV technician for help.

- SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. In general, the closer you are to a wireless base station antenna, the lower the power output.

- Before a new model phone is a available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body)as required by the FCC.

- For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that Contains no metal and that positions the handset a minimum of 5mm from the body.

- Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

- 11 -



3G flip

Manual Del Usuario

1. Información básica

1.1 Instrucción
Gracias por elegir el nuestro teléfono móvil Maxwest . Las Instrucciones sobre cómo hacer funcionar el teléfono se detallan en este manual del usuario.

1.2 Para su seguridad
Por favor revise estas sencillas instrucciones para su propia seguridad. No seguir estas instrucciones puede ser peligroso o ilegal.
Lea la guía del usuario para obtener más información. Nota: La calidad de la llamada y la conexión depende de su proveedor de servicio local y de la señal. No nos hacemos responsables de cualquier daño físico o daños materiales debido a un uso inadecuado.

2. Apariencia

2.1 Descripción del teclado

2.1.1 Izquierda / Derecha tecla de navegación
Mover el cursor a la izquierda o derecha durante la edición. Mientras que en reposo, oprima la tecla izquierda de navegación al menú [Bandeja de entrada], pulse la tecla de navegación hacia la derecha al menú [perfiles]. Durante el uso de la aplicación de la cámara, pulse la tecla izquierda / pulse la tecla izquierda de navegación puede abrir el menú de opciones, pulse la tecla de retorno de navegación derecha al menú anterior.

2.1.2 Tecla arriba / abajo de navegación
Ver el nombre, número de llamada, mensaje y todas las opciones del submenú. Mover el cursor a arriba o hacia abajo cuando edición. En estado de reposo, presione la tecla de navegación al menú [alarma].

2.1.3 Tecla suave izquierda
Para realizar la función del indicador que aparece en la esquina inferior izquierda de la pantalla.

2.1.4 Tecla suave derecha
Para realizar la función del indicador que aparece en la esquina inferior derecha de la pantalla.

2.1.5 Tecla de marcación
Para marcar o extracto de un número de llamada entrante. En el modo de espera, presione la tecla de marcación para mostrar la llamada SIM1 archivos.

2.1.6 Tecla colgar
Para finalizar una llamada o rechazar llamadas entrantes. Mantenga pulsado este botón par el encendido / apagado. Bajo la mayoría de circunstancias al pulsar esta tecla pondrá el telefono móvil en modo de espera.

2.1.7 Número clave
0 ~ 9 tecla numérica número de entrada de Can y palabra, la velocidad para seleccionar el menú de opciones, llamada velocidad (la llamada debe ser almacenado en el directorio telefónico).

2.1.8 Tecla *
Tiene función diferente en diferentes menús.

2.1.9 Tecla #
Tiene función diferente en diferentes menús.

2.1.10 Medio clave
En el modo de espera, presione la tecla para entrar en el menú principal. En otros submenús, que funciona igual

que la izquierda tecla de función.

2.1.11 EX1
En el modo de espera, llave EX1 presione para entrar en los registros de llamadas SIM2.

2.1.12 EX2
En el modo de espera, presione la tecla de cámara o EX2 FM u otro menú principal.
Consejo: En este manual, la frase "pulse la tecla" se refiere a pulsar y soltar un tiempo clave
"Mantenga pulsado una tecla" se refiere a pulsar una tecla y mantener pulsado durante 2 segundos o más.

2.2 Icono Descripción

	Cuántas más barras aparezcan, mayor será la intensidad de la señal
	GPRS conectado
	bloqueo de teclado
	Vibrar
	Anillo y vibran
	Anillo
	Vibrador y después melodía
	auricular de entrada
	Indicador de itnerancia
	Indicador SMS
	Indicador MMS
	Mensaje de voz
	Configuración y alarma abierta
	SIM1 abierta Desvío
	SIM2 abierta Desvío

La llamada de SIM1
 La llamada de SIM2
 Estado de la batería
 Bluetooth abierto
 cronómetro de usos múltiples abierto

2.3 De la batería
Para un uso óptimo por favor asegúrese de que el celular se carga a plena capacidad antes de usar.

2.4 Conectar Red

2.4.1 Tarjeta SIM
Asegúrese de que se inserta una tarjeta SIM antes de utilizar su teléfono. La tarjeta SIM debe ser proporcionada a usted por su proveedor de servicios.
Esta información es almacenada en la tarjeta SIM, tales como información de contacto, agenda, mp4 / mp4, etc se almacena en la tarjeta SIM. Para un uso óptimo de no tocar la parte metálica de la tarjeta SIM y mantenerlo alejado de los imanes y la electricidad. Si la tarjeta SIM se ha roto el teléfono o el teléfono podría no ser capaz de completar todas sus funciones.
Advertencia: Antes de insertar o extraer la tarjeta SIM, asegúrese de que el teléfono está apagado. Asegure que el teléfono no está conectado a una fuente de alimentación externa, ya que esto podría dañar potencialmente la tarjeta SIM.

2.5 Funciones características

2.6 Realización de llamadas
En estado de reposo, pulse la tecla de número a número de llamada de entrada, pulse la tecla de función derecha para borrar la entrada error, mucho tiempo pulsar la tecla de función derecha para borrar todas las entradas. Pulse la tecla programable izquierda para guardar el número de llamada de teléfono o tarjeta SIM. Pulse la tecla de marcación para realizar una llamada. En estado de la llamada, puede dirigir tecla numérica de prensa para el número de entrada si es necesario. Para realizar llamadas internacionales se debe pulsar la tecla "0" hasta que aparezca el prefijo telefónico internacional "+" en la pantalla ("+" en lugar de 00).

2.7 Las llamadas de emergencia

2.8 Responder a una llamada

2.9 Finalizar una llamada

2.10 Historial de llamadas

2.11 opción de llamada

3. Función

3.1 Teléfono libro
Puede guardar campos de información ya sea a su tarjeta SIM o el teléfono, esta información incluye el nombre linkman, número de teléfono, número de casa, nombre de la empresa, correo electrónico, teléfono de la empresa, número de fax, cumpleaños, tono de llamada selecto, grupo de llamada. Mientras la prensa de inactividad la tecla derecha para "libreta de teléfonos", ver el registro de llamadas.
NOTA: El auricular almacenar max 250 pcs registros telefónicos, base de la memoria de la tarjeta SIM en la misma capacidad.

3.2 Mensajes
Mientras la tecla de navegación para seleccionar "Mensajes" para entrar en el submenú, incluyen SMS, MMS, Chat y mensajes de voz del servidor de difusión.

3.2.1 SMS
Enviar un mensaje de texto por el Centro de Servicio. La ayuda del micro teléfono del MMS y se puede insertar la imagen, animación, melodía, tono de llamada en un mensaje.

3.2.2 MMS
Acerca de MMS
MMS o "servicio de mensajes multimedia", es la mejor manera de apoyar multimedia y es capaz de enviar mensajes de texto, imágenes, sonidos y otra información de formato multimedia.

Calentamiento

- Cualquier cambio o modificación no aprobados expresamente por la parte responsable del cumplimiento podrían anular la autoridad del usuario para utilizar los equipamiento. Este dispositivo cumple con la parte 15 de las normas de la FCC. La operación está sujeta a las siguientes dos condiciones:
(1) Este dispositivo no puede causar interferencias perjudiciales y
(2) este dispositivo debe aceptar cualquier interferencia recibida, incluyendo interferencias que puedan causar un funcionamiento no deseado.

Note: Este equipo ha sido probado y cumple con los límites para un dispositivo digital de Clase B, de acuerdo con la parte 15 de las normas FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias perjudiciales en una instalación residencial. Este equipo genera, utiliza y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencias perjudiciales a la radio de comunicaciones. Sin embargo, no hay garantía de que no se produzcan interferencias en una instalación particular. Si este equipo causa interferencias perjudiciales en la radio o la recepción de televisión, que puede ser determinada gracias al equipo apagado y, se recomienda al usuario que intente corregir la interferencia mediante una o más de las siguientes medidas:
~Reorientar O reubicar la antena receptora.
~Aumentar la separación entre el equipo y el receptor.
~Conecte El equipo a una toma de un circuito distinto de aquel al que está conectado el receptor.
~Consulte A su distribuidor o a un técnico de radio / televisión para obtener ayuda.

- Las pruebas de SAR se realizan en posiciones de funcionamiento estándar aceptadas por la FCC con el teléfono transmitiendo a su nivel más alto de potencia certificado en todas las bandas de frecuencia probadas, aunque el índice SAR se determina el máximo nivel de potencia certificado, el nivel SAR real del teléfono en funcionamiento puede estar muy por debajo del valor máximo, en general, cuanto más cerca se encuentre de una antena de estación base inalámbrica, menor será la potencia de salida.

- Antes de que un nuevo modelo de teléfono es una disponible para su venta al público, debe ser probado y certificado ante la FCC que no excede el límite de exposición establecido por la FCC, pruebas para cada teléfono se realizan en posiciones y ubicaciones (por ejemplo, en el oído y llevándolo en el cuerpo) requeridas por la FCC.
- Para usarlo en el cuerpo, este modelo de teléfono ha sido probado y cumple con las pautas de exposición a RF de la FCC cuando se utiliza con un accesorio designada para este producto o cuando se utiliza con un accesorio que no contiene metal y que posiciona el dispositivo a una distancia mínima de 5mm del cuerpo .

- El incumplimiento de estas restricciones puede resultar en violación de las normas de exposición RF.

- 11 -